Ethernet [Modbus/TCP] Communication Converter

COM-JL [For FB100/FB400/FB900] Data List

All Rights Reserved, Convright @ 2006, RKC INSTRUMENT INC

MR01Y21-F3

This manual describes the communication data of the COM-JL. For the installation, the detail handling procedures and various function settings, please refer to the following separate manuals.

 $\bullet \ \mathsf{COM\text{-}JL} \ [\mathsf{For} \ \mathsf{FB100/FB400/FB900}] \ \mathsf{Installation} \ \mathsf{Manual} \ (\mathsf{IMR01Y05\text{-}E\square}) :$

URL: http://www.rkcinst.com/english/manual_load.htm

Attached to the product
• COM-JL [For FB100/FB400/FB900] Quick Instruction Manual (IMR01Y15-EII):

Attached to the product

COM-JL [For FB100/FB400/FB900] Instruction Manual (IMR01Y10-EII):
 Separate volumes
 (Download or sold separately)

The above manuals can be downloaded from our website:

1. REFERENCE TO DATA MAP

(1) 	(2)	(3)	(4) ↓	(5)	(6) ↓
Name	Regi addi		Number	Attri-	Data range	Factory set
	HEX	DEC	of data	bute		value
Measured value (PV)	0000	0	31	RO	Input scale low to Input scale high	_
Current transformer 1 (CT1) input value monitor	0020	32	31	RO	CTL-6-P-N: 0.0 to 30.0A	_
Current transformer 2 (CT2) input value monitor	0040	64	31	RO	CTL-12-S56-10L-N: 0.0 to 100.0 A	_

(1) Name: Name of communication data

(2) Register address: The head address of each item (Vacant numbers become unused)

HEX: Hexadecimal DEC: Decimal

(3) Number of data: Number of data points

The address in the register address column will be the head address,

and the number of data items is indicated in this column.


(4) Attribute: RO: Read only data

 $(\text{Host computer [Client]} \quad \blacktriangleleft \quad \quad \text{Controller [Server])}$

R/W: Read and Write data

(Host computer [Client] ←→ Controller [Server])

(5) Data range: Read or write range of communication data



(6) Factory set value: Factory set value of communication data

Reading data of unused setting items are factory set values. Unused setting items may not be written. To do so will not cause an error however and data will be rejected.

2. DATA MAP

The data map shows data which can be used for communication between the host computer [Client] and controller (FB100/400/900) [Server].

2.1 FB100/400/900 Communication Data

Name	Register address		Number	Attri-	Data rongo	Factory set	
Name	HEX	DEC	of data	bute	Data range	value	
Measured value (PV)	0000	0	31	RO	Input scale low to Input scale high	_	
Current transformer 1	0020	32	31	RO	CTL-6-P-N:	_	
CT1) input value monitor Current transformer 2	0040	64	31	RO	0.0 to 30.0A CTL-12-S56-10L-N:		
CT2) input value monitor					0.0 to 100.0 A		
Set value (SV) monitor	0060	96	31	RO	Setting limiter low to Setting limiter high	_	
Remote setting (RS) nput value monitor	0800	128	31	RO	Setting limiter low to Setting limiter high	_	
Burnout state monitor	00A0	160	31	RO	0: OFF	_	
Burnout state monitor of	00C0	192	31	RO	1: ON 0: OFF		
eedback resistance input Event 1 state monitor	00E0	224	31	RO	1: ON 0: OFF		
Event 2 state monitor	0100	256	31	RO	1: ON		
event 3 state monitor	0120	288	31	RO			
						_	
vent 4 state monitor	0140	320	31	RO			
Heater break alarm 1 HBA1) state monitor	0160	352	31	RO	0: OFF 1: ON	_	
Heater break alarm 2 HBA2) state monitor	0180	384	31	RO		_	
Manipulated output	01A0	416	31	RO	PID control or Heat/Cool PID control:	_	
value (MV1) monitor heat-side]					-5.0 to +105.0 % Position proportioning control with		
					feedback resistance (FBR) input: 0.0 to 100.0 %		
Manipulated output	01C0	448	31	RO	-5.0 to +105.0 %	_	
alue (MV2) monitor cool-side]	L	L		L		<u>L</u>	
Error code	01E0	480	31	RO	Bit data Bit 0: Adjustment data error	_	
					Bit 1: Back-up error		
					Bit 2: A/D conversion error Bit 3 to Bit 4: Unused		
					Bit 5: Custom data error		
					Bit 6: Unused		
					Bit 7: Watchdog timer error Bit 8: Stack overflow		
					Bit 9 to Bit 10: Unused		
					Bit 11: Program error (busy)		
					Bit 12 to Bit 15: Unused		
					Data 0: OFF 1: ON [Decimal number: 0 to 4095]		
Digital input (DI) state	0200	512	31	RO	Bit data	_	
nonitor					Bit 0: DI1 Bit 4: DI5 Bit 1: DI2 Bit 5: DI6 1		
					Bit 2: DI3 Bit 6: DI7 1		
					Bit 3: DI4 Bit 7 to Bit 15: Unused		
					Data 0: Open 1: Closed [Decimal number: 0 to 127]		
Output state monitor	0220	544	31	RO	Bit data	_	
					Bit 0: OUT1 Bit 4: DO3 ¹ Bit 1: OUT2 Bit 5: DO4 ¹		
					Bit 2: DO1 Bit 6 to Bit 15: Unused		
					Bit 3: DO2 Data 0: OFF 1: ON		
		<u></u>		L	[Decimal number: 0 to 63]		
Operation mode state	0240	576	31	RO	Bit data	_	
nonitor					Bit 0: STOP Bit 1: RUN		
					Bit 2: Manual mode 2		
					Bit 3: Remote mode ²		
					Bit 4 to Bit 15: Unused Data 0: OFF 1: ON		
4	0000	000	0.1	D0	[Decimal number: 0 to 15]		
Memory area soak time nonitor	0260	608	31	RO	0 to 11999 seconds or 0 to 5999 minutes		
ntegrated operating me monitor	0280	640	31	RO	0 to 19999 hours	_	
Holding peak value	02A0	672	31	RO	−10.0 to +100.0 °C	_	
ambient temperature nonitor							
Power feed forward	02C0	704	31	RO	0.0 to 160.0 %	_	
nput value monitor 1					Display in the percentage of the load voltage (rated value).		
Backup memory state	02E0	736	31	RO	0: The content of the backup memory	_	
nonitor					does not coincide with that of the RAM.		
					1: The content of the backup memory		
Unused	0300	768	31	_	coincides with that of the RAM.		
	:	:	:				
	03FF	1023	31				

¹ Unused on the FB100

During operation in Manual mode, the Manual mode of the Operation mode state monitor is set to the "1: ON" state and the Remote mode of the same monitor is se to the "0: OFF" state even if the parameter, Remote/Local transfer is set to "1: Remote mode."

Name	Regi addi HEX		Number of data	Attri- bute	Data range	Factory set value
PID/AT transfer	0400	1024	31	R/W	0: PID control 1: Autotunig (AT) *	0
					* Automatically reverts to 0 after Autotuning ends.	
Auto/Manual transfer	0420	1056	31	R/W	0: Auto mode 1: Manual mode	0
Remote/Local transfer	0440	1088	31	R/W	0: Local mode 1: Remote mode	0
RUN/STOP transfer	0460	1120	31	R/W	0: RUN (control start)	0
Memory area transfer	0480	1152	31	R/W	1: STOP (control stop) 1 to 8	1
Interlock release	04A0	1184	31	R/W	0: Interlock release (Execution/State)	0
III.LEHOCK TELEASE	04A0	1104	31	IVVV	1: Interlock state	U
					"1" is for monitoring the interlocked state. Under this condition, do not write "1."	
Event 1 set value	04C0	1216	31	R/W	Deviation: —Input span to +Input span	50
Event 2 set value	04E0	1248	31	R/W	Process and set value: Input scale low to Input scale high	50
Event 3 set value	0500	1280	31	R/W R/W	Manipulated output value (MV1 or MV2): -5.0 to +105.0 %	50
Event 4 set value	0520	1312	31	R/W		50
Control loop break alarm (LBA) time	0540				0 to 7200 seconds (0: Unused)	480
LBA deadband	0560	1376	31	R/W	0 to Input span	0
Set value (SV)	0580	1408	31	R/W	Setting limiter low to Setting limiter high	TC/RTD inputs: 0 V/I inputs:
Proportional band	05A0	1440	31	R/W	TC/RTD inputs:	0.0 TC/RTD
[heat-side]	UJAU	1-1-10	31	1777	0 (0.0, 0.00) to Input span	inputs: 30
					(Unit: °C [°F]) 1 Voltage (V)/Current (I) inputs:	V/I inputs: 30.0
					0.0 to 1000.0 % of Input span (0, 0.0, 0.00: ON/OFF action)	
Integral time [heat-side]	05C0	1472	31	R/W	PID control or Heat/Cool PID control: 0 to 3600 seconds or	240
[rieat-side]					0.0 to 1999.9 seconds ²	
					(0, 0.0: PD action) ³ Position proportioning control:	
					1 to 3600 seconds or 0.1 to 1999.9 seconds ²	
Derivative time	05E0	1504	31	R/W	0 to 3600 seconds or 0.0 to 1999.9 seconds ²	60
[heat-side]					(0, 0.0: PI action)	
Control response parameter	0600	1536	31	R/W	Slow Medium Fast When the P or PD action is selected, this setting becomes invalid.]	PID control, Position proportioning control: 0 Heat/Cool
						PID control: 2
Proportional band [cool-side]	0620	1568	31	R/W	TC/RTD inputs: 1 (0.1, 0.01) to Input span	TC/RTD inputs: 30
[000.0.00]					(Unit: °C [°F]) 1 Voltage (V)/Current (I) inputs:	V/I inputs: 30.0
					0.1 to 1000.0 % of Input span	
Integral time [cool-side]	0640	1600	31	R/W	0 to 3600 seconds or 0.0 to 1999.9 seconds ²	240
	0660	1632	31	RW	(0, 0.0: PD action) ³ 0 to 3600 seconds or	60
Derivative time [cool-side]	0000	1032	31	FC/VV	0.0 to 1999.9 seconds ²	60
Overlap/Deadband	0680	1664	31	R/W	(0, 0.0: PI action) TC/RTD inputs:	0
					-Input span to +Input span (Unit:"C [*F]) Voltage (V)/Current (I) inputs: -100.0 to +100.0 % of Input span Minus (-) setting results in Overlap. However, the overlapping range is within the proportional range.	
Manual reset	06A0	1696	31	R/W	-100.0 to +100.0 %	0.0
Setting change rate limiter (up)	06C0	1728	31	R/W	0 to Input span/unit time * (0: Unused)	0
Setting change rate limiter (down)	06E0	1760	31	R/W	* Unit time: 60 seconds (factory set value)	0
Area soak time	0700	1792	31	R/W	0 to 11999 seconds or 0 to 5999 minutes	0:00
Link area number	0720	1824	31	R/W	0 to 8 (0: No link)	0
Heater break alarm 1 (HBA1) set value	0740	1856	31	R/W	CTL-6-P-N: 0.0 to 30.0 A (0.0: Unused) CTL-12-S56-10L-N:	0.0
Heater break determination point 1	0760	1888	31	RW	0.0 to 100.0 A (0.0: Unused) 0.0 to 100.0 % of HBA1 set value (0.0: Heater break determination is	30.0
Heater melting determination point 1	0780	1920	31	R/W	invalid) 0.0 to 100.0 % of HBA1 set value (0.0: Heater melting determination is	30.0
Heater break alarm 2 (HBA2) set value	07A0	1952	31	R/W	invalid) CTL-6-P-N: 0.0 to 30.0 A (0.0: Unused) CTL-12-S56-10L-N:	0.0
					0.0 to 100.0 A (0.0: Unused)	

¹ Varies with the setting of the Decimal point position selection.

³ When the heat-side and cool-side integral time is set to zero for Heat/Cool PID control, PD control will take place for both heat-side and cool-side.

addr FEX 7CO 3600 3600 3600 3600 3600 3600 3600 360	DEC 1984 2016 2048 2080 2112 2144 2176 2208	31 31 31 31 31 31	R/W R/W R/W R/W	Data range 0.0 to 100.0 % of HBA2 set value (0.0: Heater break determination is invalid) 0.0 to 100.0 % of HBA2 set value (0.0: Heater melting determination is invalid) -Input span to + Input span	30.0 30.0
320 340 360 38A0 36C0	2016 2048 2080 2112 2144 2176	31 31 31 31 31	R/W R/W R/W	(0.0: Heater break determination is invalid) 0.0 to 100.0 % of HBA2 set value (0.0: Heater melting determination is invalid) —Input span to + Input span	30.0
320 340 360 380 380	2048 2080 2112 2144 2176	31 31 31 31	R/W R/W	(0.0: Heater melting determination is invalid) —Input span to + Input span	
320 340 360 380 3A0	2080 2112 2144 2176	31 31 31	R/W R/W		0
340 360 380 3A0	2112 2144 2176	31	R/W	0.04-400.0	-
B60 B80 BA0	2144	31		0.0 to 100.0 seconds (0.0: Unused)	0.0
B80 BA0 BC0	2176			0.500 to 1.500	1.000
BA0 BC0		31	R/W	0.00 to 25.00 % of input span	0.00
3C0	2208	1	R/W	-Input span to + Input span	0
		31	R/W	0.0 to 100.0 seconds (0.0: Unused)	0.0
3E0	2240	31	R/W	0.001 to 9.999	1.000
	2272	31	R/W	0.1 to 100.0 seconds M: Relay contact output	M output: 20.0
900	2304	31	R/W	V: Voltage pulse output T: Triac output D: Open collector output	V, T, D output: 2.0
920	2336	31	R/W	PID control: Output limiter low [MV1] to Output limiter high [MV1] Heat/cool PID control: -Output limiter high [MV2] to +Output limiter high [MV1] (-105.0 to +105.0 %) Position proportioning control with feedback resistance (FBR) input: Output limiter low [MV1] to	0.0
940	2368	31	RW	Output limiter high [MV1] Bit data Bit 0: Lock only setting items other than SV and event set value (EV1 to EV4) Bit 1: Lock only event set value (EV1 to EV4) Bit 2: Lock only set value (SV) Bit 3 to Bit 15: Unused Data 0: Unlock 1: Lock [Decimal number: 0 to 7]	0
960	2400	31	R/W	O: SToP is displayed on the PV display T: SToP is displayed on the SV display O: SToP is displayed on the SV display	1
980	2432	31	R/W	0: No display 4: Deviation value 1: MV 5: CT1 input value 2: PV 6: CT2 input value	1
9A0	2464	31	R/W	3: SV monitor 1 to 100 digit/dot The resolution can be changed when the bar graph display was set to deviation	100
9C0	2496	31	RW	[FB100] 0: Unused 1: Used [FB400/900] 0: Unused	1
9E0	2528	31	R/W	0: Unused 1: MONI key (For type 1) or	1
A00	2560	31	R/W	0: Unused 1: AREA key (For type 1) or RUN/STOP transfer key (For type 2)	1
A20	2592	31	R/W	[FB100] 1: Auto/Manual transfer 2: Monitor 3: Memory area transfer 4: Remote/Local transfer 5: RUN/STOP transfer [FB400/900] 1: Type 1 2: Type 2	1
[For I	FB100/FI	3400/FB90	00] Inst	ruction Manual (IMR01Y10-E□).	
960	6496	31	R/W	O: Startup tuning (ST) unused 1: Execute once * 2: Execute always * Automatically reverts to 0 after Startup tuning (ST) ends.	0
[For I	FB100/FI	3400/FB90	00] Inst	ruction Manual (IMR01Y10-E□).	
A20	6688	31	RW	O: Unused 1: Learning * * Automatically reverts to 0 after automatic temperature rise learning ends.	1
	[For	2528 260 2528 260 2560 2592 2692 2692 2696 2696 2696 2696 2696	2528 31 31 31 31 320 2592 31 31 31 31 31 31 31 3	2528 31 RW 2560 31 RW 2560 31 RW 2592 31 RW 2592 31 RW 260 6496 31 RW 270 FB100/FB400/FB900] Inst	

^a The attribute becomes RO (Only reading data is possible) during RUN (control).

Varies with the setting of the Integral/Derivative time decimal point position selection.

The attribute becomes RO
 Unused on the FB100.

2.2 Memory Area Data

The register addresses, 2000H to 22BFH are used for checking and changing each set value belonging to the memory area.

	Regi	ictor	1			Г
Name	addr	ress	Number of data	Attri- bute	Data range	Factory set value
Setting memory area	HEX 2000	DEC 8192	31	R/W	1 to 8	1
number Event 1 set value	2020	8224	31	R/W	Deviation:	50
Event 2 set value	2040	8256	31	R/W	 Input span to +Input span Process and set value: 	50
Event 3 set value	2060	8288	31	R/W	Input scale low to Input scale high Manipulated output value (MV1 or MV2):	50
Event 4 set value	2080	8320	31	R/W	-5.0 to +105.0 %	50
Control loop break alarm	20A0	8352	31	R/W	0 to 7200 seconds (0: Unused)	480
(LBA) time LBA deadband	20C0	8384	31	R/W	0 to Input span	0
Set value (SV)	20E0	8416	31	R/W	Setting limiter low to Setting limiter high	TC/RTD inputs: 0 V/I inputs: 0.0
Proportional band [heat-side]	2100	8448	31	R/W	TC/RTD inputs: 0 (0.0, 0.00) to Input span (Unit: 'C [*F]) * Voltage (V/Current (1) inputs: 0.0 to 100.0 % of Input span (0, 0.0, 0.00: ON/OFF action)	TC/RTD inputs: 30 V/I inputs: 30.0
Integral time [heat-side]	2120	8480	31	R/W	PID control or Heat/Cool PID control: 0 to 3600 seconds or 0.0 to 1999.9 seconds ² (0, 0.0: PD action) ³ Position proportioning control: 1 to 3600 seconds or 0.1 to 1999.9 seconds ²	240
Derivative time [heat-side]	2140	8512	31	R/W	0 to 3600 seconds or 0.0 to 1999.9 seconds ² (0, 0.0: PI action)	60
Control response parameter	2160	8544	31	R/W	Slow Medium Fast [When the P or PD action is selected, this setting becomes invalid.]	PID control, Position proportioning control: 0 Heat/Cool PID control:
Proportional band [cool-side]	2180	8576	31	RW	TC/RTD inputs: 1 to Input span, 0.1 to Input span or 0.01 to Input span (Unit: °C [°F]) Voltage (V)/Current (1) inputs: 0.1 to 1000.0 % of Input span	TC/RTD inputs: 30 V/I inputs: 30.0
Integral time [cool-side]	21A0	8608	31	R/W	0 to 3600 seconds or 0.0 to 1999.9 seconds ² (0, 0.0: PD action) ³	240
Derivative time [cool-side]	21C0	8640	31	R/W	0 to 3600 seconds or 0.0 to 1999.9 seconds ² (0, 0.0: PI action)	60
Overlap/Deadband	21E0	8672	31	R/W	TC/RTD inputs: -Input span to +Input span (Unit:"C [°F]) Voltage (V)/Current (1) inputs: -100.0 to +100.0 % of Input span Minus (-) setting results in Overlap. However, the overlapping range is within the proportional range.	0
Manual reset	2200	8704	31	R/W	-100.0 to +100.0 %	0.0
Setting change rate limiter (up)	2220	8736	31	R/W	0 to Input span/unit time * (0: Unused)	0
Setting change rate limiter (down)	2240	8768	31	R/W	* Unit time: 60 seconds (factory set value)	0
Area soak time	2260	8800	31	R/W	0 to 11999 seconds or 0 to 5999 minutes	0:00
Link area number	2280	8832	31	R/W	0 to 8 (0: No link)	0
Unused	22A0	8864	32		_	_

¹ Varies with the setting of the Decimal point position selection.

2.3 COM-JL Communication Data

The register addresses, FA00H (64000) or more are used for checking and changing each set value of the COM-JL.

: The value of this item should always be set to 0 (FB100/400/900).

- ♦: These items become valid by turning off the power of the COM-JL once, and then turning it on again after the settings are changed.
- *: This setting (factory set value: 32) causes each address to be shifted by 32 for each communication item in the FB100/400/900 Communication Data and Memory Area Data. Therefore, exercise sufficient care if you change the setting as the data mappings will also change.

Name	Register address		Number		Data range	Factory set
	HEX DEC of data bute	Juliu Turigo	value			
Unused	FA00	64000	1	_	_	_
	FA07	64007	1			
COM-JL error code	FA08	64007	1	RO	Bit data	_
					Bit 0: Memory backup error	
					Bit 1: RAM error Bit 2: Controller configuration error	
					Bit 3: Unused	
					Bit 4: Ethernet hardware error	
					Bit 5 to Bit 15: Unused Data 0: OFF	
					1: ON	
					[Decimal number: 0 to 23]	
Unused Number of connected	FA09 FA0A	64009 64010	1	RO	0 to 31	_
controller in controller	FAUA	64010	' '	KU	0.031	
communication						
Number of connected	FA0B	64011	1	RO	0 to 128	-
channel in controller communication						
Action mode selection •	FA0C	64012	1	R/W	Bit data	Bit 0: 0
					Bit 0: Address setting	Bit 1 to 15: 0
					0: Continuous setting 1: Free setting	[Decimal number: 0]
					Bit 1 to Bit 15: Unused	
					[Decimal number: 0 to 1]	
Number of connectable controller channels • •	FA0D	64013	1	R/W	1 to 128	32
Transmmision wait time	FA0E	64014	1	R/W	0 to 100 ms	0
of controller						
communication	FA0F	64015	1	RO	Or The content of the beatrup memory	
Backup memory state monitor	FAUF	64015	' '	KU	The content of the backup memory does not coincide with that of the	
					RAM.	
					The content of the backup memory coincides with that of the RAM	
Unused	FA10	64016	1		—	_
	:	:	:			
	FA27	64039	1			
No. 1 Controller type	FA28	64040	1	R/W	0 to 65534 0: FB100/400/900	0
	I		I	:		
No. 31	FA46	64070	1	RW	0 to 65534	0
Controller type					0: FB100/400/900	
Unused	FA47	64071	1		Dit data	
No. 1 Controller state	FA48	64072	1	RO	Bit data Bit 0: Presence or absence of controller	_
					Bit 1: Presence or absence of abnormal	
					response	
					Bit 2 to Bit 15: Unused Data 0: Absence	
					1: Presence	
					[Decimal number: 0 to 3]	
				:	let t	
No. 31 Controller state	FA66	64102	1	RO	Bit data Bit 0: Presence or absence of controller	_
CONTROLL SIGILE					Bit 1: Presence or absence of abnormal	
					response	
					Bit 2 to Bit 15: Unused Data 0: Absence	
					1: Presence	
					[Decimal number: 0 to 3]	
Unused	FA67	64103	1	_	_	-
No. 1 Controller address	FA68	64104	1	R/W	1 to 99 0: There is no connection controller	1
				<u> </u>		•
No. 31	FA86	64134	1	R/W	1 to 99	31
Controller address	FA87	64425	1	R/W	There is no connection controller Do not execute the automatic	0
Automatic acquisition of controller address	rA8/	64135	'	F/VV	U: Do not execute the automatic acquisition	U
					Execute the automatic acquisition *	
					* Automatically reverts to 0 after	
					automatic acquisition ends.	

Ethernet is a registered trademark of Xerox Corp.
Modbus is a registered trademark of Schneider Electric
Company names and product names used in this manual are the trademarks or registered trademarks of the respective companies.

 RKC INSTRUMENT INC. The first edition: The third editi

Varies with the setting of the Integral/Derivative time decimal point position selection.
 When the heat-side or cool-side integral time is set to zero for Heat/Cool PID control, PD control will take place for both heat-side and cool-side.