

Module Type Controller SRZ
Current transformer
input module

Z-CT

INSTRUCTION
MANUAL

All Rights Reserved, Copyright © 2007, RKC INSTRUMENT INC.

IMS01T16-E5

Thank you for purchasing this RKC product. In order to achieve maximum performance and ensure proper operation of your new instrument, carefully read all the instructions in this manual. Please place this manual in a convenient location for easy reference.
This manual describes the mounting, wiring and specifications only. For detailed handling procedures and various function settings, please refer to separate Z-CT Instruction Manual [Detailed version] (IMS01T21-ED).

The above manuals can be downloaded from our website:
URL: http://www.rkcinst.com/english/manual_load.htm

■ Product Check

Z-CT Instruction Manual (this manual)1
Joint connector cover (KSRZ-517A).....2
Power terminal cover (KSRZ-518A).....1

WARNING

- An external protection device must be installed if failure of this instrument could result in damage to the instrument, equipment or injury to personnel.
- All wiring must be completed before power is turned on to prevent electric shock, fire or damage to instrument and equipment.
- This instrument must be used in accordance with the specifications to prevent fire or damage to instrument and equipment.
- This instrument is not intended for use in locations subject to flammable or explosive gases.
- Do not touch high-voltage connections such as power supply terminals, etc. to avoid electric shock.
- RKC is not responsible if this instrument is repaired, modified or disassembled by other than factory-approved personnel. Malfunction can occur and warranty is void under these conditions.

CAUTION

- This product is intended for use with industrial machines, test and measuring equipment. It is not designed for use with medical equipment and nuclear energy.
- This is a Class A instrument. In a domestic environment, this instrument may cause radio interference, in which case the user may be required to take adequate measures.
- This instrument is protected from electric shock by reinforced insulation. Provide reinforced insulation between the wire for the input signal and the wires for instrument power supply, source of power and loads.
- Be sure to provide an appropriate surge control circuit respectively for the following:
 - If input/output or signal lines within the building are longer than 30 meters.
 - If input/output or signal lines leave the building, regardless the length.
- This instrument is designed for installation in an enclosed instrumentation panel. All high-voltage connections such as power supply terminals must be enclosed in the instrumentation panel to avoid electric shock by operating personnel.
- All precautions described in this manual should be taken to avoid damage to the instrument or equipment.
- All wiring must be in accordance with local codes and regulations.
- To prevent instrument damage or failure, protect the power line and the input/output lines from high currents with a protection device such as fuse, circuit breaker, etc.
- Prevent metal fragments or lead wire scraps from falling inside instrument case to avoid electric shock, fire or malfunction.
- Tighten each terminal screw to the specified torque found in the manual to avoid electric shock, fire or malfunction.
- For proper operation of this instrument, provide adequate ventilation for heat dispensation.
- Do not connect wires to unused terminals as this will interfere with proper operation of the instrument.
- Turn off the power supply before cleaning the instrument.
- Do not use a volatile solvent such as paint thinner to clean the instrument. Deformation or discoloration will occur. Use a soft, dry cloth to remove stains from the instrument.
- To avoid damage to instrument display, do not rub with an abrasive material or push front panel with a hard object.

NOTICE

- This manual assumes that the reader has a fundamental knowledge of the principles of electricity, process control, computer technology and communications.
- The figures, diagrams and numeric values used in this manual are only for purpose of illustration.
- RKC is not responsible for any damage or injury that is caused as a result of using this instrument, instrument failure or indirect damage.
- RKC is not responsible for any damage and/or injury resulting from the use of instruments made by imitating this instrument.
- Periodic maintenance is required for safe and proper operation of this instrument. Some components have a limited service life, or characteristics that change over time.
- Every effort has been made to ensure accuracy of all information contained herein. RKC makes no warranty expressed or implied, with respect to the accuracy of the information. The information in this manual is subject to change without prior notice.
- No portion of this document may be reprinted, modified, copied, transmitted, digitized, stored, processed or retrieved through any mechanical, electronic, optical or other means without prior written approval from RKC.

1. PARTS DESCRIPTION

■ Module Mainframe

Terminal type

Loader communication connector

Automatic setting state indication lamp

Indication lamps

Address setting switch

Push button

Current transformer (CT) input terminals

Connector type

Loader communication connector

Automatic setting state indication lamp

Indication lamps

Address setting switch

Push button

Current transformer (CT) input connector

[Indication lamps]

● FAIL/RUN

When normal (RUN):
Self-diagnostic error (FAIL):
Instrument abnormality (FAIL):

A green lamp is on
A green lamp flashes
A red lamp is on

● RX/TX

During data send and receive:

A green lamp turns on

● SET

During automatic setting execution:
Automatic setting failure:

A green lamp is on
A green lamp flashes

[Push button]

Use when the heater break alarm set value or heater over current alarm set value should be automatically set.

■ Base

Mounting holes (M3 screw)
Holes for screws to fix the base to a panel, etc.
Customer must provide the M3 screws.

Joint connector
Used to mechanically and electrically connect each module.

Power supply terminals
Supply power to only one of the joined modules, and all of the joined modules will receive power.
(See 4.1 Wiring Cautions.)

Communication terminals (RS-485)
Connect communication wires to only one of the joined modules, and all of the joined modules will communicate.

Mounting bracket
Used to fix the module on DIN rails and also to fix each module joined together.

2. COMMUNICATION SETTING

CAUTION

Do not separate the module mainframe from the base with the power turned on. If so, instrument failure may result.

2.1 Module Address Setting

Set an address for the module using a small blade screwdriver.

Address setting switch

Setting range: 0 to F [0 to 15: Decimal]

Factory set value: 0

For RKC communication, the value obtained by adding “32” to the set address corresponds to the address used for the actual program.

For Modbus, the value obtained by adding “33” to the set address corresponds to the address used for the actual program.

To avoid problems or malfunction, do not duplicate an address on the same communication line.

2.2 Protocol Selections and Communication Speed Setting

Use the DIP switch on the right side of module to select communication speed, data bit, configuration and protocol.
The data changes become valid when the power is turned on again.

Right side view

DIP switch

(The above figure is for the terminal type. However, the switch positions are the same for the connector type.)

1	2	Communication speed
OFF	OFF	4800 bps
ON	OFF	9600 bps
OFF	ON	19200 bps
ON	ON	38400 bps

Factory set value: 19200 bps

3	4	5	Data bit configuration	Settable communication
OFF	OFF	OFF	Data 7-bit, without parity, Stop 1-bit	RKC communication
OFF	ON	OFF	Data 7-bit, Even parity, Stop 1-bit	
ON	ON	OFF	Data 7-bit, Odd parity, Stop 1-bit	
OFF	OFF	ON	Data 8-bit, without parity, Stop 1-bit	RKC communication Modbus
OFF	ON	ON	Data 8-bit, Even parity, Stop 1-bit	
ON	ON	ON	Data 8-bit, Odd parity, Stop 1-bit	

Factory set value: Data 8-bit, without parity

6	Protocol
OFF	RKC communication
ON	Modbus

Factory set value: RKC communication

- Switch No. 7 and 8 must be always OFF. Do not set to ON.
- When two or more modules are connected on the same communication line, the DIP switch settings of all modules must be the same. However, when a Z-CT module is joined to a Z-TIO-C/D or Z-TIO-E/F module used for “PLC communication,” set the communication speed and data bit configuration to the same settings as the Z-TIO-C/D or Z-TIO-E/F module and set the communication protocol to “RKC communication.”
- Connect a termination resistor between the communication terminals (No.3 and 4) of the module at the end of the communication line from the host computer.

WARNING

To prevent electric shock or instrument failure, always turn off the power before mounting or removing the instrument.

3.1 Mounting Cautions

(1) This instrument is intended to be used under the following environmental conditions. (IEC61010-1) [OVERVOLTAGE CATEGORY II, POLLUTION DEGREE 2]

(2) Use this instrument within the following environment conditions.

- Allowable ambient temperature: −10 to +50 °C
- Allowable ambient humidity: 5 to 95 %RH (Absolute humidity: MAX. W. C 29.3 g/m³ dry air at 101.3 kPa)

● Installation environment conditions: Indoor use
Altitude up to 2000 m

(3) Avoid the following conditions when selecting the mounting location:

- Rapid changes in ambient temperature which may cause condensation.
- Corrosive or inflammable gases.
- Direct vibration or shock to the mainframe.
- Water, oil, chemicals, vapor or steam splashes.
- Excessive dust, salt or iron particles.
- Excessive induction noise, static electricity, magnetic fields or noise.
- Direct air flow from an air conditioner.
- Exposure to direct sunlight.
- Excessive heat accumulation.

(4) Mount this instrument in the panel considering the following conditions:

- Ensure at least 50 mm space on top and bottom of the instrument for maintenance and environmental reasons.
- Do not mount this instrument directly above equipment that generates large amount of heat (heaters, transformers, semi-conductor functional devices, large-wattage resistors.)
- If the ambient temperature rises above 50 °C, cool this instrument with a forced air fan, cooler, or the like. Cooled air should not blow directly on this instrument.
- In order to improve safety and the immunity to withstand noise, mount this instrument as far away as possible from high voltage equipment, power lines, and rotating machinery.

High voltage equipment: Do not mount within the same panel.
Power lines: Separate at least 200 mm.
Rotating machinery: Separate as far as possible.
- If this instrument is permanently connected to equipment, it is important to include a switch or circuit-breaker into the installation. This should be in close proximity to the equipment and within the easy reach of the operator. It should be marked as the disconnecting device for the equipment.

3.2 Dimensions

[Terminal type]

[Connector type]

(Unit: mm)

85

100

101

76.9

100

101

2.9

30

6.7

- When the module is mounted on the panel, allow a minimum of 50 mm at the top and bottom of the module to attach the module to the mainframe.
- Space for connectors and cable must be considered when installing.
- For instruction of module joining, mounting and removal, refer to the Z-TIO Instruction Manual (IMS01T01-ED).

Up to 16 Z-CT modules can be connected. The maximum number of SRZ modules (including other function modules) on the same communication line is 31.

The Z-CT module cannot transmit data to or receive data from a PLC. If connected to a Z-TIO-C/D or Z-TIO-E/F module, use host communication or loader communication.

4. WIRING

WARNING

To prevent electric shock or instrument failure, do not turn on the power until all the wiring is completed. Make sure that the wiring has been properly made before applying power to the instrument.

4.1 Wiring Cautions

- To avoid noise induction, keep input/output signal wires away from instrument power line, load lines and power lines of other electric equipment.
- If there is electrical noise in the vicinity of the instrument that could affect operation, use a noise filter.
 - Shorten the distance between the twisted power supply wire pitches to achieve the most effective noise reduction.
 - Always install the noise filter on a grounded panel. Minimize the wiring distance between the noise filter output and the instrument power supply terminals to achieve the most effective noise reduction.
 - Do not connect fuses or switches to the noise filter output wiring as this will reduce the effectiveness of the noise filter.
- Power supply wiring must be twisted and have a low voltage drop.
- For an instrument with 24 V power supply, supply power from a SELV circuit.
- A suitable power supply should be considered in the end-use equipment. The power supply must be in compliance with a limited-energy circuits (maximum available current of 8 A).
- Supply the power to only one of the joined modules. When power is supplied to any one of the joined modules, all of the joined modules will receive power.
- Select the power capacity which is appropriate for the total power consumption of all joined modules and the initial current surge when the power is turned on.

Power consumption (at maximum load): 35 mA max. (at 24 V DC)
Rush current: 10 A or less

For the connector type module, use the following our connector (plug) [sold separately].
Connector type: SRZP-01 (Front-screw type), SRZP-02 (Side-screw type)
Screw size: M2.5
Recommended tightening torque: 0.43 to 0.5 N·m (4.3 to 5.0 kgf·cm)
Used cable specifications:

Lead wire type:
Solid (AWG 28 [cross-section: 0.081 mm²] to 12 [cross-section: 3.309 mm²]) or
Twisted wire (AWG 30 [cross-section: 0.051 mm²] to 12 [cross-section: 3.309 mm²])
Stripping length: 9 to 10 mm (SRZP-01), 7 to 8 mm (SRZP-02)

For the power supply terminals and communication terminals, use the specified solderless terminals. Only these specified solderless terminals can be used due to the insulation between the terminals.

Screw Size: M3 × 7 (with 5.8 × 5.8 square washer)
Recommended tightening torque: 0.4 N·m (4 kgf·cm)
Applicable wire: Solid/twisted wire of 0.25 to 1.65 mm²
Specified solderless terminals:

Manufactured by J.S.T MFG CO., LTD.
Circular terminal with isolation V1.25–MS3 (M3 screw, width 5.5 mm, hole diameter 3.2 mm)

Make sure that the any wiring such as solderless terminal is not in contact with the adjoining terminals.

When tightening a screw of the instrument, make sure to fit the screwdriver properly into the screw head mounted tilted or flat as shown in the right figure. Tightening the screw with excessive torque may damage the screw thread.

Tilted terminal

Flat terminal

4.2 Terminal Configuration

■ Terminal type

Current transformer (CT) input [CT7 to CT12]

Current transformer (CT) input [CT1 to CT6]

CT9

COM

CT8

COM

CT7

CT12

COM

CT11

COM

CT10

CT1

COM

CT2

COM

CT3

CT4

COM

CT5

COM

CT6

COM: Common

(Continued on the next page →)

