EtherNet/IP Communication Converter

COM-ML [For SRZ]

Instruction Manual

NOTICE

- This manual assumes that the reader has a fundamental knowledge of the principles of electricity, process control, computer technology and communications.
- The figures, diagrams and numeric values used in this manual are only for explanation purpose.
- RKC is not responsible for any damage or injury that is caused as a result of using this instrument, instrument failure or indirect damage.
- RKC is not responsible for any damage and/or injury resulting from the use of instruments made by imitating this instrument.
- Periodic maintenance is required for safe and proper operation of this instrument. Some components have a limited service life, or characteristics that change over time.
- Every effort has been made to ensure accuracy of all information contained herein. RKC makes no warranty, expressed or implied, with respect to the accuracy of the information. The information in this manual is subject to change without prior notice.
- No portion of this document may be reprinted, modified, copied, transmitted, digitized, stored, processed or retrieved through any mechanical, electronic, optical or other means without prior written approval from RKC.

- EtherNet/IP is a trademark of ControlNet International Ltd. used under license by Open DeviceNet Vendor Association, Inc. (ODVA).
- ControlLogix and RSLogix are trademarks of Rockwell Automation. RSLinx is a registered trademark
 of Rockwell Automation.
- Modbus is a registered trademark of Schneider Electric.
- The name of each programmable controller (PLC) means the products of each manufacturer.
- Company names and product names used in this manual are the trademarks or registered trademarks of the respective companies.

Safety Precautions

■ Pictorial Symbols (safety symbols)

Various pictorial symbols are used in this manual to ensure safe use of the product, to protect you and other people from harm, and to prevent damage to property. The symbols are described below.

Be sure you thoroughly understand the meaning of the symbols before reading this manual.



WARNING: This mark indicates precautions that must be taken if there is depose of electric sheets fire taken if there is danger of electric shock, fire, etc., which could result in loss of life or injury.



: This mark indicates that if these precautions and operating procedures are not taken, damage to the instrument may result.



: This mark indicates that all precautions should be taken for safe usage.



- To prevent injury to persons, damage to the instrument and the equipment, a suitable external protection device shall be required.
- All wiring must be completed before power is turned on to prevent electric shock, fire or damage to the instrument and the equipment.
- This instrument must be used in accordance with the specifications to prevent fire or damage to the instrument and the equipment.
- This instrument is not intended for use in locations subject to flammable or explosive gases.
- Do not touch high-voltage connections such as power supply terminals, etc. to avoid electric shock.
- RKC is not responsible if this instrument is repaired, modified or disassembled by other than factory-approved personnel. Malfunction may occur and warranty is void under these conditions.

i-1 IMR02E08-E3



- This product is intended for use with industrial machines, test and measuring equipment. (It is not designed for use with medical equipment and nuclear energy plant.)
- This is a Class A instrument. In a domestic environment, this instrument may cause radio interference, in which case the user may be required to take additional measures.
- This instrument is protected from electric shock by reinforced insulation. Provide reinforced insulation between the wire for the input signal and the wires for instrument power supply, source of power and loads.
- Be sure to provide an appropriate surge control circuit respectively for the following:
 - If input/output or signal lines within the building are longer than 30 meters.
 - If input/output or signal lines leave the building, regardless the length.
- This instrument is designed for installation in an enclosed instrumentation panel. All high-voltage connections such as power supply terminals must be enclosed in the instrumentation panel to avoid electric shock to operating personnel.
- All precautions described in this manual should be taken to avoid damage to the instrument or equipment.
- If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.
- All wiring must be in accordance with local codes and regulations.
- To prevent instrument damage as a result of failure, protect the power line and the input/output lines from high currents with a suitable overcurrent protection device with adequate breaking capacity such as a fuse, circuit breaker, etc.
- A malfunction in this product may occasionally make control operations impossible or prevent alarm outputs, resulting in a possible hazard. Take appropriate measures in the end use to prevent hazards in the event of malfunction.
- Prevent metal fragments or lead wire scraps from falling inside instrument case to avoid electric shock, fire or malfunction.
- Tighten each terminal screw to the specified torque found in the manual to avoid electric shock, fire or malfunction.
- For proper operation of this instrument, provide adequate ventilation for heat dissipation.
- Do not connect wires to unused terminals as this will interfere with proper operation of the instrument.
- Turn off the power supply before cleaning the instrument.
- Do not use a volatile solvent such as paint thinner to clean the instrument. Deformation or discoloration may occur. Use a soft, dry cloth to remove stains from the instrument.
- Do not connect modular connectors to telephone line.

For Proper Disposal

When disposing of each part used for this instrument, always follows the procedure for disposing of industrial wastes stipulated by the respective local community.

i-2 IMR02E08-E3

Symbols

■ Pictorial Symbols (safety symbols)

 \mathbf{NOTE} : This mark indicates important information on installation, handling and operating procedures.

: This mark indicates supplemental information on installation, handling and operating procedures.

: This mark indicates where additional information may be located.

■ Abbreviation symbols

These abbreviations are used in this manual:

Abbreviation symbols	Name	Abbreviation symbols	Name
PV	Measured value	TC (input)	Thermocouple (input)
SV	Set value	RTD (input)	Resistance temperature detector (input)
MV	Manipulated output value	V (input)	Voltage (input)
AT	Autotuning	I (input)	Current (input)
ST	Startup tuning	HBA	Heater break alarm
OUT	Output	CT	Current transformer
DI	Digital input	LBA	Control loop break alarm
DO	Digital output	LBD	LBA deadband

i-3 IMR02E08-E3

About This Manual

There are four manuals pertaining to this product. Please be sure to read all manuals specific to your application requirements.

The following manuals can be downloaded from the official RKC website: https://www.rkcinst.com/english/manual_load.htm.

Manual	Manual Number	Remarks
EtherNet/IP Communication Converter COM-ML [For SRZ] Installation Manual	IMR02E05-E□	This manual is enclosed with instrument. This manual explains the mounting and wiring.
EtherNet/IP Communication Converter COM-ML [For SRZ] Quick Operation Manual	IMR02E06-E□	This manual is enclosed with instrument. This manual explains the communication setting and the basic operation method.
EtherNet/IP Communication Converter COM-ML [For SRZ] Host Communication Data List	IMR02E07-E□	This manual is enclosed with instrument. This list is a compilation of the host communication data items.
EtherNet/IP Communication Converter COM-ML [For SRZ] Instruction Manual	IMR02E08-E3	This manual you are reading now. This manual describes mounting, wiring, communication setting, protocol, communication data, troubleshooting and product specification.

Read this manual carefully before operating the instrument. Please place the manual in a convenient location for easy reference.

i-4 IMR02E08-E3

Contents

NOTICE	Page
Safety Precautions	
■ Pictorial Symbols (safety symbols)	
WARNING	
CAUTION	
For Proper Disposal	
Symbols	
■ Pictorial Symbols (safety symbols)	
■ Abbreviation symbols About This Manual	
1. OUTLINE	1
1.1 Checking the Product	2
1.2 Model Code	3
1.3 Parts Description	4
A LIANDI INC DECCEPTIBLE	
2. HANDLING PROCEDURES	6
MOUNTING	
3. MOUNTING	7
3. MOUNTING	7
3. MOUNTING 3.1 Mounting Cautions 3.2 Dimensions	7 7
3. MOUNTING 3.1 Mounting Cautions 3.2 Dimensions 3.3 DIN Rail Mounting	
3. MOUNTING 3.1 Mounting Cautions 3.2 Dimensions	
3. MOUNTING 3.1 Mounting Cautions 3.2 Dimensions 3.3 DIN Rail Mounting	
3. MOUNTING 3.1 Mounting Cautions	
3. MOUNTING 3.1 Mounting Cautions 3.2 Dimensions 3.3 DIN Rail Mounting 3.4 Panel Mounting 4. WIRING 4.1 Wiring Cautions	
3. MOUNTING 3.1 Mounting Cautions 3.2 Dimensions 3.3 DIN Rail Mounting 3.4 Panel Mounting 4. WIRING 4.1 Wiring Cautions 4.2 Terminal Configuration	
3. MOUNTING 3.1 Mounting Cautions 3.2 Dimensions 3.3 DIN Rail Mounting 3.4 Panel Mounting 4. WIRING 4.1 Wiring Cautions 4.2 Terminal Configuration 4.3 Connection to EtherNet/IP	
3. MOUNTING 3.1 Mounting Cautions 3.2 Dimensions 3.3 DIN Rail Mounting 3.4 Panel Mounting 4. WIRING 4.1 Wiring Cautions 4.2 Terminal Configuration	
3. MOUNTING 3.1 Mounting Cautions 3.2 Dimensions 3.3 DIN Rail Mounting 3.4 Panel Mounting 4. WIRING 4.1 Wiring Cautions 4.2 Terminal Configuration 4.3 Connection to EtherNet/IP 4.4 Connection to Host Computer	

5. HOST COMMUNICATION SETTING	Page 21
5.1 Address Setting	21
5.2 DIP Switch Setting	
6. COMMUNICATION SETTING OF SRZ FUNCTION MODULE	·23
6.1 Address Setting of the Function Modules	
6.2 Temperature Control Channel of the SRZ Unit	
6.3 Digital Input/Output Channel of Z-DIO Module	
7. INITIAL COMMUNICATION DATA SETTING	26
7.1 IP Address Setting	26
7.2 EtherNet/IP Communication Settings	
7.3 Other Communication Data Settings	
8. EtherNet/IP	35
8.1 Outline of EtherNet/IP	35
8.2 Communication Method	37
9. COMMUNICATION DATA LIST	38
9.1 Reference to Communication Data List	38
9.2 Communication Data of COM-ML	
9.3 Communication Data of Z-TIO Module	43
9.4 Memory Area Data Address of Z-TIO Module	66
9.5 Communication Data of Z-DIO Module	68
10. USAGE EXAMPLE	73
10.1 Handling Procedures	73
10.2 System Configuration	
10.3 Use Instruments Settings	75
10.4 Initial Communication Data Settings	75
10.5 Tool Settings	76
10.6 I/O Communication	84
10.7 Explicit Message Communication	87

i-6 IMR02E08-E3

11. TRO	DUBLESHOOTING	Page 93
12. SPE	ECIFICATIONS	98
13. OB	JECT MODEL	102
13.1 CI	P Common Object	102
	oplication Object	
ADDEN	DIX. HOST COMMUNICATION PRO	TOCOL 108
	DIA. HOUT COMMONICATION I NO	1000L 100
A.1 Co	mmunication Requirements	108
A.1 Co A.2 RK	mmunication Requirements	108
A.1 Co A.2 RK A.2.1 A.2.2	mmunication Requirements	
A.1 Co A.2 RK A.2.1 A.2.2 A.2.3	mmunication Requirements	
A.1 Co A.2 RK A.2.1 A.2.2 A.2.3 A.3 Mo	mmunication Requirements	
A.1 Co A.2 RK A.2.1 A.2.2 A.2.3 A.3 Mo A.3.1	mmunication Requirements C Communication Protocol Polling procedures Selecting procedures Communication data structure odbus Protocol Message format	
A.1 Co A.2 RK A.2.1 A.2.2 A.2.3 A.3 Mo A.3.1 A.3.2	mmunication Requirements	
A.1 Co A.2 RK A.2.1 A.2.2 A.2.3 A.3 Mo A.3.1 A.3.2 A.3.3	mmunication Requirements C Communication Protocol Polling procedures Selecting procedures Communication data structure odbus Protocol Message format Function code Communication mode	
A.1 Co A.2 RK A.2.1 A.2.2 A.2.3 A.3 Mo A.3.1 A.3.2 A.3.3 A.3.4	mmunication Requirements CC Communication Protocol Polling procedures Selecting procedures Communication data structure odbus Protocol Message format Function code Communication mode Slave responses	
A.1 Co A.2 RK A.2.1 A.2.2 A.2.3 A.3 Mo A.3.1 A.3.2 A.3.3	mmunication Requirements C Communication Protocol Polling procedures Selecting procedures Communication data structure odbus Protocol Message format Function code Communication mode Slave responses Calculating CRC-16	
A.1 Co A.2 RK A.2.1 A.2.2 A.2.3 A.3 Mo A.3.1 A.3.2 A.3.3 A.3.4 A.3.5 A.3.6	mmunication Requirements C Communication Protocol Polling procedures Selecting procedures Communication data structure Odbus Protocol Message format Function code Communication mode Slave responses Calculating CRC-16	

<u>MEMO</u>

i-8 IMR02E08-E3


1. OUTLINE

EtherNet/IP communication converter COM-ML [For SRZ] (hereafter called COM-ML) is communication converter to connect the RKC module type controller SRZ to the EtherNet/IP.

This chapter describes features, package contents, model code, system configuration, etc.

- EtherNet/IP is an implementation of CIP (Common Industrial Protocol) on Ethernet and TCP/IP.
- COM-ML supports "I/O communication" and "Explicit message communication" for EtherNet/IP.
- Scanner/adapter (multicast: 1 to N) communication is used in I/O communication.

 Client/server (peer to peer: 1 to 1) communication is used in explicit message communication.
- In scanner/adapter communication, COM-ML corresponds to the adapter. In client/server communication, COM-ML corresponds to the server.
- Up to 30 function modules (Z-TIO and Z-DIO) can be connected to one COM-ML with SRZ unit. (However, the maximum joinable number of function modules of the same type is 16.)



For EtherNet/IP, see the website of ODVA (Open DeviceNet Vendor Association).


URL: https://www.odva.org/

1.1 Checking the Product

Before using this product, check each of the following:

- Model code
- Check that there are no scratch or breakage in external appearance (case, front panel, or terminal, etc.)
- Check that all of the items delivered are complete. (See below)

Name	Q'TY	Remarks
COM-ML [For SRZ] Installation Manual (IMR02E05-E□)	1	Enclosed with instrument
COM-ML [For SRZ] Quick Instruction Manual (IMR02E06-E□)	1	Enclosed with instrument
COM-ML [For SRZ] Communication Data List (IMR02E07-E□)	1	Enclosed with instrument
Joint connector cover KSRZ-517A	2	Enclosed with instrument
Power terminal cover KSRZ-518A	1	Enclosed with instrument
COM-ML [For SRZ] Instruction Manual (IMR02E08-E3)	1	This manual (sold separately) This manual can be downloaded from the official RKC website: https://www.rkcinst.com/english/manual_load.htm





The EDS file is used for recognition of the COM-ML on EtherNet/IP in the configuration tool (software for environment settings and creating programs); however, EtherNet/IP communication is possible without using the EDS file.

If you require the EDS file, download it from the official RKC website.

https://www.rkcinst.com/english/manual load.htm

■ Accessories (sold separately)

Name	Q'TY	Remarks
□ End plate DEP-01	2	Secures the SRZ on the DIN rail
☐ Communication converter COM-K2-1	1	For loader communication (Option: with loader communication cable)
☐ Connection cable (W-BF-01-☐, ☐: cable length)	1	For host communication Modular connector and Spade lug terminal
☐ Connection cable (W-BF-02-□, □: cable length)	1	For host communication Modular connectors (at both ends)
☐ Connection cable (W-BF-28-□, □: cable length)	1	For host communication Modular connector and D-sub 9-pin connector

1.2 Model Code


Check whether the delivered product is as specified by referring to the following model code list. If the product is not identical to the specifications, please contact RKC sales office or the agent.

- (1) Ethernet communication type
 - 2: EtherNet/IP
- (2) Host communication interface (COM. PORT)
 - 4: RS-422A 5: RS-485
- (3) Corresponding to the RKC controller

02: SRZ

1.3 Parts Description

■ COM-ML mainframe



Indication lamps

FAIL/ RUN	[Green or Red]	When normal:	A green lamp is on (RUN)
		• During setting of default IP address setting:	A green lamp flashes (RUN)
		Self-diagnostic error (Recoverable fault):	A green lamp flashes (FAIL)
		Self-diagnostic error (Major fault):	A red lamp is on (FAIL)
RX/TX	[Green]	During host communication data send and recei	ve: A green lamp turns on
NS (Network sta	tus)	No power or no IP address:	Turns off
	[Green or Red]	Online, no connection established:	A green lamp flashes
		Online, connections established:	A green lamp turns on
		• I/O connection is timeout:	A red lamp flashes
		A fatal communications error has occurred (Duplicate IP address):
			A red lamp turns on
LINK (Link/Activ	ity) [Green]	No link, no activity:	Turns off
		Activity (During data send):	A green lamp flashes
		Link established:	A green lamp turns on
MS (Module stat	tus)	No power:	Turns off
	[Green or Red]	Controlled by a Scanner in Run state:	A green lamp turns on
		Not configured, or Scanner in idle state:	A green lamp flashes
		Recoverable fault:	A red lamp flashes
		Major fault:	A red lamp turns on


• Communication port (modular connector) and communication connector

	,
COM. PORT	Use to connecting the Operation panel or Host computer. [RS-485 or RS-422A]
EtherNet/IP communication connector	Use to connecting the EtherNet/IP.
Loader communication connector	Use to connecting the communication converter and personal computer when loader communication is performed.

Switch

Host communication address setting switch	Sets unit address for host communication.
DIP switch	 Sets the communication speed and communication protocol corresponding to host communication. Sets dip switch setting validity/invalidity. Sets the default IP address settings.

■ Base



Mounting holes (M3 screw)	Holes for screws to fix the base to a panel, etc. Customer must provide the M3 screws.			
Joint connector	Used to mechanically and electrically connect each module.			
Power supply terminals	These are terminals to supply power to the COM-ML and joined function modules.			
	Terminal number Signal name			
		1	24 V DC (+)	
		2	24 V DC (-)]
Terminal 3, 4 and 5	These terminals cannot be used for the COM-ML. (Usage is prohibited.) NOTE When the COM-ML is connected to a function module, do not use terminals 3, 4 and 5 of the function module.			
Mounting bracket	Used to fix the module on DIN rails and also to fix each module joined together.			

2. HANDLING PROCEDURES

Conduct necessary setting before operation according to the procedure described below.

Host communication settings



The address, communication speed, communication protocol, data bit configuration, and DIP switch setting validity/invalidity of host communication are set only when host communication is used in the COM-ML.

See 5. HOST COMMUNICATION SETTINGS (P. 21).

Mounting



Wiring





Controller (SRZ) settings



IP address settings



EtherNet/IP communication settings



Other communication data settings



EtherNet/IP communication Install the COM-ML.



• For controller (SRZ), see **Z-TIO Instruction Manual** (IMS01T01-E□) and Z-DIO Instruction Manual (IMS01T03-E□).

Connect the COM-ML power wiring and the controller (SRZ) wiring, and connect the COM-ML to the scanner (or client). Connect the wiring for host communication or loader communication in the COM-ML.



- See 4. WIRING (P. 12)
 - For controller (SRZ), see **Z-TIO Instruction Manual** (IMS01T01-E□) and Z-DIO Instruction Manual $(IMS01T03-E\square).$

Set the communication setting of controller (SRZ).



- See 6. COMMUNICATIOM SETTING OF SRZ **FUNCTION MODULE (P. 23).**
 - For controller (SRZ), see **Z-TIO Instruction Manual** (IMS01T01-E□) and Z-DIO Instruction Manual (IMS01T03-E□).

Set the IP address of COM-ML.

See 7.1 IP Address Settings (P. 26).

Configure initial settings for EtherNet/IP communication.



- See 7.2 EtherNet/IP Communication Setting (P. 29).
 - See 10.5 Tool Settings (P. 76).

Set the data for the COM-ML and controller (SRZ).



- See 7.3 Other Communication Data Settings (P. 34).
 - See 9. COMMUNICATION DATA LIST (P. 38).

Execute I/O communication or explicit message communication.



- See 10.6 I/O Communication (P. 84).
 - See 10.7 Explicit Message Communication (P. 87).

3. MOUNTING

This chapter describes installation environment, mounting cautions, dimensions and mounting procedures.

MARNING

To prevent electric shock or instrument failure, always turn off the power before mounting or removing the instrument.

3.1 Mounting Cautions

- (1) This instrument is intended to be used under the following environmental conditions. (IEC 61010-1) [POLLUTION DEGREE 2]
- (2) Use this instrument within the following environment conditions.

Allowable ambient temperature: -10 to +50 °C
 Allowable ambient humidity: 5 to 95 %RH

(Absolute humidity: MAX.W.C 29.3 g/m³ dry air at 101.3 kPa)

• Installation environment conditions: Indoor use

Altitude up to 2000 m


- (3) Avoid the following conditions when selecting the mounting location:
 - Rapid changes in ambient temperature which may cause condensation.
 - Corrosive or inflammable gases.
 - Direct vibration or shock to the mainframe.
 - Water, oil, chemicals, vapor or steam splashes.
 - Excessive dust, salt or iron particles.
 - Excessive induction noise, static electricity, magnetic fields or noise.
 - Direct air flow from an air conditioner.
 - Exposure to direct sunlight.
 - Excessive heat accumulation.
- (4) Mount this instrument in the panel considering the following conditions:
 - Provide adequate ventilation space so that heat does not build up.
 - Do not mount this instrument directly above the equipment that generates large amount of heat (heaters, transformers, semi-conductor functional devices, large-wattage resistors.)
 - If the ambient temperature rises above 50 °C, cool this instrument with a forced air fan, cooler, or the like. Cooled air should not blow directly on this instrument.
 - In order to improve safety and the immunity to withstand noise, mount this instrument as far away as possible from high voltage equipment, power lines, and rotating machinery.

High voltage equipment: Do not mount within the same panel.

Power lines: Separate at least 200 mm Rotating machinery: Separate as far as possible


• For correct functioning mount this instrument in a horizontal position.

• Space required between each module vertically
When the module is mounted on the panel, allow a
minimum of 50 mm at the top and bottom of the
module to attach the module to the mainframe.




• Depth for modular cables mount type module


Space for modular cables must be considered when installing.



• It is recommended to use a plastic cover on the connector on both sides of the mounted modules for protection of connectors.





• Be sure the COM-ML and SRZ function modules (Z-TIO and Z-DIO modules) are joined when using them.



(5) In case this instrument is connected to a supply by means of a permanent connection, a switch or circuit-breaker shall be included in the installation. This shall be in close proximity to the equipment and within easy reach of the operator. It shall be marked as the disconnecting device for the equipment.

3.2 Dimensions






3.3 DIN Rail Mounting


■ Mounting procedures

- 1. Pull down the mounting bracket at the bottom of the module (A). Attach the hooks on the top of the module to the DIN rail and push the lower section into place on the DIN rail (B).
- 2. Slide the mounting bracket up to secure the module to the DIN rail (C).




■ Module joining procedures

1. Mount the function modules on the DIN rail. Slide the modules until the modules are closely joined together and the joint connectors are securely connected.




- 2. Push in the mounting brackets to lock the modules together and fix to the DIN rail.
- After module joining, install a plastic cover on the connector on both sides of the mounted modules for protection of connectors. (See P. 8)
- To firmly fix the modules, use end plates (DEP-01) sold separately on both sides of the mounted modules.



Push in all of the mounting brackets.

■ Removing procedures


- 1. Turn the power OFF.
- 2. Remove the wiring.
- 3. Pull down a mounting bracket with a blade screwdriver (A). Lift the module from bottom, and take it off (B).




3.4 Panel Mounting

■ Mounting procedures


1. Refer to the mounting dimensions below when selecting the location.



2. Remove the base from the module (B) while the lock is pressed (A).



- 3. Join bases. Then, lock them by pushing in the mounting brackets. (See P. 10)
- 4. Fix the base to its mounting position using M3 screws. Customer must provide the screws.
- 5. Mount the module on the base.



4. WIRING

This chapter describes wiring cautions, terminal configuration and connections.

4.1 Wiring Cautions

MARNING

To prevent electric shock or instrument failure, do not turn on the power until all the wiring is completed. Make sure that the wiring is correct before applying power to the instrument.

- To avoid noise induction, keep communication signal wire away from instrument power line, load lines and power lines of other electric equipment.
- If there is electrical noise in the vicinity of the instrument that could affect operation, use a noise filter.
 - Shorten the distance between the twisted power supply wire pitches to achieve the most effective noise reduction
 - Always install the noise filter on a grounded panel. Minimize the wiring distance between the noise filter output and the instrument power supply terminals to achieve the most effective noise reduction.
 - Do not connect fuses or switches to the noise filter output wiring as this will reduce the effectiveness of the noise filter.
- Power supply wiring must be twisted and have a low voltage drop.
- For an instrument with 24 V power supply input, supply power from a "SELV" circuit defined as IEC 60950-1.
- A suitable power supply should be considered in the end-use equipment. The power supply must be in compliance with a limited-energy circuits (maximum available current of 8 A).
- Supply the power to only one of the joined modules or COM-ML. When power is supplied to any one of the joined modules or COM-ML, all of the joined modules and COM-ML will receive power.
- Select the power capacity which is appropriate for the total power consumption of all joined modules (include COM-ML) and the initial current surge when the power is turned on.

Power consumption (at maximum load): 120 mA max. (at 24 V DC) Rush current: 12 A or less

• When connecting the wiring to the power supply terminals on the base, use the specified solderless terminals. Only these specified solderless terminals can be used due to the insulation between the terminals.

Screw Size: $M3 \times 7$ (with 5.8×5.8 square washer) Recommended tightening torque:

0.4 N·m (4 kgf·cm)


Applicable wire: Solid/twisted wire of 0.25 to 1.65 mm²


Specified solderless terminal:

Manufactured by J.S.T MFG CO., LTD. Circular terminal with isolation V1.25–MS3 (M3 screw, width 5.5 mm, hole diameter 3.2 mm)

• Make sure that during field wiring parts of conductors cannot come into contact with adjacent conductive parts.


When tightening a screw of the instrument, make sure to fit the screwdriver properly into the screw head mounted tilted or flat as shown in the right figure. Tightening the screw with excessive torque may damage the screw thread. (Only function modules)





4.2 Terminal Configuration

The terminal layout of COM-ML (base) is as follows.



NOTE

When using the COM-ML connected to function modules, terminals 3, 4 and 5 are not used. Do not connect anything to terminals 3, 4 and 5.


In addition, do not use terminals 3, 4 and 5 of function modules.

■ Wiring method


When using the COM-ML connected to function modules, the power supply wiring is connected to any one of the modules. Power is supplied from the module with the power wiring to the other modules.

[Wiring example]


When supplied a power supply to a COM-ML



When supplied a power supply to a function module



- 1. Remove the module mainframe to which the power wiring will be connected.
- 2. Attach the solderless terminals to the power terminals with a Phillips head screwdriver. When attaching the terminals, make sure that the polarity (+ and -) is correct.




3. Return the module mainframe to the base. This completes the wiring work.

4.3 Connection to EtherNet/IP

Connect COM-ML to EtherNet/IP.

■ Pin layout of connector



■ Connector pin number and signal details

Pin No.	Signal name	Symbol
1	Send data +	TX+
2	Send data –	TX-
3	Receive data +	RX+
4	Unused	
5	Unused	
6	Receive data –	RX-
7	Unused	
8	Unused	_

The cable must be provided by the customer.


Used cable: The cable is based on the 10BASE-T or the 100BASE-TX standard of Ethernet.

Used connector: RJ-45 type

■ Wiring example


• When directly connected to scanner or client

Use a cross cable when directly connected to the scanner or client (such as PLC or computer, etc.).



When use network hub

Use straight cables when connected to the network hub.




Cross cables may be used depending on the connecting device used. Therefore, follow the instructions for the respective device.

4.4 Connection to Host Computer

This section explains the connections for using the host computer and the operation panel to set COM-ML data and controller (SRZ) data.

4.4.1 When connected with RS-422A

■ Pin layout of connector




■ Connector pin number and signal details

Pin No.	Signal name	Symbol	
1	Receive data	R (A)	
2	Receive data	R (B)	
3	Signal ground	SG	
4	Send data	T (B)	
5	Send data	T (A)	
6	Signal ground	SG	

The 6-pin type modular connector should be used for the connection to the COM-ML.

Recommended model: TM4P-66P (Manufactured by HIROSE ELECTRIC CO., LTD.)

■ Wiring




NOTE

If communication errors occur frequently due to the operation environment or the communication distance, connect termination resistors to the host computer side.

Up to 16 SRZ units can be connected to a host computer communication port.

■ When the interface of host computer is RS-232C


Connect the RS-232C/RS-422A converter between the host computer and the COM-ML.



- W-BF-02 and W-BF-28 communication cable (RKC product) can be used as communication cable. If noise is a factor, customer should use a twisted pair cable (not included) or something to that effect.
- Recommended RS-232C/RS-422A converter: COM-A (RKC product)
 For the COM-A, see the **COM-A/COM-B Instruction Manual (IMSRM33-E** .

■ When the host computer has a USB connector


Connect the USB communication converter between the host computer and the COM-ML.



For the COM-K2, see the **COM-K2 Instruction Manual**.

4.4.2 When connected with RS-485

■ Pin layout of connector




■ Connector pin number and signal details

Pin No.	Signal name	Symbol
1	Send/receive data	T/R (A)
2	Send/receive data	T/R (B)
3	Signal ground	SG
4	Unused	_
5	Unused	_
6	Signal ground	SG

The 6-pin type modular connector should be used for the connection to the COM-ML.

Recommended model: TM4P-66P (Manufactured by HIROSE ELECTRIC CO., LTD.)

■ Wiring




NOTE

If communication errors occur frequently due to the operation environment or the communication distance, connect termination resistors to the host computer side.

Up to 16 SRZ units can be connected to a host computer communication port.

■ When the interface of host computer is RS-232C

Connect the RS-232C/RS-485 converter between the host computer and the COM-ML.




NOTE

Be sure to insulate the wires that are not used by covering them with insulating tape.

- Recommended RS-232C/RS-485 converter: CD485, CD485/V Data Link product, Inc. or equivalent.
- W-BF-01 communication cable (RKC product) can be used as communication cable. If noise is a factor, customer should use a twisted pair cable (not included) or something to that effect.

■ When the host computer has a USB connector

Connect the USB communication converter between the host computer and the COM-ML.



For the COM-K2, see the **COM-K2 Instruction Manual**.


4.4.3 Connections for loader communication

Connect a USB communication converter COM-K2 (sold separately)* between the host computer and the COM-ML.

Loader communication makes it possible to check and set data of the COM-ML and the controller (SRZ).

* A loader communication cable (option) is required for the connection to the loader communication connector on the COM-MI.

USB communication converter COM-K2-1 (with Loader communication cable [cable length: 1 m])



NOTE

The Loader port is only for parameter setup. Not used for data logging during operation.

- During the loader communication, the COM-ML requires an external power source. The COM-ML will not function on the USB power from a personal computer alone.
- The module address for loader communication is fixed at "0."
- Loader communication corresponds to RKC communication (based on ANSI X3.28-1976 subcategories 2.5 and B1).
- For the COM-K2, see the **COM-K2 Instruction Manual**.

5. HOST COMMUNICATION SETTING

⚠ WARNING


- To prevent electric shock or instrument failure, always turn off the power before setting the switch.
- To prevent electric shock or instrument failure, never touch any section other than those instructed in this manual.

5.1 Address Setting

Set host communication address of COM-ML (SRZ unit). Set an address for the COM-ML (SRZ unit) using a small blade screwdriver.


NOTE

When two or more COM-ML (SRZ unit) are connected, to avoid problems or malfunction, do not duplicate an address on the same communication line.



5.2 DIP Switch Setting

Use the DIP switch at the left side of the COM-ML to set the speed and protocol of host communication, default IP address setting, and DIP switch enable/disable.



1	2		Host communication speed
OFF	OFF	4800 bps	
ON	OFF	9600 bps	
OFF	ON	19200 bps	[Factory se value]
ON	ON	38400 bps	

3	Communication protocol/Data bit configuration			
OFF	RKC communication (Data 8-bit, without parity, Stop 1-bit)	[Factory se value]		
ON	Modbus (Data 8-bit, without parity, Stop 1-bit)			

6	7	Default IP address setting
OFF	OFF	Do not execute the default IP address setting [Factory se value]
ON	OFF	Do not set this one
OFF	ON	Do not set this one
ON	ON	Execute the default IP address setting *

^{*} See ■ Default IP address setting (P. 28).

8	DIP switch enable/disable			
OFF	Enable (enable the DIP switch settings) [Factory se			
ON	Disable (enable the host communication or loader commu	nication settings) *		

^{*} The only host communication or loader communication settings that are enabled are the host communication speed and protocol and the data bit configuration.


4	5	
OFF	OFF	Fixed

When the communication protocol is set with the DIP switch, the data bit configuration is automatically set to "data 8-bit, without parity, stop 1-bit." To change to another data bit configuration, set the configuration in host communication or loader communication.

If you wish to set the data bit configuration, host communication speed, and communication protocol in host communication or loader communication, first set DIP switch No. 8 to ON.

6. COMMUNICATION SETTING OF **SRZ FUNCTION MODULE**

Only make the module address setting to make the SRZ function module (Z-TIOA/B and Z-DIO-A modules) communication settings. The SRZ unit performs internal communication between the COM-ML and the function module, so the communication protocol, communication speed, and data bit configuration do not need to be set.



Setting the Z-TIO module address determines the temperature control channel number used for communication.

For relation of the module address and channel number, see 6.2 Temperature Control Channel of SRZ Unit (P. 24) and 6.3 Digital Input/Output Channel of Z-DIO Module (P. 25).


6.1 Address Setting of the Function Modules

Set the address of the function modules. When using two or more function modules, set the desired module address to each module. For this setting, use a small blade screwdriver.



M NOTE


To avoid problems or malfunction, do not duplicate a module address on the same communication line.



Ш The maximum number of function modules (Z-TIO-A/B and Z-DIO-A modules) described in the following can be joined per COM-ML.

- When joining function modules of the same type: Up to 16 modules
- When joining function modules of two or more different types: Up to 31 modules (However, the maximum joinable number of function modules of the same type is 16.)

Address setting example of function module (16 Z-TIO module, 14 Z-DIO module):



6.2 Temperature Control Channel of the SRZ Unit


Setting the Z-TIO module address determines the temperature control channel number used for communication. To each Z-TIO module address, the relevant temperature control channel is assigned. Each temperature control channel number can be calculated from the following equation.

Temperature control channel number of communication =

[Module address setting a] × [Maximum channel number of the function module b]

+ [Channel number in a module]

Example: When 16 Z-TIO modules (4-channel type) are joined



• Z-TIO module 3: The temperature control channel number used for communication of channel 4 - 2 × 4 + 4 = 12

^a When the setting is A to F, it is a decimal number.

^b For the Z-TIO module, it is calculated by "4."

6.3 Digital Input/Output Channel of Z-DIO Module

Setting the Z-DIO module address determines the digital input/output channel number of SRZ unit. To each Z-DIO module address, the relevant digital input/output channel is assigned. Each digital input/output channel can be calculated from the following equation.

Digital input/output channel number =


[Module address setting a] × [Maximum channel number of the function module b]

+ [Input (or output) channel number in a module]

^a When the setting is A to F, it is a decimal number.

^b For the Z-DIO module, it is calculated by "8."

Example: When 16 Z-DIO modules are joined



• Digital output channel number of digital output (DO) channel 6 of Z-DIO module 16 \cdot 15 \times 8 + 6 = 126

7. INITIAL COMMUNICATION DATA SETTINGS

Configure the initial communication data settings for EtherNet/IP communication.

7.1 IP Address Setting

■ Fixed IP address setting

Set the fixed IP address to the COM-ML.

The IP address can be set in host communication or loader communication.


Refer to the following RKC communication identifiers and Modbus register addresses to set the IP address. For the set IP address, the power must be turned off and then on, in order for the settings to take effect.

Name	RKC identifier	Modbus register address		Data range	Factory set value
	identiller	HEX	DEC		Set value
First-byte of IP address	QB	801B	32795	0 to 255	192
Second-byte of IP address	QC	801C	32796	0 to 255	168
Third-byte of IP address	QD	801D	32797	0 to 255	1
Fourth-byte of IP address	QE	801E	32798	0 to 255	1

(Factory set value for COM-ML IP address: 192.168.1.1)



For the IP address, check with the administrator of the network (LAN) to which the COM-ML is connected.



For information on connecting the COM-ML to a host computer, see **4.4 Connection to Host Computer (P. 16)**.

■ Acquisition of the IP address by the DHCP


The acquisition of the IP address by the DHCP is possible.

Use host communication or loader communication to set "DHCP selection" to "1 (valid)," and then connect to Ethernet to acquire an IP address from the DHCP server.

The IP address which was acquired, the power must be turned off and then on, in order for the settings to take effect.

Name	RKC identifier	Mod register	lbus address	Data range	Factory set value	
	luentiner	HEX	DEC		Set value	
DHCP selection	QF	801F	32799	0: DHCP is invalid 1: DHCP is valid	0	

[Connection example]



NOTE

For information on acquiring an IP address by DHCP, check with the administrator of the network (LAN) to which the COM-ML is connected.

NOTE

When an IP address is acquired by DHCP, an IP address is acquired each time the COM-ML connects to the network, and thus the IP address will be different each time. Note that some programs will require settings to be changed when the IP address changes.


When the default IP address setting is executed using the DIP switches, the DHCP selection will change to "0: DHCP is invalid."

■ Default IP address setting


The IP address can be set to the factory set value using the DIP switches.

Operation procedure

- 1. Turn off the power of COM-ML.
- 2. Turn on No. 6 and No. 7 of DIP switch.



- 3. Turn on the power of COM-ML.
- 4. The FAIL/RUN lamp will flash green for about 5 seconds and then light solidly. At this point, the IP address changes to the factory set value "192.168.1.1" and the DHCP selection will change to "0: DHCP is invalid."



- 5. Turn off the power of the COM-ML once again and return DIP switches No. 6 and No. 7 to OFF.
 - If DIP switches No. 6 and No. 7 are left ON, the set IP address will revert to the factory set value every time the power is turned on.
- 6. Turn the power of the COM-ML back on. This completes the procedure.

7.2 EtherNet/IP Communication Settings

Configure settings necessary for EtherNet/IP communication.

EtherNet/IP communication methods supported by the COM-ML are "I/O Communication" and "Explicit Message Communication." And the setting of three objects to show below is necessary.

- Controller communication data item setting object (0xC5: C5Hex) [hereafter called 0xC5] (Set the first Modbus address of the communication items used in EtherNet/IP communication.)
- Controller communication measurement item (IN) setting object (0xC6: C6Hex) [hereafter called 0xC6] *

(Set the number of communication items used for monitor in I/O communication.)

Controller communication setting item (OUT) setting object (0xC7: C7Hex)
 [hereafter called 0xC7] *

(Set the number of communication items used for setting in I/O communication.)

* Use it in case of I/O communication.

The content of these objects can be set by host communication or loader communication. Explicit message communication of EtherNet/IP communication can also be used.

When host communication or loader communication is used to set the content of the objects, the objects correspond to the RKC identifiers and Modbus register addresses shown below.

Name and Object	RKC	register	lbus address	Data range	Factory set
-	identifier	HEX	DEC	(data size indicated in brackets [])	value
Communication data items setting [Object: 0xC5]	QG	8020 : 8051	32800 : 32849	RKC communication: 0 to 65535 Modbus: 0000H to FFFFH	65535 (FFFFH)
		0031	32077	[50]	
Number of measured data items (IN) [Object: 0xC6]	QH	8052 :	32850 :	0 to 128 0: Unused	0
		8083	32899	[50]	
Number of setting data items (OUT) [Object: 0xC7]	QI	8084 :	32900 :	0 to 127 0: Unused	0
(o o 1) [o ojeen oke/]		80B5	32949	[50]	

For information on explicit message communication setting, see 10.5 Tool Settings (P. 76) and 10.7 Explicit Message Communication (P. 87).

Communication data items setting

Set the communication items used in EtherNet/IP communication.

These apply to the object model "Controller communication data item setting object (0xC5: C5Hex)."

- Up to 50 communication items (attributes 100 to 149) can be set.
- 0xC5 attributes 100 to 149 (50 items) correspond to CH1 to CH50 of identifier QG of RKC communication, and to Modbus register addresses 8020H to 8051H.
- In each item, set the Modbus register address (first address only) of all communication items used in EtherNet/IP communication (I/O communication and explicit message communication).
- Set items used in I/O communication (these can also be used in explicit message communication) in attributes 100 and following without any intervals, and then set items that are only used in explicit message communication.

- The data order in I/O communication is the same as the 0xC5 attribute order. Set the number of data used in each item in 0xC6 and 0xC7.
- Set 65535 (FFFFH) in unused items. Communication items following attributes set to 65535 (FFFFH) are not used in I/O communication.
 - For object models, see 13. OBJECT MODELS (P. 102). In addition, for Modbus register addresses of communication items, see 9. COMMUNICATION DATA LIST (P. 38).
 - For setting configuration, see \blacksquare Setting example (P. 32).

Number of measured data items (IN)

Set the number of communication items used for monitor in I/O communication of EtherNet/IP. These apply to the object model "Controller communication measurement item (IN) setting object (0xC6: C6Hex)."

- Up to 50 communication items (attributes 100 to 149) can be set.
- In the attribute numbers of 0xC6 that are the same as the attribute numbers of the communication items used in the measurement items (IN) of I/O communication (in the communication items set in 0xC5), set the data size used.
- 0xC6 attributes 100 to 149 (50 items) correspond to CH1 to CH50 of identifier QH of RKC communication and to Modbus register addresses 8052H to 8083H.
- Data up to a total of the set values in the attributes of 0xC6 (cumulative total from attribute 100) of 128 (0080H) are valid. Any data after that are disregarded.
 - For object models, see 13. OBJECT MODELS (P. 102).
 - For setting configuration, see \blacksquare Setting example (P. 32).

Number of setting data items (OUT)

Set the number of communication items used for setting in I/O communication of EtherNet/IP. These apply to the object model "Controller communication setting item (OUT) setting object (0xC7: C7Hex)."

- Up to 50 communication items (attributes 100 to 149) can be set.
- In the attribute numbers of 0xC7 that are the same as the attribute numbers of the communication items used in the setting items (OUT) of I/O communication (in the communication items set in 0xC5), set the data size used.
- 0xC7 attributes 100 to 149 (50 items) correspond to CH1 to CH50 of identifier QI of RKC communication and to Modbus register addresses 8084H to 80B5H.
- Data up to a total of the set values in the attributes of 0xC7 (cumulative total from attribute 100) of 127 (007FH) are valid. Any data after that are disregarded.
- Regardless of the setting of 0xC7, "setting state selection" is assigned to the first-word of the setting data item (OUT).
 - For object models, see 13. OBJECT MODELS (P. 102).
 - For setting configuration, see \blacksquare Setting example (P. 32).

■ Data setting of each items

Set the data of the communication items set in 0xC5.

The content of these objects can be set by host communication or loader communication. Explicit message communication of EtherNet/IP communication can also be used.

Host communication and Loader communication

Set the data for the communication items corresponding to the Modbus register addresses set in 0xC5.

[Example]

Setting the data of CH1 to "100" when "set value (SV)" is specified in the communication item setting (0xC5)

Modbus: Write "100" to the Modbus register address "0ADCH" of CH1 of the set value (SV). RKC communication:

Write "100" to CH1 of the RKC communication identifier "S1" of the set value (SV).

Explicit message communication

These apply to the object model "Controller object (0x64: 64Hex)" [hereafter called 0x64].

- 0x64 attributes 100 to 149 correspond to 0xC5 attributes 100 to 149.
- The instance number of 0x64 indicates what number the data is from the Modbus register address specified in the attribute number of 0xC5.
- If data was set for a read-only (RO) item, the data will revert to the data that was read after several seconds. The attribute of unused items is read-only (RO), and the data is 0.
 - For object models, see 13. OBJECT MODELS (P. 102). In addition, for Modbus register addresses of communication items, see 9. COMMUNICATION DATA LIST (P. 38).
 - For setting configuration, see \blacksquare Setting example (P. 32).

Setting example

If one Z-TIO module is joined to the COM-ML, set the following conditions:

- For I/O communication, use CH1 to CH4 of "measured value (PV)" and "set value (SV)" of the Z-TIO module.
- For explicit message communication, use "RUN/STOP transfer (each units)."
- Setting condition: Measured data items (IN): Measured value (PV), Set value (SV)

Setting data items (OUT): Set value (SV) Assigned destination of communication item:

Measured value (PV): Attribute 100
Set value (SV): Attribute 101
RUN/STOP transfer: Attribute 102

Set value (SV): CH1: 150, CH2: 200, CH3: 250, CH4: 300

RUN/STOP transfer: 0 (STOP), 1 (RUN)

Setting of object models

0xC5 setting [Communication data items]

Attribute 100: 01FCH [First Modbus register address of measured value (PV)]

Attribute 101: 0ADCH [First Modbus register address of set value (SV)]

Attribute 102: 0133H [First Modbus register address of RUN/STOP transfer (each units)]

Attribute 103 to 149: FFFFH [Unused]

0xC6 setting [Number of measured data items (IN)]

Attribute 100: 0004H [Number of measured value (PV): For 4 channels]

Attribute 101: 0004H [Number of set value (SV): For 4 channels]

Attribute 102 to 149: 0000H [Unused]

0xC7 setting [Number offsetting data items (OUT)]

Attribute 100: 0000H [Unused]

Attribute 101: 0004H [Number of set value (SV): For 4 channels]

Attribute 102 to 149: 0000H [Unused]

0x64 setting [Data of each communication items] *

Object instance 1: Attribute 100: CH1 of measured value (PV): Read value
Attribute 101: CH1 of set value (SV): 0096H (150)

Attribute 102: RUN/STOP transfer (each units): 0000H (0), 0001H (1)

Attribute 103 to 149: 0 [Unused]

Object instance 2: Attribute 100: CH2 of measured value (PV): Read value

Attribute 101: CH2 of set value (SV): 00C8H (200)

Attribute 102 to 149: 0 [Unused]

Object instance 3: Attribute 100: CH3 of measured value (PV): Read value

Attribute 101: CH3 of set value (SV): 00FAH (250)

Attribute 102 to 149: 0 [Unused]

Object instance 4: Attribute 100: CH4 of measured value (PV): Read value

Attribute 101: CH4 of set value (SV): 0012CH (300)

Attribute 102 to 149: 0 [Unused]

^{*} Use it in case of explicit message communication

Setting of RKC communication (Set value is a decimal number.)

Communication data items

```
CH1 of identifier OG:
                                    [First Modbus register address of measured value (PV)]
                            508
CH2 of identifier QG:
                            2780
                                    [First Modbus register address of set value (SV)]
CH3 of identifier QG:
                            307
                                    [First Modbus register address of RUN/STOP transfer (each units)]
```

CH4 to 50 of identifier QG: 65535

Number of measured data items (IN)

CH1 of identifier OH,: 4 [Number of measured value (PV): For 4 channels] 4 [Number of set value (SV): For 4 channels] CH2 of identifier OH:

CH3 to 50 of identifier QH: 0 [Unused]

Number offsetting data items (OUT)

CH1 of identifier QI: 0 [[Unused]

CH2 of Identifier OI: 4 [Number of set value (SV): For 4 channels]

CH3 to 50 of identifier QI: 0 [[Unused]

Data setting of communication items

CH1 of identifier S1: 150 [CH1 of set value (SV)] CH2 of identifier S1: 200 [CH2 of set value (SV)] CH3 of identifier S1: 250 [CH3 of set value (SV)] CH4 of identifier S1: 300 [CH4 of set value (SV)]

CH1 of identifier SR: 0 [RUN/STOP transfer (each units): STOP]

1 [RUN/STOP transfer (each units): RUN]

Setting of Modbus

Communication data items

8020H: 01FCH [First Modbus register address of measured value (PV)] 8021H: 0ADCH [First Modbus register address of set value (SV)] 8022H: 0133H [First Modbus register address of RUN/STOP transfer (each units)]

8023H to 8051H: FFFFH [Unused]

Number of measured data items (IN)

8052H: 0004H [Number of measured value (PV): For 4 channels] [Number of set value (SV): For 4 channels] 8053H: 0004H

8054H to 8083H: 0000H [Unused]

Number offsetting data items (OUT)

8084H: 0000H [Unused]

8085H: 0004H [Number of set value (SV): For 4 channels]

8086H to 80B5H: 0000H [Unused]


Data setting of communication items

0ADCH: 0096H [CH1 of set value (SV)] 0ADDH: 00C8H [CH2 of set value (SV)] 0ADEH: 00FAH [CH3 of set value (SV)] 0ADFH: 012CH [CH4 of set value (SV)]

0133H: 0000H [RUN/STOP transfer (each units): STOP] 0001H [RUN/STOP transfer (each units): RUN]

7.3 Other Communication Data Settings

Set communication data (PID constants and event set values of the Z-TIO module, DO manual output of the Z-DIO module, etc.) other than the items set in 7.2 EtherNet/IP Communication Settings (P. 29) using host communication, loader communication, or explicit message communication of EtherNet/IP communication.



For each of the communication setting items, see 9. COMMUNICATION DATA LIST (P. 38).

8. EtherNet/IP


8.1 Outline of EtherNet/IP

EtherNet/IP is an implementation of CIP (Common Industrial Protocol) on Ethernet and TCP/IP. CIP is an application layer protocol that does not depend on the physical layer, and which realizes the product (communication) functions by means of object models.

■ OSI model of EtherNet/IP


EtherNet/IP uses existing Ethernet technology for data communication.

To transmit the CIP message (which is the communication protocol between devices) as TCP/UDP data, the encapsulation layer encapsulates the data.



■ Message structure of EtherNet/IP

An EtherNet/IP message packet has the following structure.




Message required between EtherNet/IP devices.

* CPF: Common Paket Format

■ Communication flow


Explicit message communication uses TCP to transmit data. I/O communication uses UDP to transmit data.



■ CIP communication model

CIP uses the "producer/consumer model" as a communication model.

As communication methods that are possible in the producer/consumer model, scanner/adapter (multi-cast: 1 to N) communication and client/server (peer-to-peer: 1 to 1) communication are used.



8.2 Communication Method

COM-ML supports "I/O communication" and "Explicit message communication" for EtherNet/IP.

■ I/O communication

I/O communication is mainly used in adapter/scanner (multi-cast: 1 to N) communication. Data is periodically exchanged between the scanner and adapter.

To perform I/O communication, the following items must be set.

Setting item	Description
Controller communication data item setting object (0xC5: C5Hex)	Set the first Modbus address of the communication items used in communication.
Controller communication measurement item (IN) setting object (0xC6: C6Hex)	Set the number of communication items used for monitor.
Controller communication setting item (OUT) setting object (0xC7: C7Hex)	Set the number of communication items used for setting.



In the case of I/O communication, data is sent and received using the "Assembly object (0x04: 04Hex)" object model. Measurement items (IN) use attribute 3 of instance 100, and setting items (OUT) use attribute 3 of instance 101.

To check and set measurement items (IN) and settings items (OUT), a tool is used.

■ Explicit message communication

Explicit message communication is mainly used in client/server (peer-to-peer: 1 to 1) communication. Data communication between the client and server only takes place when necessary (at an event). To use explicit message communication, the following items must be set.

Setting item	Description
Controller communication data item setting object (0xC5: C5Hex)	Set the first Modbus address of the communication items used in communication.
Controller object (0x64: 64Hex)	Set the Modbus register address data specified in 0xC5. The order of the data is as specified in 0xC5.

For setting contents, see 7.2 EtherNet/IP Communication Settings (P. 29).



9. COMMUNICATION DATA LIST

9.1 Reference to Communication Data List

	(1) ↓	(2) 	(3) 		4) 	(5) 	(6) ↓ ▼	(7) ↓	(8) ↓	(9)
No.	Name	lden- tifier	Chan- nel	Register HEX	address DEC	Digits	Attri- bute	Struc- ture	Data range	Factory set value
1	Measured value (PV)	M1	CH1 : : CH64	01FC : 023B	508 : : 571	7	RO	С	Input scale low to Input scale high	_

(1) Name: Communication data name

(2) Identifier: Communication identifier of RKC communication

(3) Channel: Channel number of data of one unit

(4) Register address: Register address of Modbus data item specification

HEX: Hexadecimal DEC: Decimal

(5) Digits: The number of communication data digits in RKC communication

(6) Attribute: A method of how communication data items are read or written when viewed

from the host computer or PLC is described

RO: Read only data

Data direction
Host computer or PLC ← Controller

R/W: Read and Write data

Host computer or PLC ← Controller

(7) Structure: U: Data for each SRZ unit


M: Data for each module

C: Data for each channel 1,2


¹ On a Z-TIO module (2-channel type), the communication data of the CH3 and CH4 becomes invalid.

(8) Data range: Read or write range of communication data

• ASCII code data (Example: 7 digits)



• 16-bit data (bit image)



(9) Factory set value: Factory set value of communication data

² Parameters only used for heat/cool control or position proportioning control, therefore data (indicated by ♣ in the name column) for CH2 and CH4 of Z-TIO modules are unused. [Read is possible (0 is shown), but the result of Write is disregarded.]

⚠ WARNING

The Engineering setting data should be set according to the application before setting any parameter related to operation. Once the communication data in the Engineering mode are set correctly, no further changes need to be made to parameters for the same application under normal conditions. If they are changed unnecessarily, it may result in malfunction or failure of the instrument. RKC will not bear any responsibility for malfunction or failure as a result of improper changes in the Engineering mode.

NOTE

Some of the communication data of the COM-ML will not be enabled until the power is turned on again, or control is switched from STOP to RUN.

Communication data No. 18 to 38

NOTE

Communication data includes both "Normal setting data" and "Engineering setting data." During RUN (control), the attribute of engineering setting data is RO. To configure engineering setting data, the RUN/STOP switch must be set to STOP (control stopped).

Z-TIO module: Normal setting data No. 1 to 85

Engineering setting data No. 86 to 208

Z-DIO module: Normal setting data No. 1 to 13

Engineering setting data No. 14 to 27

9.2 Communication Data of COM-ML

NI -	A1	lden-	Chan-	Register	address	D:	Attri-	Struc-	D-1	Factory
No.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
1	Model code (COM-ML)	ID	CH1	_	_	32	RO	M	Model code (character)	_
2	Model code (Function module*)	ΙE	CH1 : : CH100	_	_	32	RO	M	Model code (character)	_
3	ROM version (COM-ML)	VR	CH1	_	_	8	RO	M	ROM version	_
4	ROM version (Function module*)	VQ	CH1 : : CH100	_	_	8	RO	M	ROM version	_
5	Integrated operating time monitor (COM-ML)	UT	CH1		_	7	RO	M	0 to 19999 hours	_
6	Integrated operating time monitor (Function module*)	UV	CH1 : : CH100	_	_	7	RO	M	0 to 19999 hours	_
7	Error code (COM-ML)	ER	CH1	0000	0	7	RO	U	RKC communication Adjustment data error Data back-up error Logic output data error Stack overflow Modbus Bit data Chick Adjustment data error Adjustment data error Adjustment data error Logic output data Bit data Chick Adjustment data error Chick Adjustment data error	
8	Error code (Function module*)	EZ	CH1 : CH100	0001 : 0064	1 : 100	7	RO	M	b6: Stack overflow ² b7 and b8: Unused b9: Network module error ² b10 to b15: Unused Data 0: OFF 1: ON [Decimal number: 0 to 615] The error condition is shown by the OR of each module. When multiple errors occur, the error No. is the sum value. ¹ Common item of the COM-ML and function module ² Item of the COM-ML	
9	Backup memory state monitor (COM-ML)	EM	CH1	0065	101	1	RO	M	0: The content of the backup memory does not coincide with that of the RAM.	_
10	Backup memory state monitor (Function module*)	CZ	CH1 : CH100	0066 : : 00C9	102 : : 201	1	RO	M	The content of the backup memory coincides with that of the RAM.	_
11	Unused			00CA 00CB	202 203	_	_	_	_	
12	Network error code	ES	CH1	00CC	204	7	RO	U	Normal Network operation not possible	_
13	Unused	_	_	00CD : 0131	205 : 305	_	_	_	_	_

^{*} Function module: Z-TIO-A/B module or Z-DIO module

Continued on the next page.

No.	Name	Iden-	1		address	Digits	Attri-	Struc-	Data range	Factory
14	N. 1. C. 1	tifier	nel	HEX	DEC	_	bute	ture		set value
14	Monitor for the number of connected modules	QK	CH1	0132	306	7	RO	U	0 to 31	
15	RUN/STOP transfer (Each unit)	SR	CH1	0133	307	1	R/W	U	0: STOP (Control stop) 1: RUN (Control start)	0
16	RUN/STOP transfer (Each module)	SW	CH1 : CH100	0134 : 0197	308 : 407	1	R/W	M	0: STOP (Control stop) 1: RUN (Control start)	0
17	Control RUN/STOP holding setting (Each module)	X1	CH1 : : CH100	0198 : 01FB	408 : 507	1	R/W	М	0: Not holding (STOP start) 1: Holding (RUN/STOP hold)	1
	The following items	are ena	bled wh	en the po	ower is tu	rned o	n agai	n or wh	en control is changed from STOP to l	RUN.
18	Unused	_	_	8000	32768	_		_	_	_
19	Communication protocol	VP	CH1	8003 8004	32771 32772	1	R/W	U	0: RKC communication 1: Modbus	0
20	Communication communication speed	VU	CH1	8005	32773	1	R/W	U	0: 4800 bps 2: 19200 bps 1: 9600 bps 3: 38400 bps	2
21	Communication data bit configuration	VW	CH1	8006	32774	7	R/W	U	0 to 5 See Table 1: Data bit configuration	0
22	Communication interval time	VX	CH1	8007	32775	7	R/W	U	0 to 250 ms	10
23	Unused	_	_	8008 : 8010	32776 : 32784	_	_	_	_	_
24	Method for setting the number of connected modules	RY	CH1	8011	32785	7	R/W	U	O: No action 1: Automatically set the maximum number of connected function modules only when power is turned on. 2: Execute automatic setting of the maximum number of connected function modules. (After automatic setting of the number of connected function modules, the value automatically reverts to 0.)	1
25	Unused	_	_	8012	32786	_	_	_	_	
26	Number of connected modules * (Z-TIO module)	QY	CH1	8013	32787	7	R/W	U	0 to 16 This is the maximum address of the Z-TIO module that is connected to the COM-ML.	_
27	Number of connected modules * (Z-DIO module)	QU	CH1	8014	32788	7	R/W	U	0 to 16 This is the maximum address of the Z-DIO module that is connected to the COM-ML.	

^{*} When 1 or 2 is set for the communication identifier RY (method of setting the number of connected modules), the maximum number of connected modules is set automatically. When 0 is set, the maximum number of connected modules is set manually.

Maximum number of connected modules: Maximum address of function modules (address setting switch set value + 1)

COM-ML uses this set value to calculate the number of channels of communication data (RKC communication only).

Table 1: Data bit configuration

Set value	Data bit	Parity bit	Stop bit	Settable communication
0	8	Without	1	37. 11
1	8	Even	1	Modbus RKC communication
2	8	Odd	1	Terce communication
3	7	Without	1	
4	7	Even	1	RKC communication
5	7	Odd	1	

Continued on the next page.

NI.	Mana	lden-	Chan-	Register	address	D: -:4-	Attri-	Struc-	Data was se	Factory
No.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
28	Unused	_	_	8015	32789	_	_	_	_	_
				:	:					
				801A	32794					
29	First-byte of IP address	QB	CH1	801B	32795	7	R/W	U	0 to 255	192
30	Second-byte of IP address	QC	CH1	801C	32796	7	R/W	U	0 to 255	168
31	Third-byte of IP address	QD	CH1	801D	32797	7	R/W	U	0 to 255	1
32	Fourth-byte of IP address	QE	CH1	801E	32798	7	R/W	U	0 to 255	1
33	DHCP selection	QF	CH1	801F	32799	1	R/W	U	0: DHCP is invalid 1: DHCP is valid	0
34	Communication data	QG	CH1	8020	32800	7	R/W	M	0 to 65535	65535
	items setting		:	:	:					
			CH50	8051	32849					
35	Number of measured	QH	CH1	8052	32850	7	R/W	M	0 to 128	0
	data items (IN)		:	:	:				0: Unused	
			CH50	8083	32899					
36	Number of setting data	QI	CH1	8084	32900	7	R/W	M	0 to 127	0
	items (OUT)		:	:	:				0: Unused	
			CH50	80B5	32949					
37	Unused			80B6	32950	_			<u> </u>	_
38	Control RUN/STOP	X2	CH1	80B7	32951	1	R/W	U	0: Not holding (STOP start)	1
	holding setting (Each unit)								1: Holding (RUN/STOP hold)	

9.3 Communication Data of Z-TIO Module

For details of Z-TIO module communication data, see **SRZ Instruction Manual (IMS01T04-E)**.

NI -	N	lden-	Chan-	Register	address	D:::11	Attri-	Struc-	D-1	Factory
No.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
1	Measured value (PV)	M1	CH1	01FC	508	7	RO	C	Input scale low to Input scale high	
			:	:	:					
			CH64	023B	571					
2	Comprehensive event state	AJ	CH1 : CH64	023C : 027B	572 : : 635	7	RO	С	• RKC communication Least significant digit: Event 1 2nd digit: Event 2 3rd digit: Event 3 4th digit: Event 4 5th digit: Heater break alarm 6th digit: Temperature rise completion 7th digit: Burnout Data 0: OFF 1: ON • Modbus Bit data b0: Event 1 b1: Event 2 b2: Event 3 b3: Event 4 b4: Heater break alarm b5: Temperature rise completion b6: Burnout	
3	Operation mode state monitor	LO	CH1 : CH64	027C : 02BB	636 : 699	7	RO	С	Data 0: OFF 1: ON [Decimal number: 0 to 127] • RKC communication Least significant digit: Control STOP 2nd digit: Control RUN 3rd digit: Manual mode 4th digit: Remote mode 5th digit to Most significant digit: Unused Data 0: OFF 1: ON • Modbus Bit data b0: Control STOP b1: Control RUN b2: Manual mode b3: Remote mode b4 to b15: Unused Data 0: OFF 1: ON [Decimal number: 0 to 15]	_
4	Unused	_	_	02BC :	700 :	_	_	_	_	_
5	Moninulated autout	01	CH1	02CB 02CC	715 716	7	RO	С	PID control or heat/cool PID control:	
3	Manipulated output value (MV) monitor [heat-side]	O1	: : : : : :	02CC : 030B	716 : 779	,	KU		PlD control of heat/cool PlD control: -5.0 to +105.0 % Position proportioning control with feedback resistance (FBR) input: 0.0 to 100.0 %	_
6	Manipulated output value (MV) monitor [cool-side]	O2	CH1 : CH64	030C : 034B	780 : 843	7	RO	С	-5.0 to +105.0 %	_
7	Current transformer (CT) input value monitor	M3	CH1 : CH64	034C : 038B	844 : 907	7	RO	С	CTL-6-P-N: 0.0 to 30.0 A CTL-12-S56-10L-N: 0.0 to 100.0 A	_

Continued on the next page.

No.	Name	lden-	Chan-	Register	address	Dicita	Attri-	Struc-	Data rongo	Factory
NO.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
8	Set value (SV) monitor	MS	CH1 :	038C :	908 :	7	RO	С	Setting limiter (low) to Setting limiter (high)	_
			CH64	03CB	971					
9	Remote setting (RS) input value monitor	S2	CH1 :	03CC :	972 :	7	RO	С	Setting limiter (low) to Setting limiter (high)	_
			CH64	040B	1035					
10	Burnout state monitor	B1	CH1 :	040C :	1036 :	1	RO	С	0: OFF 1: ON	_
			CH64	044B	1099			_	2 2 2 2 2	
11	Event 1 state monitor	AA	CH1 :	044C :	1100	1	RO	С	0: OFF 1: ON	_
12	Event 2 state monitor	AB	CH64 CH1	048B 048C	1163 1164	1	RO	C	If the Event 3 type is temperature	
12	Event 2 state monitor	Ab	: : : : :	046C : 04CB	1104	1	KO	C	rise completion, check the temperature rise completion state	_
13	Event 3 state monitor	AC	CH04	04CB	1227	1	RO	С	in the comprehensive event state (Identifier: AJ, Register address:	
13	Event 3 state monitor	AC	: : : :	050B	1228		RO	C	023C to 027B). (The Event 3 state monitor does	
14	Event 4 state monitor	AD	CH1	050C	1292	1	RO	С	not turn ON.)	
	Zieni i sime memer		: CH64	.: 054B	1355		110	Ü		
15	Heater break alarm	AE	CH1	054C	1356	1	RO	С	0: OFF	_
	(HBA) state monitor		: CH64	.: 058B	: 1419				1: ON	
16	Output state monitor	Q1	CH1	058C	1420	7	RO	M	RKC communication	_
10		Th	CH16	059B	1435		Po		Least significant digit: OUT1 2nd digit: OUT2 3rd digit: OUT3 4th digit: OUT4 5th digit to Most significant digit: Unused Data 0: OFF 1: ON Modbus Bit data b0: OUT1 b1: OUT2 b2: OUT3 b3: OUT4 b4 to b15: Unused Data 0: OFF 1: ON [Decimal number: 0 to 15] Valid only for time-proportional control output.	
17	Memory area soak time monitor	TR	CH1 : CH64	059C : 05DB	1436 : 1499	7	RO	С	0 minutes 00 seconds to 199 minutes 59 seconds: RKC communication: 0:00 to 199:59 (min:sec) Modbus: 0 to 11999 seconds 0 hours 00 minutes to 99 hours 59 minutes: RKC communication: 0:00 to 99:59 (hrs:min) Modbus: 0 to 5999 minutes Data range of Area soak time can be selected on the Soak time unit.	_
18	Unused	_	_	05DC :	1500	_	_	_	_	_

Continued on the next page.

No.	M	lden-	Chan-	Register	address	D:	Attri-	Struc-	Data	Factory
NO.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
19	Holding peak value ambient temperature	Нр	CH1 :	05EC :	1516 :	7	RO	С	−10.0 to +100.0 °C (14.0 to 212.0 °F)	_
	monitor		CH64	062B	1579					
20	Unused	_	_	062C :	1580 :	_	_		_	_
2.1	*	ED	CYYI	063B	1595		D.O.		DVC : .:	
21	Logic output monitor 1	ED	CH1 : CH16	063C : 064B	1596 : 1611	7	RO	M	RKC communication Least significant digit: Logic output 1 2nd digit: Logic output 2 3rd digit: Logic output 3 4th digit: Logic output 4 5th digit to Most significant digit: Unused Data 0: OFF 1: ON Modbus Bit data b0: Logic output 1 b1: Logic output 2 b2: Logic output 2 b2: Logic output 3 b3: Logic output 4 b4: Logic output 4 b5: Logic output 5 b5: Logic output 6 b6: Logic output 7 b7: Logic output 8 b8 to b15: Unused Data 0: OFF 1: ON [Decimal number: 0 to 255]	
22	Logic output monitor 2	EE	CH1 : CH16	_	_	7	RO	M	Least significant digit: Logic output 5 2nd digit: Logic output 6 3rd digit: Logic output 7 4th digit: Logic output 8 5th digit to Most significant digit: Unused Data 0: OFF 1: ON	
23	Unused	_	_	064C :	1612 :	_	_	_	—	_
				080B	2059					
24	PID/AT transfer	G1	CH1 : CH64	080C : 084B	2060 : 2123	1	R/W	С	PID control Autotuning (AT) * Automatically reverts to 0 after autotuning ends.	0
25	Auto/Manual transfer	J1	CH1 : : CH64	084C : 088B	2124 : 2187	1	R/W	С	0: Auto mode 1: Manual mode	0
26	Remote/Local transfer	C1	CH1 : CH64	088C : 08CB	2188 : : 2251	1	R/W	С	0: Local mode 1: Remote mode When performing remote control by remote setting input and also performing cascade control and ratio setting, transfer to the Remote mode.	0
27	Unused	_	_	08CC : 08DB	2252 : 2267	_	_		_	_
28	Memory area transfer	ZA	CH1 :	08DC :	2268 :	7	R/W	С	1 to 8	1
29	Interlock release	AR	CH64 CH1 :	091B 091C :	2331 2332 :	1	R/W	С	0: Normal state 1: Interlock release execution	0
			CH64	095B	2395					

Continued on the next page.

Nic	Nerre	lden-	Chan-	Register	address	Die!t-	Attri-	Struc-	Dete ::-::::	Factory
No.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
30	Event 1 set value (EV1) ★	A1	CH1 : : CH64	095C : 099B	2396 : : 2459	7	R/W	С	Deviation action, Deviation action between channels, Temperature rise completion range: —Input span to +Input span	50
31	Event 2 set value (EV2) ★	A2	CH1 : CH64	099C : 09DB	2460 : 2523	7	R/W	С	Process action, SV action: Input scale low to Input scale high MV action: -5.0 to +105.0 %	50
32	Event 3 set value (EV3) ★	A3	CH1 : CH64	09DC : 0A1B	2524 : 2587	7	R/W	С	If the Event type corresponds to "0: None," set to RO (Only reading data is possible). If Event 3 corresponds to "9: Temperature rise completion," the Event 3 set value	50
33	Event 4 set value (EV4) ★	A4	CH1 : CH64	0A1C : 0A5B	2588 : : 2651	7	R/W	С	becomes the range for determining temperature rise completion. If Event 4 corresponds to "9: Control loop break alarm (LBA)," the Event 4 set value becomes RO (Only reading data is possible).	50
34	Control loop break alarm (LBA) time ★	A5	CH1 : CH64	0A5C : 0A9B	2652 : : 2715	7	R/W	С	0 to 7200 seconds (0: Unused) If Event 4 is other than "9: Control loop break alarm (LBA)," set to RO (Only reading data is possible).	480
35	LBA deadband ★	N1	CH1 : CH64	0A9C : 0ADB	2716 : : 2779	7	R/W	С	0 (0.0) to Input span If Event 4 is other than "9: Control loop break alarm (LBA)," set to RO (Only reading data is possible).	0 (0.0)
36	Set value (SV) ★	S1	CH1 : : CH64	0ADC : 0B1B	2780 : : 2843	7	R/W	С	Setting limiter (low) to Setting limiter (high)	TC/RTD: 0 V/I: 0.0
37	Proportional band [heat-side]	P1	CH1 : CH64	0B1C : 0B5B	2844 : 2907	7	R/W	С	TC/RTD inputs: 0 (0.0) to Input span (Unit: °C [°F]) Varies with the setting of the decimal point position selection. Voltage (V)/current (I) inputs: 0.0 to 1000.0 % of input span 0 (0.0): ON/OFF action (ON/OFF action for both heat and cool actions in case of a heat/cool control type.)	TC/RTD: 30 (30.0) V/I: 30.0
38	Integral time [heat-side] ★ ♣	I1	CH1 : CH64	0B5C : 0B9B	2908 : : 2971	7	R/W	С	PID control or heat/cool PID control: 0 to 3600 seconds or 0.0 to 1999.9 seconds (0, 0.0: PD action) Position proportioning control: 1 to 3600 seconds or 0.1 to 1999.9 seconds Varies with the setting of the integral/derivative time decimal point position selection.	240
39	Derivative time [heat-side]	D1	CH1 : CH64	0B9C : 0BDB	2972 : 3035	7	R/W	С	0 to 3600 seconds or 0.0 to 1999.9 seconds (0, 0.0: PI action) Varies with the setting of the integral/derivative time decimal point position selection.	60
40	Control response parameter	CA	CH1 : CH64	0BDC : 0C1B	3036 : : 3099	1	R/W	С	0: Slow 1: Medium 2: Fast When the P or PD action is selected, this setting becomes invalid.	PID control, Position proportioning control: 0 Heat/cool PID control: 2

 $[\]bigstar\colon \textsc{Parameters}$ which can be used in multi-memory area function

Continued on the next page.

No.	News	lden-	Chan-	Register	address	Die!t-	Attri-	Struc-	Data	Factory
NO.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
41	Proportional band [cool-side]	P2	CH1 : CH64	0C1C : 0C5B	3100 : 3163	7	R/W	С	TC/RTD inputs: 1 (0.1) to Input span (Unit: °C [°F]) Varies with the setting of the decimal	TC/RTD: 30 (30.0) V/I: 30.0
									point position selection. Voltage (V)/current (I) inputs: 0.1 to 1000.0 % of input span If control is other than heat/cool PID control, set to RO (Only reading data is possible).	
42	Integral time [cool-side]	I2	CH1 :	0C5C :	3164	7	R/W	С	0 to 3600 seconds or 0.0 to 1999.9 seconds	240
	* *		CH64	0C9B	3227				(0, 0.0: PD action) Varies with the setting of the integral/derivative time decimal point position selection. If control is other than heat/cool PID control, set to RO (Only reading data is possible).	
43	Derivative time [cool-side]	D2	CH1 :	0C9C :	3228	7	R/W	С	0 to 3600 seconds or 0.0 to 1999.9 seconds	60
	* *		СН64	0CDB	3291				(0, 0.0: PI action)	
									Varies with the setting of the integral/derivative time decimal point position selection.	
									If control is other than heat/cool PID control, set to RO (Only reading data is possible).	
44	Overlap/Deadband ★ ♣	V1	CH1 :	0CDC :	3292 :	7	R/W	С	TC/RTD inputs: -Input span to +Input span (Unit: °C [°F])	0
			CH64	0D1B	3355				Voltage (V)/current (I) inputs: -100.0 to +100.0 % of input span	
									Minus (–) setting results in overlap. However, the overlapping range is within the proportional range. If control is other than heat/cool PID control, set to RO (Only reading data is possible).	
45	Manual reset ★	MR	CH1 :	0D1C :	3356	7	R/W	С	-100.0 to +100.0 % If the integral function is valid, set to	0.0
			CH64	0D5B	3419				RO (Only reading data is possible). When integral action (heating or cooling side) is zero, manual reset value is	
46	Setting change rate	НН	CH1	0D5C	3420	7	R/W	С	added to the control output. 0 (0.0) to Input span/unit time *	0 (0.0)
	limiter (up) ★		: CH64	0D9B	3483				0 (0.0): Unused	
47	Setting change rate	HL	CH1	0D9C	3484	7	R/W	С	* Unit time: 60 seconds	0 (0.0)
	limiter (down) ★		: CH64	: 0DDB	: 3547				(factory set value)	
48	Area soak time ★	TM	CH1 : CH64	0DDC : 0E1B	3548 : 3611	7	R/W	С	0 minutes 00 seconds to 199 minutes 59 seconds: RKC communication: 0:00 to 199:59 (min:sec) Modbus: 0 to 11999 seconds	RKC communication 0:00 Modbus: 0
									0 hours 00 minutes to 99 hours 59 minutes: RKC communication: 0:00 to 99:59 (hrs:min) Modbus: 0 to 5999 minutes	
									Data range of Area soak time can be selected on the Soak time unit.	

 $[\]bigstar$: Parameters which can be used in multi-memory area function

Continued on the next page.

Na	Nome	lden-	Chan-	Register	address	Dieita	Attri-	Struc-	Data reme	Factory
No.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
49	Link area number ★	LP	CH1	0E1C	3612	7	R/W	С	0 to 8	0
			:	:	:				(0: No link)	
			CH64	0E5B	3675					
50	Heater break alarm	A7	CH1	0E5C	3676	7	R/W	C	When CT is CTL-6-P-N:	0.0
	(HBA) set value		CIICA	: OEOD	2720				0.0 to 30.0 A (0.0: Not used) When CT is CTL-12-S56-10L-N:	
			CH64	0E9B	3739				0.0 to 100.0 A (0.0: Not used)	
									If there is no current transformer (CT)	
									or CT is assigned to "0: None," set to RO (Only reading data is possible).	
51	Heater break	NE	CH1	0E9C	3740	7	R/W	С	0.0 to 100.0 % of HBA set value	30.0
	determination point		:	:	:				(0.0:Heater break determination is	
			CH64	0EDB	3803				invalid) If there is no current transformer (CT) or	
									CT is assigned to "0: None," set to RO	
									(Only reading data is possible).	
									If Heater break alarm (HBA) corresponds to "0: Type A," set to RO	
									(Only reading data is possible).	
52	Heater melting	NF	CH1	0EDC :	3804	7	R/W	C	0.0 to 100.0 % of HBA set value	30.0
	determination point		CIICA		2067				(0.0:Heater melting determination is invalid)	
			CH64	0F1B	3867				If there is no current transformer (CT) or	
									CT is assigned to "0: None," set to RO (Only reading data is possible).	
									If Heater break alarm (HBA)	
									corresponds to "0: Type A," set to RO (Only reading data is possible).	
53	PV bias	PB	CH1	0F1C	3868	7	R/W	С	-Input span to +Input span	0
			:	:	:	,		_		
			CH64	0F5B	3931					
54	PV digital filter	F1	CH1	0F5C	3932	7	R/W	С	0.0 to 100.0 seconds	0.0
			:	:	:				(0.0: Unused)	
			CH64	0F9B	3995			_		
55	PV ratio	PR	CH1 :	0F9C	3996	7	R/W	С	0.500 to 1.500	1.000
			CH64	0FDB	4059					
56	PV low input cut-off	DP	CH1	0FDC	4060	7	R/W	С	0.00 to 25.00 % of input span	0.00
30	1 v low input out off	D1	:	:	:	,	10 11		If the Square root extraction	0.00
			CH64	101B	4123				corresponds to "0: Unused," set to RO	
								_	(Only reading data is possible).	
57	RS bias *	RB	CH1 :	101C :	4124 :	7	R/W	С	-Input span to +Input span	0
			CH64	105B	4187					
58	RS digital filter *	F2	CH1	105B	4188	7	R/W	С	0.0 to 100.0 seconds	0.0
			:	:	:	,			(0.0: Unused)	•••
			CH64	109B	4251					
59	RS ratio *	RR	CH1	109C	4252	7	R/W	С	0.001 to 9.999	1.000
			:	:	:					
			CH64	10DB	4315					
60	Output distribution selection	DV	CH1	10DC	4316	1	R/W	С	0: Control output 1: Distribution output	0
	Selection		CIICA	11175	1270				1. Distribution output	
61	Output distribution	DW	CH64 CH1	111B 111C	4379 4380	7	R/W	С	-100.0 to +100.0 %	0.0
υı		שע	CHI	1110	4300	· /	IV/ W		-100.0 to +100.0 70	0.0
	bias									

^{*} Data on RS bias, RS ratio and RS digital filter is that in cascade control or ratio setting.

Continued on the next page.

 $[\]bigstar$: Parameters which can be used in multi-memory area function

No.		lden-	Chan-	Register	address	D:- ''	Attri-	Struc-	D-4	Factory
	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
62	Output distribution ratio	DQ	CH1 :	115C :	4444 :	7	R/W	С	-9.999 to +9.999	1.000
			CH64	119B	4507					
63	Proportional cycle time	ТО	CH1 : CH64	119C : 11DB	4508 : 4571	7	R/W	С	0.1 to 100.0 seconds This item becomes RO (Only reading data is possible) for the voltage/current output specification.	Relay contact output: 20.0 Voltage pulse output, triac
									This parameter is valid when "0: control output" has been selected at No.95 "Output assignment."	output, triac output and open collector output: 2.0
64	Minimum ON/OFF	VI	CH1	11DC	4572	7	R/W	С	0 to 1000 ms	0
ļ	time of proportioning cycle		: CH64	: 121B	: 4635				This item becomes RO (Only reading data is possible) for the voltage/current output specification.	
65	Manual manipulated output value	ON	CH1 :	121C :	4636 :	7	R/W	С	PID control: Output limiter (low) to	0.0
	*		CH64	125B	4699				Output limiter (high) Heat/cool PID control: -Cool-side output limiter (high) to +Heat-side output limiter (high) Position proportioning control: When there is feedback resistance (FBR) input and it does not break:	
									Output limiter (low) to Output limiter (high) When there is no feedback resistance (FBR) input or the feedback resistance (FBR) input is disconnected:	
									0: Close-side output OFF, Open-side output OFF 1: Close-side output ON, Open-side output OFF 2: Close-side output OFF, Open-side output ON	
66	Area soak time stop function	RV	CH1 : : CH64	125C : 129B	4700 : 4763	1	R/W	С	0: No function 1: Event 1 2: Event 2 3: Event 3 4: Event 4	0
67	EDS mode (for disturbance 1)	NG	CH1 : : CH64	129C : 12DB	4764 : 4827	1	R/W	С	0: No function 1: EDS function mode 2: Learning mode	0
68	EDS mode (for disturbance 2)	NX	CH1 : : CH64	12DC : 131B	4828 : 4891	1	R/W	С	3: Tuning mode EDS function: External disturbance suppression function	0
69	EDS value 1 (for disturbance 1)	NI	CH1 : : CH64	131C : :	4892 : 4955	7	R/W	С	-100.0 to +100.0 %	0.0
70	EDS value 1 (for disturbance 2)	NJ	CH1 : CH64	135C :	4956 :	7	R/W	С		0.0
71	EDS value 2 (for disturbance 1)	NK	CH1 :	139B 139C :	5019 5020 .:	7	R/W	С	-100.0 to +100.0 %	0.0
72	EDS value 2 (for disturbance 2)	NM	CH64 CH1 :: CH64	13DB 13DC :	5083 5084 :	7	R/W	С		0.0

Continued on the next page.

No.	Name	Iden-	Chan-		address	Digits	Attri-	Struc-	Data range	Factory
10.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
73	EDS transfer time (for disturbance 1)	NN	CH1 :	141C :	5148 :	7	R/W	С	0 to 3600 seconds or 0.0 to 1999.9 seconds	0
7.4	EDG (C (NO	CH64	145B	5211	-	D /XX			0
74	EDS transfer time (for disturbance 2)	NO	CH1 :	145C :	5212	7	R/W	С		0
75	EDS action time	NQ	CH64 CH1	149B 149C	5275 5276	7	R/W	С	1 to 3600 seconds	600
13	(for disturbance 1)	NQ	:	:	:	/	K/W	C	1 to 3000 seconds	000
76	EDS action time	NL	CH64 CH1	14DB 14DC	5339 5340	7	R/W	С		600
, 0	(for disturbance 2)	IVL	: CH64	151B	5403	,	IO W	C		000
77	EDS action wait time	NR	CH1	151C	5404	7	R/W	С	0.0 to 600.0 seconds	0.0
, ,	(for disturbance 1)	IVIC	: CH64	155B	5467	,	10 11	C	o.o to ooo.o seconds	0.0
78	EDS action wait time	NY	CH1	155C	5468	7	R/W	С		0.0
	(for disturbance 2)		: CH64	: 159B	.: 5531					
79	EDS value learning	NT	CH1	159C	5532	7	R/W	С	0 to 10 times	1
	times		:	:	:				(0: No learning mode)	
			CH64	15DB	5595				0.770	_
80	EDS start signal	NU	CH1 :	15DC :	5596 :	1	R/W	С	0: EDS start signal OFF 1: EDS start signal ON (for disturbance 1)	0
			CH64	161B	5659				2: EDS start signal ON (for disturbance 2)	
31	Operation mode	EI	CH1	161C	5660	1	R/W	С	0: Unused	3
			: CH64	: 165B	÷ 5723				1: Monitor 2: Monitor + Event function 3: Control	
32	Startup tuning (ST)	ST	CH1	165C	5724	1	R/W	С	0: ST unused	0
,_	Startup tuning (ST)	51	:	:	:	•	10 11		1: Execute once *	· ·
			СН64	169B	5787				2: Execute always * When the startup tuning (ST) is finished,	
									the setting will automatically returns to "0: ST unused." The startup tuning (ST) function is	
									activated according to the ST start condition selected.	
									If control is position proportioning control, set to RO (Only reading data is possible).	
33	Automatic temperature rise	Y8	CH1 :	169C :	5788 :	1	R/W	С	0: Unused 1: Learning *	0
	learning		CH64	16DB	5851				* When the automatic temperature rise	
			C1104	ТОДВ	3631				learning is finished, the setting will automatically returns to "0: Unused."	
34	Communication switch for logic	EF	CH1 :	16DC :	5852 :	7	R/W	M	RKC communication Least significant digit:	0
	switch for logic		CH16	16EB	5867				Communication switch 1 2nd digit: Communication switch 2	
									3rd digit: Communication switch 3	
									4th digit: Communication switch 4 5th digit to Most significant digit:	
									Unused Data 0: OFF 1: ON	
									Modbus Bit data	
									b0: Communication switch 1 b1: Communication switch 2	
									b2: Communication switch 3	
									b3: Communication switch 4 b4 to b15: Unused	
									Data 0: OFF 1: ON	
									[Decimal number: 0 to 15]	

Continued on the next page.

No.	Name	lden-	Chan-	Register	address	Digits	Attri-	Struc-	Data rongo	Factory
NO.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
85	Unused		_	16EC	5868	_				_
				: 196B	6507					
		Set data N	o. 86 or		1	eerina	settin	a [Writa	ble in the STOP mode]	
86	Input type	XI	CH1 :	196C :	6508	7	R/W	C	0: TC input K 1: TC input J	Depends on
			: CH64	: 19AB	6571				1: 1C input J 2: TC input R 3: TC input S 4: TC input B 5: TC input E 6: TC input N 7: TC input T 8: TC input PLII 12: RTD input PLII 12: RTD input Pt100 13: RTD input JPt100 14: Current input 0 to 20 mA DC 15: Current input 4 to 20 mA DC 16: Voltage (high) input 0 to 10 V DC 17: Voltage (high) input 1 to 5 V DC 18: Voltage (high) input 1 to 5 V DC 19: Voltage (low) input 0 to 1 V DC 20: Voltage (low) input 0 to 10 mV DC 21: Voltage (low) input 0 to 10 mV DC 22: Feedback resistance input 100 to 150 Ω 23: Feedback resistance input 151 Ω to 6 kΩ If changed to voltage (high) input from TC/RTD/current/voltage (low)/feedback resistance input, select the hardware by the input selector switch at the side of the module. See SRZ Instruction Manual (IMS01T04+ED).	model code When not specifying: 0
87	Display unit	PU	CH1 :	19AC :	6572 :	7	R/W	С	0: °C 1: °F	0
			СН64	19EB	6635				Use to select the temperature unit for thermocouple (TC) and RTD inputs.	
88	Decimal point position	XU	CH1 : CH64	19EC : 1A2B	6636 : 6699	7	R/W	С	0: No decimal place 1: One decimal place 2: Two decimal places 3: Three decimal places 4: Four decimal places TC input: • K, J, T, E: Only 0 or 1 can be set. • R, S, B, N, PLII, W5Re/W26Re: Only 0 can be set. RTD input: Only 0 or 1 can be set. Voltage (V)/current (I) inputs: From 0 to 4 can be set.	Depends on model code When not specifying: TC/RTD: 1 V/I: 1

Continued on the next page.

NI -	N.	lden-	Chan-	Register	address	D: "	Attri-	Struc-	Dete	Factory
No.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
89	Input scale high	XV	CH1 : CH64	1A2C : 1A6B	6700 : 6763	7	R/W	С	TC/RTD inputs: Input scale low to Maximum value of the selected input range Voltage (V)/current (I) inputs: -19999 to +19999 (However, a span is 20000 or less.) Varies with the setting of the decimal point position	TC/RTD: Maximum value of the selected input range V/I: 100.0
90	Input scale low	XW	CH1 : CH64	1A6C : 1AAB	6764 : 6827	7	R/W	С	TC/RTD inputs: Minimum value of the selected input range to Input scale high Voltage (V)/current (I) inputs: -19999 to +19999 (However, a span is 20000 or less.) Varies with the setting of the decimal point position	TC/RTD: Minimum value of the selected input range V/I: 0.0
91	Input error determination point (high)	AV	CH1 : CH64	1AAC : 1AEB	6828 : 6891	7	R/W	С	Input error determination point (low limit) to (Input range high + 5 % of Input span)	Input range high + (5 % of Input span)
92	Input error determination point (low)	AW	CH1 : : CH64	1AEC : 1B2B	6892 : 6955	7	R/W	С	(Input range low – 5 % of Input span) to Input error determination point (high limit)	Input range low – (5 % of Input span)
93	Burnout direction	BS	CH1 : : CH64	1B2C : 1B6B	6956 : 7019	1	R/W	С	0: Upscale 1: Downscale Valid only when the TC input and voltage (low) input are selected.	0
94	Square root extraction	ХН	CH1 : : CH64	1B6C : 1BAB	7020 : 7083	1	R/W	С	0: Unused 1: Used	0
95	Output assignment (Logic output selection function)	Е0	CH1 : CH64	1BAC : 1BEB	7084 : 7147	1	R/W	С	0: Control output 1: Logic output result 2: FAIL output	0
96	Energized/ De-energized (Logic output selection function)	NA	CH1 : CH64	1BEC : 1C2B	7148 : 7211	1	R/W	С	0: Energized 1: De-energized	0

Ma	N	lden-	Chan-	Register	address	D:- ''	Attri-	Struc-	Detaile	Factory
No.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
97	Event 1 type	XA	CH1 : CH64	1C2C : 1C6B	7212 : 7275	7	R/W	C	0: None 1: Deviation high (Using SV monitor value) 1 2: Deviation low (Using SV monitor value) 1 3: Deviation high/low (Using SV monitor value) 1 4: Band (Using SV monitor value) 1 5: Process low 1 7: SV high 8: SV low 9: Unused 10:MV high [heat-side] 1,2 11:MV low [heat-side] 1,2 11:MV low [cool-side] 1 13:MV low [cool-side] 1 13:MV low [cool-side] 1 14: Deviation high (Using local SV value) 1 15: Deviation low (Using local SV value) 1 16: Deviation high/low (Using local SV value) 1 17: Band (Using local SV value) 1 18: Deviation between channels high 1 19: Deviation between channels low 1 20: Deviation between channels high/low 1 21: Deviation between channels band 1 1 Event hold action is available. 2 If there is feedback resistance (FBR) input in position proportioning control, set to the feedback resistance (FBR) input value.	Depends on model code When not specifying: 0
98	Event 1 channel setting	FA	CH1 :	1C6C :	7276 :	1	R/W	С	1: Channel 1 3: Channel 3 2: Channel 2 4: Channel 4 This function is valid when "deviation	1
			CH64	1CAB	7339				between channels"is selected.	
99	Event 1 hold action	WA	CH1 : CH64	1CAC : 1CEB	7340 : 7403	1	R/W	С	O: OFF 1: Hold action ON (When power turned on) 2: Re-hold action ON (When power turned on and SV changed) This function is valid when input value, deviation or manipulated value action has been selected. In case of a deviation action, this function is not available while in remote mode and while setting changing rate limiter is working.	Depends on model code When not specifying: 0
100	Event 1 interlock	LF	CH1 : : CH64	1CEC : 1D2B	7404 : 7467	1	R/W	С	0: Unused 1: Used	0
101	Event 1 differential gap	НА	CH04 CH1 : CH64	1D2B 1D2C : 1D6B	7468 : 7531	7	R/W	С	Deviation, process, set value, or Deviation action between channels: 0 to Input span (Unit: °C [°F]) MV: 0.0 to 110.0 %	①: 1 ②: 1.0
102	Event 1 delay timer	TD	CH1 : : CH64	1D6C : 1DAB	7532 : 7595	7	R/W	С	0 to 18000 seconds	0

Continued on the next page.

No.	Name	lden-	Chan-	Register	address	Diate	Attri-	Struc-	Dete seems	Factory
NO.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
103	Force ON of Event 1 action	OA	CH1 : CH64	IDAC : IDEB	7596 : 7659	7	R/W	C	■ RKC communication Least significant digit: Event output turned on at input error occurrence 2nd digit: Event output turned on in manual mode 3rd digit: Event output turned on during the autotuning (AT) function is being executed 4th digit: Event output turned on during the setting change rate limiter is being operated 5th digit to Most significant digit: Unused Data 0: Invalid 1: Valid ■ Modbus Bit data b0: Event output turned on at input error occurrence b1: Event output turned on in manual mode b2: Event output turned on during the autotuning (AT) function is being executed b3: Event output turned on during the setting change rate limiter is being operated b4 to b15: Unused Data 0: Invalid 1: Valid	0
104	Event 2 type	XB	CH1 : CH64	1DEC : 1E2B	7660 : 7723	7	R/W	С	[Decimal number: 0 to 15] 0: None 1: Deviation high (Using SV monitor value) 1 2: Deviation low (Using SV monitor value) 1 3: Deviation high/low (Using SV monitor value) 1 4: Band (Using SV monitor value) 1 5: Process high 1 6: Process low 1 7: SV high 8: SV low 9: Unused 10: MV high [heat-side] 1, 2 11: MV low [heat-side] 1 12: MV low [heat-side] 1 13: MV low [cool-side] 1 13: MV low [cool-side] 1 14: Deviation high (Using local SV value) 1 15: Deviation low (Using local SV value) 1 16: Deviation high/low (Using local SV value) 1 17: Band (Using local SV value) 1 18: Deviation between channels high 1 19: Deviation between channels low 1 20: Deviation between channels high/low 1 21: Deviation between channels band 1 1 Event hold action is available. 2 If there is feedback resistance (FBR) input in position proportioning control, set to the feedback resistance (FBR) input inp	Depends on model code When not specifying: 0

Continued on the next page.

No.	Name	lden-	Chan-	Register	address	Dicito	Attri-	Struc-	Data rongo	Factory
NO.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
105	Event 2 channel setting	FB	CH1 : CH64	1E2C : 1E6B	7724 : 7787	1	R/W	С	1: Channel 1 2: Channel 2 3: Channel 3 4: Channel 4	1
									This function is valid when "deviation between channels" is selected.	
106	Event 2 hold action	WB	CH1 : CH64	1E6C : 1EAB	7788 : 7851	1	R/W	С	O: OFF 1: Hold action ON (When power turned on) 2: Re-hold action ON (When power turned on and SV changed) This function is valid when input value, deviation or manipulated value action has been selected. In case of a deviation action, this function is not available while in remote	Depends on model code When not specifying: (
									mode and while setting changing rate limiter is working.	
107	Event 2 interlock	LG	CH1 : : CH64	1EAC : 1EEB	7852 : 7915	1	R/W	С	0: Unused 1: Used	0
108	Event 2 differential gap	НВ	CH1 : : CH64	1EEC : 1F2B	7916 : 7979	7	R/W	С	① Deviation, process, set value, or Deviation action between channels: 0 to Input span (Unit: °C [°F]) ② MV: 0.0 to 110.0 %	①: 1 ②: 1.0
109	Event 2 delay timer	TG	CH1 : : CH64	1F2C : 1F6B	7980 : 8043	7	R/W	С	0 to 18000 seconds	0
110	Force ON of Event 2 action	OB	CH1 : CH64	1F6C : 1FAB	8044 : 8107	7	R/W	C	• RKC communication Least significant digit: Event output turned on at input error occurrence 2nd digit: Event output turned on in manual mode 3rd digit: Event output turned on during the autotuning (AT) function is being executed 4th digit: Event output turned on during the setting change rate limiter is being operated 5th digit to Most significant digit: Unused Data 0: Invalid 1: Valid Modbus Bit data b0: Event output turned on at input error occurrence b1: Event output turned on in manual mode b2: Event output turned on during the autotuning (AT) function is being executed b3: Event output turned on during the setting change rate limiter is being operated b4 to b15: Unused Data 0: Invalid 1: Valid [Decimal number: 0 to 15]	0

Continued on the next page.

NI -	N	lden-	Chan-	Register	address	D:'	Attri-	Struc-	Data was a	Factory
NO.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
No.	Name Event 3 type					7			O: None 1: Deviation high (Using SV monitor value) 1 2: Deviation low (Using SV monitor value) 1 3: Deviation high/low (Using SV monitor value) 1 4: Band (Using SV monitor value) 1 5: Process high 1 6: Process low 1 7: SV high 8: SV low 9: Temperature rise completion 10: MV high [heat-side] 1, 2 11: MV low [heat-side] 1 12: MV low [cool-side] 1 13: MV low [cool-side] 1 14: Deviation high (Using local SV value) 1 15: Deviation high/low (Using local SV value) 1 16: Deviation high/low (Using local SV value) 1 17: Band (Using local SV value) 1 17: Band (Using local SV value) 1 18: Deviation between channels high 1 19: Deviation between channels low 1 20: Deviation between channels high/low 1 21: Deviation between channels band 1 1 Event hold action is available. 2 If there is feedback resistance (FBR)	_
112	Event 3 channel setting	FC	CH1 : CH64	1FEC : : 202B	8172 : 8235	1	R/W	С	input in position proportioning control, set to the feedback resistance (FBR) input value. 1: Channel 1 2: Channel 2 3: Channel 3 4: Channel 4	1
									This function is valid when "deviation between channels" is selected.	
113	Event 3 hold action	WC	CH1 : CH64	202C : : 206B	8236 : 8299	1	R/W	С	0: OFF 1: Hold action ON (When power turned on) 2: Re-hold action ON (When power turned on and SV changed) This function is valid when input value, deviation or manipulated value action has been selected. In case of a deviation action, this function is not available while in remote mode and while setting changing rate	Depends on model code When not specifying: 0
114	Event 3 interlock	LH	CH1 :	206C :	8300	1	R/W	С	limiter is working. 0: Unused 1: Used	0
115	Event 3 differential gap	НС	CH64 CH1 : CH64	20AB 20AC : : 20EB	8363 8364 : 8427	7	R/W	С	① Deviation, process, set value, Deviation action between channels, or Temperature rise completion: 0 to Input span (Unit: °C [°F]) ② MV: 0.0 to 110.0 %	①: 1 ②: 1.0
116	Event 3 delay timer	TE	CH1 : CH64	20EC : 212B	8428 : 8491	7	R/W	С	0 to 18000 seconds If Event 3 corresponds to "9: Temperature rise completion," the Event 3 delay timer becomes the temperature rise completion soak time.	0

Continued on the next page.

NI a	Nema	lden-	Chan-	Register	address	Dia:t-	Attri-	Struc-	Data ::-:-::	Factory
No.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
1117	Force ON of Event 3 action	OC	CH1 : CH64	212C : 216B	8492 : 8555	7	R/W	С	RKC communication Least significant digit: Event output turned on at input error occurrence 2nd digit: Event output turned on in manual mode 3rd digit: Event output turned on during the autotuning (AT) function is being executed 4th digit: Event output turned on during the setting change rate limiter is being operated 5th digit to Most significant digit: Unused Data 0: Invalid 1: Valid Modbus Bit data b0: Event output turned on at input error occurrence b1: Event output turned on in manual mode b2: Event output turned on during the autotuning (AT) function is being executed b3: Event output turned on during the setting change rate limiter is being operated b4 to b15: Unused Data 0: Invalid 1: Valid	0
118	Event 4 type	XD	CH1 : CH64	216C : 21AB	8556 : 8619	7	R/W	С	[Decimal number: 0 to 15] 0: None 1: Deviation high (Using SV monitor value) 1 2: Deviation low (Using SV monitor value) 1 3: Deviation high/low (Using SV monitor value) 1 4: Band (Using SV monitor value) 1 5: Process high 1 6: Process low 1 7: SV high 8: SV low 9: Control loop break alarm (LBA) 10: MV high [heat-side] 1, 2 11: MV low [heat-side] 1 13: MV low [cool-side] 1 13: MV low [cool-side] 1 14: Deviation high (Using local SV value) 1 15: Deviation low (Using local SV value) 1 16: Deviation high/low (Using local SV value) 1 17: Band (Using local SV value) 1 18: Deviation between channels high 1 19: Deviation between channels low 1 20: Deviation between channels high/low 1 21: Deviation between channels band 1 Event hold action is available. If there is feedback resistance (FBR) input in position proportioning control, set to the feedback resistance (FBR) input value.	Depends on model code When not specifying: (

Continued on the next page.

No.	Name	lden- tifier		Register address		Digits	Attri-		Data range	Factory
10.			nel	HEX	DEC	- igita	bute	ture	Data range	set value
119	Event 4 channel setting	FD	CH1 : CH64	21AC : : 21EB	8620 : 8683	1	R/W	С	1: Channel 1 2: Channel 2 3: Channel 3 4: Channel 4 This function is valid when "deviation	1
		IVID	CIII	AIEG	0.004	1	D/W/		between channels"is selected.	
120	Event 4 hold action	WD	CH1 : CH64	21EC : : 222B	8684 : 8747	1	R/W	C	0: OFF 1: Hold action ON (When power turned on) 2: Re-hold action ON (When power turned on and SV changed) This function is valid when input value, deviation or manipulated value action has been selected. In case of a deviation action, this function is not available while in remote mode and while setting changing rate limiter is working.	Depends on model code When not specifying:
121	Event 4 interlock	LI	CH1 : : CH64	222C : 226B	8748 : : 8811	1	R/W	С	0: Unused 1: Used	0
122	Event 4 differential gap	HD	CH1 : CH64	226C : : 22AB	8812 : 8875	7	R/W	С	Deviation, process, set value, or Deviation action between channels: 0 to Input span (Unit: °C [°F]) MV: 0.0 to 110.0 % Becomes invalid when the Event 4 type corresponds to "9: Control loop break alarm (LBA)."	①: 1 ②: 1.0
123	Event 4 delay timer	TF	CH1 : : CH64	22AC : : 22EB	8876 : 8939	7	R/W	С	0 to 18000 seconds	0
124	Force ON of Event 4 action	OD	CH1 :: CH64	22EC :: 232B	8940 : 9003	7	R/W	С	RKC communication Least significant digit: Event output turned on at input error occurrence 2nd digit: Event output turned on in manual mode 3rd digit: Event output turned on during the autotuning (AT) function is being executed 4th digit: Event output turned on during the setting change rate limiter is being operated 5th digit to Most significant digit: Unused Data 0: Invalid 1: Valid Modbus Bit data b0: Event output turned on at input error occurrence b1: Event output turned on in manual mode b2: Event output turned on during the autotuning (AT) function is being executed b3: Event output turned on during the setting change rate limiter is being operated b4 to b15: Unused Data 0: Invalid 1: Valid [Decimal number: 0 to 15]	0

Continued on the next page.

NI -	M	lden-	Chan- Register addres			D:-:4-	Attri-	Struc-	Data range	Factory
No.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
125	CT ratio	XS	CH1 : CH64	232C : : 236B	9004 : 9067	7	R/W	С	0 to 9999	CTL-6-P-N: 800 CTL-12-S56- 10L-N:
126	CT assignment	ZF	CH1 : : CH64	236C : : 23AB	9068 : 9131	1	R/W	С	0: None 1: OUT1 2: OUT2 3: OUT3 4: OUT4	1000
127	Heater break alarm (HBA) type	ND	CH1 : CH64	23AC : : 23EB	9132 : 9195	1	R/W	С	0: Heater break alarm (HBA) type A (Time-proportional control output) 1: Heater break alarm (HBA) type B (Continuous control output and time-proportional control output)	1
128	Number of heater break alarm (HBA) delay times	DH	CH1 : : CH64	23EC : : 242B	9196 : 9259	7	R/W	С	0 to 255 times	5
129	Hot/Cold start	XN	CH1 : : CH64	242C : 246B	9260 : 9323	1	R/W	С	0: Hot start 1 1: Hot start 2 2: Cold start	0
130	Start determination point	SX	CH1 : CH64	246C : 24AB	9324 : 9387	7	R/W	С	0 to Input span (The unit is the same as input value.) (0: Action depending on the Hot/Cold start selection)	Depends on specification
131	SV tracking	XL	CH1 : : CH64	24AC : 24EB	9388 : 9451	1	R/W	С	0: Unused 1: Used	1
132	MV transfer function [Action taken when changed to Manual mode from Auto mode]	OT	CH1 : CH64	24EC : : 252B	9452 : 9515	1	R/W	С	0: MV in Auto mode is used. [Balanceless-bumpless function] 1: MV in previous Manual mode is used.	0
133	Control action	XE	CH1 : CH64	252C : 256B	9516 : 9579	1	R/W	С	O: Brilliant II PID control (Direct action) 1: Brilliant II PID control (Reverse action) 2: Brilliant II Heat/Cool PID control [Water cooling type] 3: Brilliant II Heat/Cool PID control [Air cooling type] 4: Brilliant II Heat/Cool PID control [Cooling gain linear type] 5: Position proportioning control Odd channel: From 0 to 5 can be set. Even channel: Only 0 or 1 can be set. * In heat/cool control and position proportioning control, control action is not performed. Only PV monitor and event action is performed.	Depends on model code When not specifying: 1
134	Integral/derivative time decimal point position	PK	CH1 : CH64	256C : 25AB	9580 : 9643	1	R/W	С	0: 1 second setting (No decimal place) 1: 0.1 seconds setting (One decimal place)	0
135	Derivative action	KA	CH1 : : CH64	25AC : 25EB	9644 : 9707	1	R/W	С	Neasured value derivative Deviation derivative	0

Continued on the next page.

		lden-	I	Register	address	Digits	Attri-	Struc-	Data remas	Factory
No.	Name	tifier		HEX	DEC		bute	ture	Data range	set value
136	Undershoot suppression factor	KB	CH1 : : CH64	25EC : : 262B	9708 : 9771	7	R/W	С	0.000 to 1.000	Water cooling: 0.100 Air cooling:
			СПО4	202В	9//1					0.250 Cooling gain linear type: 1.000
137	Derivative gain	DG	CH1 :: CH64	262C : 266B	9772 : 9835	7	R/W	С	0.1 to 10.0	6.0
138	ON/OFF action differential gap (upper)	IV	CH1 : CH64	266C : 26AB	9836 : 9899	7	R/W	С	TC/RTD inputs: 0 to Input span (Unit: °C [°F]) Voltage (V)/current (I) inputs:	TC/RTD: 1 V/I: 0.1
139	ON/OFF action differential gap (lower)	IW	CH1 : : CH64	26AC : : 26EB	9900 : 9963	7	R/W	С	0.0 to 100.0 % of input span	TC/RTD: 1 V/I: 0.1
140	Action (high) at input error	WH	CH1 : CH64	26EC : 272B	9964 : : 10027	1	R/W	С	O: Normal control 1: Manipulated output value at Input error	0
141	Action (low) at input error	WL	CH1 :: CH64	272C : 276B	10028 : : 10091	1	R/W	С		0
142	Manipulated output value at input error	OE	CH1 : CH64	276C : : 27AB	10092 : : 10155	7	R/W	С	-105.0 to +105.0 % Actual output values become those restricted by the output limiter. Position proportioning control: If there is no feedback resistance (FBR) input or the feedback resistance (FBR) input is disconnected, an action taken when abnormal is in accordance with the value action setting during STOP.	0.0
143	Manipulated output value at STOP mode [heat-side]	OF	CH1 : CH64	27AC : : 27EB	10156 : : 10219	7	R/W	С	-5.0 to +105.0 % Position proportioning control: Only when there is feedback resistance (FBR) input and it does not break, the	-5.0
144	Manipulated output value at STOP mode [cool-side]	OG	CH1 :: CH64	27EC : : 282B	10220 : : 10283	7	R/W	С	manipulated output value [heat-side] at STOP is output.	-5.0
145	Output change rate limiter (up) [heat-side]	PH	CH1 : CH64	282C : : 286B	10284 : : 10347	7	R/W	С	0.0 to 100.0 %/seconds (0.0: OFF) Becomes invalid when in position proportioning control.	0.0
146	Output change rate limiter (down) [heat-side]	PL	CH1 :: CH64	286C : : 28AB	10348 : : 10411	7	R/W	С	proportioning control.	0.0
147	Output limiter (high) [heat-side]	ОН	CH1 : CH64	28AC : : 28EB	10412 : : 10475	7	R/W	С	Output limiter (low) to 105.0 % Position proportioning control: Becomes valid only when there is feedback resistance (FBR) input and it does not break.	105.0
148	Output limiter (low) [heat-side]	OL	CH1 : CH64	28EC : : 292B	10476 : : 10539	7	R/W	С	-5.0 % to Output limiter (high) Position proportioning control: Becomes valid only when there is feedback resistance (FBR) input and it does not break.	-5.0

Continued on the next page.

No.	Nome	lden-	Chan-	Register address		Dicita	Attri-	Struc-	Data range	Factory
NO.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
149	Output change rate limiter (up)	PX	CH1 :	292C :	10540 :	7	R/W	С	0.0 to 100.0 %/seconds (0.0: OFF)	0.0
	[cool-side]		CH64	296B	10603				Becomes invalid when in position proportioning control.	
150	Output change rate limiter (down) [cool-side]	PY	CH1 : : CH64	296C : 29AB	10604 : 10667	7	R/W	С		0.0
151	Output limiter (high) [cool-side]	OX	CH1 :	29AC	10668	7	R/W	С	Output limiter (low) [cool-side] to 105.0 %	105.0
	*		CH64	29EB	10731					
152	Output limiter (low) [cool-side]	OY	CH1 :	29EC :	10732	7	R/W	С	-5.0 % to Output limiter (high) [cool-side]	-5.0
153	AT bias	GB	CH64 CH1	2A2B 2A2C	10795 10796	7	R/W	С	-Input span to +Input span	0
133	AT that	GB	: : : :	2A2C : : 2A6B	10790	,	IV W	C	-input span to +input span	V
154	AT cycles	G3	CH1 : CH64	2A6C : 2AAB	10860 : : 10923	1	R/W	С	0: 1.5 cycles 1: 2.0 cycles 2: 2.5 cycles 3: 3.0 cycles	1
155	Output value with AT turned on	OP	CH1 :	2AAC :	10924	7	R/W	С	Output value with AT turned off to +105.0 %	105.0
	*		CH64	2AEB	10987				Actual output values become those restricted by the output limiter. Position proportioning control: Becomes valid only when there is feedback resistance (FBR) input and it does not break (high limit of feedback resistance input at AT).	
156	Output value with AT turned off	OQ	CH1 : CH64	2AEC : : 2B2B	10988 : 11051	7	R/W	С	-105.0 % to Output value with AT turned on Actual output values become those restricted by the output limiter. Position proportioning control: Becomes valid only when there is feedback resistance (FBR) input and it does not break (low limit of feedback resistance input at AT).	-105.0
157	AT differential gap time	GH	CH1 : : CH64	2B2C : 2B6B	11052 : 11115	7	R/W	С	0.0 to 50.0 seconds	10.0
158	Proportional band adjusting factor [heat-side]	KC	CH1 :	2B6C :	11116 :	7	R/W	С	0.01 to 10.00 times	1.00
	*		CH64	2BAB	11179					
159	Integral time adjusting factor [heat-side]	KD	CH1 : : CH64	2BAC : 2BEB	11180 : 11243	7	R/W	С	0.01 to 10.00 times	1.00
	*									
160	Derivative time adjusting factor [heat-side]	KE	CH1 : : CH64	2BEC : 2C2B	11244 : : 11307	7	R/W	С	0.01 to 10.00 times	1.00
161	*	KF				7	R/W	C	0.01 to 10.00 times	1.00
161	Proportional band adjusting factor [cool-side]	K.F	CH1 : : CH64	2C2C : 2C6B	11308 : 11371	/	K/W	С	0.01 to 10.00 times	1.00

Continued on the next page.

		lden-	Chan-	Register address			Attri-	Struc-		Factory
No.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
162	Integral time adjusting factor	KG	CH1 :	2C6C :	11372	7	R/W	С	0.01 to 10.00 times	1.00
	[cool-side] ♣		CH64	2CAB	11435					
163	Derivative time adjusting factor [cool-side]	KH	CH1 :	2CAC :	11436 :	7	R/W	С	0.01 to 10.00 times	1.00
	♣		CH64	2CEB	11499					
164	Proportional band limiter (high) [heat-side]	P6	CH1 :	2CEC :	11500 :	7	R/W	С	TC/RTD inputs: 0 (0.0) to Input span (Unit: °C [°F])	TC/RTD: Input span
			CH64	2D2B	11563				Varies with the setting of the decimal point position selection.	V/I: 1000.0
165	Proportional band limiter (low)	P7	CH1 :	2D2C :	11564 :	7	R/W	С	Voltage (V)/current (I) inputs: 0.0 to 1000.0 % of input span	TC/RTD:
	[heat-side] ∕		CH64	2D6B	11627				0 (0.0): ON/OFF action (ON/OFF action for both heat and cool actions in case of a heat/cool control type.)	0 (0.0) V/I: 0.0
166	Integral time limiter (high) [heat-side]	16	CH1	2D6C	11628	7	R/W	С	PID control or heat/cool PID control:	3600
	(mgn) [neat-side]		: CH64	2DAB	11691				0 to 3600 seconds or 0.0 to 1999.9 seconds	
167	Integral time limiter (low) [heat-side]	I7	CH1 :	2DAC :	11692 :	7	R/W	С	Position proportioning control: 1 to 3600 seconds or 0.1 to 1999.9 seconds	PID control, Heat/cool PID
	*		CH64	2DEB	11755				Varies with the setting of the integral/derivative time decimal point position selection.	control: 0 Position proportioning control: 1
168	Derivative time limiter (high) [heat-side]	D6	CH1 :	2DEC :	11756	7	R/W	С	0 to 3600 seconds or 0.0 to 1999.9 seconds	3600
	*		CH64	2E2B	11819				Varies with the setting of the	
169	Derivative time limiter (low)	D7	CH1 :	2E2C	11820 :	7	R/W	С	integral/derivative time decimal point position selection.	0
	[heat-side]		СН64	2E6B	11883				position selection.	
170	Proportional band limiter (high)	P8	CH1 :	2E6C :	11884 :	7	R/W	С	TC/RTD inputs: 1(1.0) to Input span	TC/RTD: Input span
	[cool-side]		CH64	2EAB	11947				(Unit: °C [°F]) Varies with the setting of the decimal	V/I: 1000.0
171	Proportional band limiter (low)	P9	CH1	2EAC	11948	7	R/W	С	point position selection.	TC/RTD:
	[cool-side]		СН64	2EEB	12011				Voltage (V)/current (I) inputs: 0.1 to 1000.0 % of input span	1 (0.1) V/I: 0.1
172	Integral time limiter (high) [cool-side]	I8	CH1 :	2EEC :	12012 :	7	R/W	С	0 to 3600 seconds or 0.0 to 1999.9 seconds	3600
	*		CH64	2F2B	12075				Varies with the setting of the	
173	Integral time limiter (low) [cool-side]	19	CH1 :	2F2C :	12076 :	7	R/W	С	integral/derivative time decimal point position selection.	0
	*		CH64	2F6B	12139				If control is other than heat/cool PID control, set to RO (Only reading data is possible).	
174	Derivative time limiter (high)	D8	CH1 :	2F6C :	12140 :	7	R/W	С	0 to 3600 seconds or 0.0 to 1999.9 seconds	3600
	[cool-side] ♣		СН64	2FAB	12203				Varies with the setting of the integral/derivative time decimal point	
175	Derivative time limiter (low)	D9	CH1 :	2FAC	12204	7	R/W	С	position selection. If control is other than heat/cool PID	0
	[cool-side]		CH64	2FEB	12267				control, set to RO (Only reading data is possible).	

Continued on the next page.

No.	Nama	lden-	Chan-	Register	address	Diate	Attri-	Struc-	Data vanas	Factory
ΝО.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
176	Open/Close output neutral zone	V2	CH1 :	2FEC :	12268	7	R/W	С	0.1 to 10.0 %	2.0
	*		CH64	301C	12331					
177	Action at feedback	SY	CH1	302C	12332	1	R/W	С	0: Action depending on the valve	0
	resistance (FBR) input		:	:	:				action at STOP 1: Control action continued	
	error		CH64	306B	12395				1: Control action continued	
178	Feedback adjustment	FV	CH1 :	306C :	12396 :	1	R/W	С	0: Adjustment end 1: Open-side adjustment start 2: Close-side adjustment start	_
170	G + 1 + +:	TNI	CH64	30AB	12459	7	D/III		Ÿ	10
179	Control motor time	TN	CH1 :	30AC :	12460	7	R/W	С	5 to 1000 seconds	10
100	T	O.T.	CH64	30EB	12523	-	D/III		0.0 + 200.0 0/ 5 + 1 + + +	
180	Integrated output limiter	OI	CH1 :	30EC :	12524	7	R/W	С	0.0 to 200.0 % of control motor time (0.0: OFF) Becomes invalid when there is feedback	150.0
	7		CH64	312B	12587				resistance (FBR) input.	
181	Valve action at STOP	VS	CH1 : CH64	312C : 316B	12588 : 12651	1	R/W	С	0: Close-side output OFF, Open-side output OFF 1: Close-side output ON, Open-side output OFF 2: Close-side output OFF, Open-side output ON	0
									Becomes valid when there is no feedback resistance (FBR) input or the feedback resistance (FBR) input is disconnected.	
182	ST proportional band adjusting factor	KI	CH1 :	316C :	12652	7	R/W	С	0.01 to 10.00 times	1.00
102		1/ 1	CH64	31AB	12715	7	D/W/	C	0.01 +- 10.00 +:	1.00
183	ST integral time adjusting factor	KJ	CH1 :	31AC :	12716	7	R/W	С	0.01 to 10.00 times	1.00
184	ST derivative time	KK	CH64 CH1	31EB 31EC	12779 12780	7	R/W	С	0.01 to 10.00 times	1.00
104	adjusting factor	KK	:	:	:	,	K/W	C	0.01 to 10.00 times	1.00
185	ST start condition	SU	CH64 CH1	322B 322C	12843 12844	1	R/W	С	0: Activate the startup tuning (ST)	0
103	*	50	: CH64	326B	12907	1	IC W	C	function when the power is turned on; when transferred from STOP to RUN; or when the set value (SV) is changed. 1: Activate the startup tuning (ST) function when the power is turned on; or when transferred	v
									from STOP to RUN. 2: Activate the startup tuning (ST) function when the set value (SV) is changed.	
186	Automatic temperature rise group	Y7	CH1 : : CH64	326C : 32AB	12908 : 12971	7	R/W	С	0 to 16 (0: Automatic temperature rise function OFF)	0
187	Automatic temperature rise dead time	RT	CH1 :	32AC :	12971	7	R/W	С	0.1 to 1999.9 seconds	10.0
	*		CH64	32EB	13035					
188	Automatic temperature rise gradient data	R2	CH1 :	32EC :	13036 :	7	R/W	С	0.1 to Input span/minutes	
	*		CH64	332B	13099					
189	EDS transfer time decimal point position	NS	CH1 :	332C :	13100	1	R/W	С	0: 1 second setting (No decimal place)	0
	*		CH64	336B	13163				1: 0.1 seconds setting (One decimal place)	

Continued on the next page.

M.	N -	lden-	Chan-	Register	address	D:	Attri-	Struc-	D. C.	Factory
No.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
190	Output average processing time for	NV	CH1 :	336C :	13164 :	7	R/W	С	0.1 to 200.0 seconds	1.0
	EDS		СН64	33AB	13227					
191	Responsive action trigger point for EDS	NW	CH1 :	33AC :	13228 :	7	R/W	С	TC/RTD inputs: 0 (0.0) to Input span (Unit: °C [°F])	TC/RTD: 1 (1.0)
	•		CH64	33EB	13291				Varies with the setting of the decimal point position selection. Voltage (V)/current (I) inputs: 0.0 to Input span (Unit: %)	V/I: 1.0
192	Setting change rate limiter unit time	HU	CH1 :	33EC :	13292 :	7	R/W	С	1 to 3600 seconds	60
			CH64	342B	13355					
193	Soak time unit	RU	CH1 : CH64	342C : : 346B	13356 : 13419	7	R/W	С	RKC communication 0: 0:00 to 99:59 (hrs:min) [0 hours 00 minutes to 99 hours 59 minutes] 1: 0:00 to 199:59 (min:sec) [0 minutes 00 seconds to 199 minutes 59 seconds] Modbus 0: 0 to 5999 minutes [0 hours 00 minutes to 99 hours 59 minutes] 1: 0 to 11999 seconds [0 minutes 00 seconds to 199 minutes 59 seconds] Set the data range of Memory area soak time monitor and Area soak time.	1
194	Setting limiter (high)	SH	CH1	346C	13420	7	R/W	C	Setting limiter (low) to	Input scale
			: CH64	: 34AB	: 13483				Input scale high	high
195	Setting limiter (low)	SL	CH1 : : CH64	34AC : 34EB	13484 : 13547	7	R/W	С	Input scale low to Setting limiter (high)	Input scale low
196	PV transfer function	TS	CH1 :	34EC :	13548 :	1	R/W	С	0: Unused 1: Used	0
197	Operation mode assignment 1 (Logic output selection function) Logic output 1 to 4	EA	CH64 CH1 : CH64	352B 352C : 356B	13611 13612 : : 13675	7	R/W	С	0: No assignment 1: Operation mode (monitor, control) 2: Operation mode (monitor, event function, control) 3: Auto/Manual 4: Remote/Local 5: Unused (Don't set this one)	0
198	Operation mode assignment 2 (Logic output selection function) Logic output 5 to 8	EB	CH1 : CH64	356C : 35AB	13676 : : 13739	7	R/W	С	0: No assignment 1: Operation mode (monitor, control) 2: Operation mode (monitor, event function, control) 3: Auto/Manual 4: Remote/Local 5: Unused (Don't set this one)	0
199	SV select function	KM	CH1 : CH64	35AC : 35EB	13740 : 13803	1	R/W	С	Remote SV function Cascade control function Ratio setting function Cascade control 2 function	0

Continued on the next page.

N.c.	Na	lden-	Chan-	Register	address	Die:#-	Attri-	Struc-	Deta	Factory
No.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
200	Remote SV function master channel module address	MC	CH1 : CH64	35EC : : 362B	13804 : 13867	7	R/W	С	-1 (Master channel is selected from itself) 0 to 99 (Master channel is selected from other modules)	-1
201	Remote SV function master channel selection	MN	CH1 : : CH64	362C : 366B	13868 : 13931	7	R/W	С	1 to 99	1
202	Output distribution master channel module address	DY	CH1 : : CH64	366C : 36AB	13932 : 13995	7	R/W	С	-1 (Master channel is selected from itself) 0 to 99 (Master channel is selected from other modules)	-1
203	Output distribution master channel selection	DZ	CH1 : : CH64	36AC : 36EB	13996 : 14059	7	R/W	С	1 to 99	1
204	Address of interacting modules	RL	CH1 : : CH64	36EC : : 372B	14060 : : 14123	7	R/W	С	-1 (Interact with its own module address) 0 to 99 (Interact with the addresses of other modules)	-1
205	Channel selection of interacting modules	RM	CH1 : : CH64	372C : 376B	14124 : 14187	7	R/W	С	1 to 99 Becomes valid when the selected module is "Z-TIO module."	1
206	Selection switch of interacting modules	RN	CH1 : CH64	376C : 37AB	14188 : 14251	7	R/W	С	RKC communication Least significant digit: Memory area number 2nd digit: Auto/Manual 4th digit: Remote/Local 5th digit EDS start signal 6th digit Interlock release Most significant digit: Suspension of area soak time Data 0: No interaction 1: Interact with other channels Modbus Bit data b0: Memory area number b1: Operation mode b2: Auto/Manual b3: Remote/Local b4: EDS start signal b5: Interlock release b6: Suspension of area soak time b7 to b15: Unused Data 0: No interaction 1: Interact with other channels [Decimal number: 0 to 127]	0
207	TIO Interval time	VG	CH1 : : CH16	37AC : 37BB	14252 : 14267	7	R/W	M	0 to 250 ms	10
208	Unused	_	_	37BC : : 386B	14268 : 14443	_	_	_	_	_

9.4 Memory Area Data Address of Z-TIO Module

The register addresses, 386CH to 3DABH are used for checking and changing each set value belonging to the memory area.

No.	Nama	Chan-	Register	address	Attri-	Struc-	Data ranga	Factory	
NO.	Name	nel	HEX	DEC	bute	ture	Data range	set value	
1	Setting memory area number	CH1 :	386C :	14444 :	R/W	С	1 to 8	1	
		CH64	38AB	14507					
2	Event 1 set value (EV1)	CH1	38AC	14508	R/W	С	Deviation action,	50	
		:	:	:			Deviation action between channels, Temperatue rise completion range:		
		CH64	38EB	14571			-Input span to +Input span		
3	Event 2 set value (EV2)	CH1	38EC	14572	R/W	С	Process action, SV action:	50	
		:	:	14625			Input scale low to Input scale high		
4	Event 3 set value (EV3)	CH64 CH1	392B 392C	14635 14636	R/W	С	MV action:	50	
4	Event 3 set value (E v 3)	EHI E	392C :	14030	K/W		-5.0 to +105.0 %	30	
		CH64	396B	14699					
5	Event 4 set value (EV4)	CH1 :	396C :	14700 :	R/W	С		50	
		CH64	39AB	14763					
6	Control loop break alarm	CH1	39AC	14764	R/W	С	0 to 7200 seconds	480	
	(LBA) time	:	:	:			(0: Unused)		
		CH64	39EB	14827					
7	LBA deadband	CH1 :	39EC :	14828	R/W	С	0 (0.0) to Input span	0 (0.0)	
		CH64	3A2B	14791					
8	Set value (SV)	CH1 :	3A2C	14892 :	R/W	С	Setting limiter (low) to Setting limiter (high)	TC/RTD: 0 V/I: 0.0	
		CH64	3A6B	14955				V/1. U.U	
9	Proportional band [heat-side]	CH1 :	3A6C :	14956 :	R/W	С	TC/RTD inputs: 0 (0.0) to Input span (Unit: °C [°F])	TC/RTD: 30 (30.0)	
		CH64	3AAB	15019			Voltage (V)/current (I) inputs: 0.0 to 1000.0 % of input span	V/I: 30.0	
							0 (0.0): ON/OFF action (ON/OFF action for both heat and cool actions in case of a heat/cool control type.)		
10	Integral time [heat-side]	CH1 :	3AAC :	15020 :	R/W	С	PID control or heat/cool PID control: 0 to 3600 seconds or 0.0 to 1999.9 seconds (0, 0.0: PD action)	240	
		CH64	3AEB	15083			Position proportioning control:		
11	Derivative time	CH1	3AEC	15084	R/W	С	1 to 3600 seconds or 0.1 to 1999.9 seconds 0 to 3600 seconds or 0.0 to 1999.9 seconds	60	
11	[heat-side]	:	:	:	IX/ W		(0, 0.0: PI action)	00	
10	C + 1	CH64	3B2B	15147	D/XI	C	0. 01	DID 1	
12	Control response parameter	CH1 :	3B2C :	15148	R/W	С	0: Slow 1: Medium	PID control, Position	
	parameter	CH64	3B6B	15211			2: Fast	proportioning control: 0	
							When the P or PD action is selected, this setting becomes invalid.	Heat/cool PID control: 2	
13	Proportional band	CH1	3B6C	15212	R/W	С	TC/RTD inputs:	TC/RTD:	
	[cool-side]	:	:	:			1 to Input span or 0.1 to Input span	30 (30.0)	
		CH64	3BAB	15275			(Unit: °C [°F]) Voltage (V)/current (I) inputs:	V/I: 30.0	
							0.1 to 1000.0 % of input span		
14	Integral time [cool-side]	CH1 :	3BAC :	15276 :	R/W	С	0 to 3600 seconds or 0.0 to 1999.9 seconds (0, 0.0: PD action)	240	
					1		/	1	

Continued on the next page.

No.	Name	Chan-	Register	address	Attri-	Struc-	Data vanas	Factory
NO.	Name	nel	HEX	DEC	bute	ture	Data range	set value
15	Derivative time [cool-side]	CH1 :	3BEC :	15340 :	R/W	С	0 to 3600 seconds or 0.0 to 1999.9 seconds (0, 0.0: PI action)	60
		CH64	3C2B	15403				
16	Overlap/Deadband	CH1 :	3C2C :	15404 :	R/W	С	TC/RTD inputs: —Input span to +Input span (Unit:°C [°F])	0
		CH64	3C6B	15467			Voltage (V)/current (I) inputs: -100.0 to +100.0 % of input span	
17	Manual reset	CH1 :	3C6C :	15468 :	R/W	С	-100.0 to +100.0 %	0.0
		CH64	3CAB	15531				
18	Setting change rate limiter (up)	CH1 :	3CAC :	15532 :	R/W	С	0 (0.0) to Input span/unit time * 0 (0.0): Unused	0 (0.0)
		CH64	3CEB	15595				
19	Setting change rate limiter (down)	CH1 :	3CEC :	15596 :	R/W	С	* Unit time: 60 seconds (factory set value)	0 (0.0)
		CH64	3D2B	15659	D ////	-		
20	Area soak time	CH1 :	3D2C :	15660 :	R/W	С	0 minutes 00 seconds to 199 minutes 59 seconds: 0 to 11999 seconds	0
		CH64	3D6B	15723			0 hours 00 minutes to 99 hours 59 minutes: 0 to 5999 minutes	
21	Link area number	CH1 :	3D6C :	15724 :	R/W	С	0 to 8 (0: No link)	0
		CH64	3DAB	15787				
22	Unused	_	3DAC	15788	_	_	_	_
			:	:				
			3E6B	15979				

9.5 Communication Data of Z-DIO Module

For details of Z-DIO module communication data, see **SRZ Instruction Manual (IMS01T04-E \Boxed**).

		lden-	Chan-	Register	address		Attri-	Struc-		Factory
No.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
1	Digital input (DI) state 1	L1	CH1 : CH16	3E6C : 3E7B	15980 : 15995	7	RO	М	RKC communication Least significant digit: D11 2nd digit: D12 3rd digit: D13 4th digit: D14 5th digit to Most significant digit: Unused Data 0: Contact open 1: Contact closed Modbus Bit data b0: D11 b1: D12 b2: D13 b3: D14 b4: D15 b5: D16 b6: D17 b7: D18 b8 to b15: Unused Data 0: Contact open 1: Contact closed [Decimal number: 0 to 255]	
2	Digital input (DI) state 2	L6	CH1 : CH16	П	_	7	RO	M	Least significant digit: DI5 2nd digit: DI6 3rd digit: DI7 4th digit: DI8 5th digit to Most significant digit: Unused Data 0: Contact open 1: Contact closed	_
3	Digital output (DO) state 1	Q2	CH1 : CH16	3E7C : 3E8B	15996 : 16011	7	RO	M	• RKC communication Least significant digit: DO1 2nd digit: DO2 3rd digit: DO3 4th digit: DO4 5th digit to Most significant digit: Unused Data 0: OFF 1: ON • Modbus Bit data b0: DO1 b1: DO2 b2: DO3 b3: DO4 b4: DO5 b5: DO6 b6: DO7 b7: DO8 b8 to b15: Unused Data 0: OFF 1: ON [Decimal number: 0 to 255]	
4	Digital output (DO) state 2	Q3	CH1 : CH16	_	_	7	RO	M	Least significant digit: DO5 2nd digit: DO6 3rd digit: DO7 4th digit: DO8 5th digit to Most significant digit: Unused Data 0: OFF 1: ON	_

Continued on the next page.

No.	Name	lden-	Chan-	Register	address	Dieite	Attri-	Struc-	Data	Factory
NO.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
5	Unused	_	_	3E8C	16012	_	_	_	_	_
				:	:					
6	DO manual output 1	Q4	CH1	3FDB 3FDC	16347 16348	7	R/W	M	RKC communication	0
O	DO manuar output 1	Q4	:	:	:		IX/ VV	IVI	Least significant digit:	0
			CH16	3FEB	16363				DO1 manual output	
									2nd digit: DO2 manual output 3rd digit: DO3 manual output	
									4th digit: DO4 manual output	
									5th digit to Most significant digit:	
									Unused Data 0: OFF 1: ON	
									• Modbus	
									Bit data	
									b0: DO1 manual output b1: DO2 manual output	
									b2: DO3 manual output	
									b3: DO4 manual output	
									b4: DO5 manual output b5: DO6 manual output	
									b6: DO7 manual output	
									b7: DO8 manual output b8 to b15: Unused	
									Data 0: OFF 1: ON	
									[Decimal number: 0 to 255]	
7	DO manual output 2	Q5	CH1	_	_	7	R/W	M	Least significant digit: DO5 manual output	0
			: CH16						2nd digit: DO6 manual output	
			CHIO						3rd digit: DO7 manual output	
									4th digit: DO8 manual output 5th digit to Most significant digit:	
									Unused	
_									Data 0: OFF 1: ON	
8	DO output distribution selection	DO	CH1 :	3FEC :	16364 :	1	R/W	С	DO output Distribution output	0
	distribution selection		CH128	406B	16491				1. Distribution curput	
9	DO output	O8	CH1	406C	16492	7	R/W	С	-100.0 to +100.0 %	0.0
	distribution bias		:	:	:					
			CH128	40EB	16619					
10	DO output distribution ratio	O9	CH1	40EC	16620	7	R/W	С	-9.999 to +9.999	1.000
	distribution ratio		: CH128	: 416B	: 16747					
11	DO proportional cycle	V0	CH1	416C	16747	7	R/W	С	0.1 to 100.0 seconds	Relay contact
	time		:	:	:	,	10		011 to 10010 500 51145	output: 20.0
			CH128	41EB	16875					Open collector output: 2.0
12	DO minimum	VJ	CH1	41EC	16876	7	R/W	С	0 to 1000 ms	0 output: 2.0
	ON/OFF time of		:	:	:	,	12 "			
	proportioning cycle		CH128	426B	17003				_	
13	Unused	_	_	426C	17004	_	_	_	_	_
				:	:					
	Sat	data N	0.14.05	433B	17211	eering	sattin	a [Write	ble in the STOP mode]	
14	DI function	H2	CH1	433C	17212	eering 7	R/W	g [writa	0 to 29	Depends on
	assignment		:	:	:	,			(see P. 71.)	model code.
			CH16	434B	17227					When not
	İ	ı	1	l	ĺ	I	1	i	l e e e e e e e e e e e e e e e e e e e	specifying:

Continued on the next page.

Nic	Name	lden-	Chan-	Register	address	Die!t-	Attri-	Struc-	Data	Factory
No.	Name	tifier	nel	HEX	DEC	Digits	bute	ture	Data range	set value
15	Memory area setting signal	E1	CH1 :	434C :	17228 :	1	R/W	M	0: Valid 1: Invalid	1
			CH16	435B	17243					
16	DO signal assignment	LQ	CH1	435C	17244	7	R/W	M	-1, 0 to 99	-1
	module address 1 [DO1 to DO4]		: CH16	: 436B	: 17259				When "-1" is selected, all of the signals of the same type (except temperature rise completion and DO manual output value) are <i>OR</i> -operated and produced as outputs from DO.	
17	DO signal assignment	LR	CH1	436C	17260	7	R/W	M	-1, 0 to 99	-1
	module address 2 [DO5 to DO8]		: CH16	: 437B	17275				When "-1" is selected, all of the signals of the same type (except temperature rise completion and DO manual output value) are <i>OR</i> -operated and produced as outputs from DO.	
18	DO output	LT	CH1	437C	17276	7	R/W	M	0 to 13	Depends on
	assignment 1		:	:	:				(see P. 72 .)	model code.
	[DO1 to DO4]		CH16	438B	17291					When not specifying:
19	DO output assignment 2	LX	CH1 :	438C	17292	7	R/W	M	0 to 13 (see P. 72 .)	Depends on model code.
	[DO5 to DO8]		CH16	439B	17307					When not specifying:
20	DO energized/de-energized	NB	CH1 :	439C :	17308	7	R/W	С	0: Energized 1: De-energized	0
21	DO output distribution	DD	CH128 CH1	441B 441C	17435 17436	7	R/W	С	-1	-1
21	master channel module address	DD	:	:	:	,	10 **		(Master channel is selected from itself)	_1
	444		CH128	449B	17563				0 to 99 (Master channel is selected from other modules)	
22	DO output distribution master channel	DJ	CH1 :	449C :	17564 :	7	R/W	С	1 to 99	1
	selection		CH128	451B	17691					
23	DO manipulated output value (MV) at STOP mode	OJ	CH1 :	451C :	17692 :	7	R/W	С	-5.0 to +105.0 %	-5.0
24		D3	CH128 CH1	459B 459C	17819 17820	7	R/W	С	DO output limiter (low) to 105.0 %	105.0
24	DO output limiter (high)	D3	: CH128	439C : : 461B	17820	,	K/W		DO output limiter (low) to 103.0 %	105.0
25	DO output limiter	D4	CH1	461C	17947	7	R/W	С	-5.0 % to DO output limiter (high)	-5.0
	(low)		: CH128	469B	18075	,	15 ,,		2 / v to 2 o cusput minter (mgn)	2.0
26	Z-DIO Interval time	VF	CH128	469C	18076	7	R/W	M	0 to 250 ms	10
20	2 Dio mervar time	*1	:	:	:	,	10 **	141	0 to 250 ms	10
27	Unused	_	CH16	46AB 46AC	18091 18092	_		_	_	_
				: 46BB	: 18107					

Table 1: DI assignment table

Set value	DI1	DI2	DI3	DI4	DI5	DI6	DI7	DI8
0				No a	ssignment			
1								AUTO/MAN ⁴
2								REM/LOC ⁴
3							Interlock release	EDS start signal 1
4								Soak stop
5								RUN/STOP ⁴
6								REM/LOC ⁴
7							AUTO/MAN ⁴	EDS start signal 1
8					Operatio	n mode ³		Soak stop
9								RUN/STOP ⁴
10								EDS start signal 1
11							REM/LOC ⁴	Soak stop
12								RUN/STOP ⁴
13	M	lemory area transfer (1 to 8) ¹	Area set 2			EDS start signal 1	Soak stop
14							ED3 start signal 1	RUN/STOP ⁴
15							Soak stop	KON/310F
16								EDS start signal 1
17							REM/LOC ⁴	Soak stop
18					Interlock release	AUTO/MAN ⁴		RUN/STOP 4
19							EDS start signal 1	Soak stop
20							LDO start signar i	RUN/STOP ⁴
21							Soak stop	110140101
22							EDS start signal 1	Soak stop
23					AUTO/MAN	REM/LOC	250 otal roighair.	
24							Soak stop	RUN/STOP 4
25					REM/LOC	EDS start signal 1	coun stop	
26	Memory area transfer (1, 2) ¹	Area set ²	Interlock release	RUN/STOP 4	AUTO/MAN 4	REM/LOC ⁴	Operatio	n mode ³
27	Men	nory area transfer (1 to	8) 1	Area set 2	Operatio	n mode ³	EDS start signal 1	
28	Memory area transfer (1, 2) 1	Area set ²	Interlock release	RUN/STOP 4	AUTO/MAN ⁴	AUTO/MAN 4 REM/LOC 4		EDS start signal 2
29	EDS start signal 1	EDS start signal 2					Operation mode ³	

RUN/STOP: RUN/STOP transfer (Contact closed: RUN)
AUTO/MAN: Auto/Manual transfer (Contact closed: Manual mode)
REM/LOC: Remote/Local transfer (Contact closed: Remote mode)
Interlock release (Interlock release when rising edge is detected)
EDS start signal 1 (EDS start signal ON when rising edge is detected [for disturbance 1])
EDS start signal 2 (EDS start signal ON when rising edge is detected [for disturbance 2])
Soak stop (Contact closed: Soak stop)

DI signal will become valid at rising edge after the closed contact is held for 250 ms. 250 ms or more Contact closed (Rising edge) Contact open

¹ Memory area transfer

(x:Contact open -: Contact closed)

		Memory area number									
	1 2 3 4 5 6 7 8										
DI1	×	-	×	-	×	-	×	-			
DI2	×	×	-	-	×	×	_	_			
DI3	×	×	×	×	-	_	_	_			

² Area set becomes invalid prior to factory shipment.

(x:Contact open -: Contact closed)

	Operation mode										
	Unused	Monitor	Monitor + Event function	Control							
DI5 (DI7)	×	-	×	_							
DI6 (DI8)	×	×	-	_							

⁴ Actual device states (AUTO/MAN, REM/LOC, RUN/STOP)

	DI-switched state	Communication-switched state	Actual device state	
	Manual (Contact closed)	Manual → Auto	Manual mode	
Auto/Manual transfer a	Manual (Contact closed)	Auto → Manual	Manual mode	
(AUTO/MAN)	Auto (Contact open)	Manual → Auto	Auto mode	
	Auto (Contact open)	Auto → Manual	Auto mode	
	Remote (Contact closed)	Remote → Local	Remote mode	
Remote/Local transfer ^a	Remote (Contact closed)	Local → Remote	Remote mode	
(REM/LOC)	Local (Contact open)	Remote → Local	Local mode	
	Local (Contact open)	Local → Remote	Local mode	
	RUN (Contact closed)	$STOP \rightarrow RUN$	RUN	
RUN/STOP ^b	KON (Contact closed)	$RUN \rightarrow STOP$	STOP	
	STOP (Contact open)	$STOP \rightarrow RUN$	STOP	

^a Device state when AUTO/MAN or REM/LOC assigned to DI is set so that the Z-TIO module and Z-DIO module are linked using the Master-slave mode of the Z-TIO module.

³ Operation mode transfer

^b STOP of RUN/STOP switching is given priority regardless of communication or DI switching.

Table 2: DO assignment table

[DO1 to DO4]

Set value	DO1	DO2	DO3	DO4
0		No assignment		
1	DO1 manual output	DO2 manual output	DO3 manual output	DO4 manual output
2	Event 1 comprehensive output 1	Event 2 comprehensive output 2	Event 3 comprehensive output 3	Event 4 comprehensive output 4
3	Event 1 (CH1)	Event 2 (CH1)	Event 3 (CH1)	Event 4 (CH1)
4	Event 1 (CH2)	Event 2 (CH2)	Event 3 (CH2)	Event 4 (CH2)
5	Event 1 (CH3)	Event 2 (CH3)	Event 3 (CH3)	Event 4 (CH3)
6	Event 1 (CH4)	Event 2 (CH4)	Event 3 (CH4)	Event 4 (CH4)
7	Event 1 (CH1)	Event 1 (CH2)	Event 1 (CH3)	Event 1 (CH4)
8	Event 2 (CH1)	Event 2 (CH2)	Event 2 (CH3)	Event 2 (CH4)
9	Event 3 (CH1)	Event 3 (CH2)	Event 3 (CH3)	Event 3 (CH4)
10	Event 4 (CH1)	Event 4 (CH2)	Event 4 (CH3)	Event 4 (CH4)
11	HBA (CH1)	HBA (CH2)	HBA (CH3)	HBA (CH4)
12	Burnout status (CH1)	Burnout status (CH2)	Burnout status (CH3)	Burnout status (CH4)
13	Temperature rise completion 5	HBA comprehensive output 6	Burnout state comprehensive output 7	DO4 manual output

[DO5 to DO8]


003 10 000	ני			
Set value	DO5	DO6	DO7	DO8
0		No assignment		
1	DO5 manual output	DO6 manual output	DO7 manual output	DO8 manual output
2	Event 1 comprehensive output 1	Event 2 comprehensive output 2	Event 3 comprehensive output 3	Event 4 comprehensive output 4
3	Event 1 (CH1)	Event 2 (CH1)	Event 3 (CH1)	Event 4 (CH1)
4	Event 1 (CH2)	Event 2 (CH2)	Event 3 (CH2)	Event 4 (CH2)
5	Event 1 (CH3)	Event 2 (CH3)	Event 3 (CH3)	Event 4 (CH3)
6	Event 1 (CH4)	Event 2 (CH4)	Event 3 (CH4)	Event 4 (CH4)
7	Event 1 (CH1)	Event 1 (CH2)	Event 1 (CH3)	Event 1 (CH4)
8	Event 2 (CH1)	Event 2 (CH2)	Event 2 (CH3)	Event 2 (CH4)
9	Event 3 (CH1)	Event 3 (CH2)	Event 3 (CH3)	Event 3 (CH4)
10	Event 4 (CH1)	Event 4 (CH2)	Event 4 (CH3)	Event 4 (CH4)
11	HBA (CH1)	HBA (CH2)	HBA (CH3)	HBA (CH4)
12	Burnout status (CH1)	Burnout status (CH2)	Burnout status (CH3)	Burnout status (CH4)
13	Temperature rise completion 5	HBA comprehensive output ⁶	Burnout state comprehensive output 7	DO8 manual output

¹ Logical *OR* of Event 1 (ch1 to ch4)
2 Logical *OR* of Event 2 (ch1 to ch4)
3 Logical *OR* of Event 3 (ch1 to ch4)
4 Logical *OR* of Event 4 (ch1 to ch4)
5 Temperature rise completion status (ON when temperature rise completion.)
6 Logical *OR* of HBA (ch1 to ch4)
7 Logical *OR* of burnout state (ch1 to ch4)

10. USAGE EXAMPLE


This chapter describes an usage example of EtherNet/IP communication when connected with the COM-ML and controller (SRZ) with the PLC set to a scanner or client.

10.1 Handling Procedures



10.2 System Configuration

The example given in this section is based on the system configuration below.



Loader communication is used for the initial communication data settings.

■ Devices used

• EtherNet/IP communication converter: COM-ML................ 1

• Controller (SRZ): Z-TIO module...... 2 (4-channel type)

• Programmable controller (PLC)

ControlLogix 5555 (Rockwell Automation)

• USB communication converter: COM-K2 (for loader communication)

- Network hub
- Various cables
- Personal computer

RSLogix 5000 and RSLinx Classic Lite (RSLinx Classic is also acceptable) programming software (Rockwell Software) must be installed.

10.3 Use Instruments Settings

■ COM-ML setting

There is not the setting of the hardware.

In this example the initial settings for COM-ML communication data are configured using loader communication, and thus COM-ML host communication settings are not necessary.

■ Controller (SRZ) setting

The COM-ML and controllers (Z-TIO modules) are connected by internal communication, and settings for the Z-TIO modules such as communication speed, protocol, and data bit configuration are not necessary. The only setting that is configured for the controllers is the module address. The same is true when a Z-DIO module is used.

- Module address: Z-TIO module: 1, 2
- For the procedure for module address settings, see **Z-TIO Host Communication Quick Instruction Manual (IMS01T02-E□)** or **Z-DIO INSTRUCTION MANUAL (IMS01T03-E□)**.

■ PLC setting

There is not the setting of the hardware. Use programming software to configure EtherNet/IP settings.

For details, see 10.5 Tool Settings (P. 76).

10.4 Initial Communication Data Settings

Use loader communication to configure the initial communication data settings.

[Set values]

- IP address of COM-ML: 192.168.1.3
- EtherNet/IP communication settings:

Measured data items (IN): Measured value (PV) [4 channels \times 2 = 8 channels]

Set value (SV) [4 channels \times 2 = 8 channels]

Setting data items (OUT): Set value (SV) [4 channels \times 2 = 8 channels]

Assigned destination of communication item:

Measured value (PV): Attribute 100 Set value (SV): Attribute 101

• Other communication data: Set other required items.

For the setting procedures, see 7. INITIAL COMMUNICATION DATA SETTINGS (P. 26).
For information on each communication item, see 9. COMMUNICATION DATA LIST (P. 38).


10.5 Tool Settings

The RSLogix 5000 and RSLinx Classic Lite (or RSLinx Classic) programming software are used to configure the various settings.


■ EtherNet/IP module driver settings

Set the IP address of the EtherNet/IP module (1756-ENBT) used to connect the PLC to EtherNet/IP, and register the driver.

1. Start RSLinx Classic Lite.



- 2. Select "Configure Drivers" from "Communications" in the menu bar.
- 3. Select "Ethernet devices" in "Available Driver Types:" in the "Configure Drivers" window.



4. Click the [Add New] button to display "Add New RSLinx Classic Driver."

The driver name can be entered here; however, the displayed name "AB_ETH-1" will be used, so simply click [OK].




5. In "Station Mapping" in the "Configure drivers: AB_ETH-1" window, enter the IP address of the EtherNet/IP module and click [OK].

In this example, the IP address of the EtherNet/IP module is set to "192.168.1.2."



6. The "AB_ETH-1" driver of the EtherNet/IP module is added to "Configured Driver:" of the "Configure Drivers" window.



■ Creating a new project

To build the system of this example in the RSLogix 5000 programming software, create a new project.

1. Start the RSLogix 5000 programming software.




2. Select "New" from the "File" in the menu bar to open the "New Controller" window and create a new project. Configure the following settings in "New Controller."


Type: 1756-L55 (CPU module type) Revision: 13 (CPU module version)

Name: Test (Project name) Chassis Type: 1756-A4 (Chassis type)


Slot: 0 (Chassis slot number where CPU module is inserted)



- 3. Click [OK] to store the project settings.
- 4. Set the path of the CPU module in the test project window. Click "Path" at the upper right of the screen to display the "Who Active" window.



5. Select CPU module "1756-L55" and click the [Set Project Path] button.




6. Click the [Close] button to store the path that is selected in "Path" on the test project screen.




■ EtherNet/IP module settings

Add an EtherNet/IP module to the project.


1. Select "I/O Configuration" from the tree on the left side of the test project screen and right-click "New Module."



2. The "Select Module Type" window will open. Select EtherNet/IP module "1756-ENBT" and click [OK].



3. The "Select Major Revision" window will open. Enter the current version number (Major Revision) of the EnterNet/IP module and click [OK].




4. The "Module Properties" window will open. Set the name of the EtherNet/IP module, the IP address, the chassis slot number, and the version number (2nd digit).

In this example, the "Module Properties" is set as follows:

Name: EtherNet_IP_module

IP address: 192.168.1.2

Slot: 2 Revision: 1




5. Click the [Finish] button to store the EtherNet/IP module settings.


■ COM-ML settings

Add a COM-ML to the project.

1. Right-click "1756-ENBT/A" under "I/O Configuration" in the tree at the left side of the test project screen and select "New Module."



2. The "Select Module Type" window will open. Select "ETHERNET-MODULE" and click [OK].



3. The "Module Properties" window will open. Set the name of the ETHERNET-MODULE, the data format, and the IP address.

Configure the I/O communication settings (Connection Parameters).

Set the assembly object instance numbers and the total data sizes of measured data items (IN) and setting data items (OUT) in "Assembly Instance" and "Size" of "Input" and "Output."

In the case of I/O communication, data is sent and received using the "Assembly object (0x04: 04Hex)" object model. Measurement items (IN) use attribute 3 of instance 100, and setting items (OUT) use attribute 3 of instance 101.

Continued on the next page.

In this example, the "Module Properties" is set as follows:


Name: COM_ML Comm Format: Data - INT IP Address: 192.168.1.3 Connection Parameters

Input: Assembly Instance: 100

Size: 16 [Measured value (PV): 8 channels + Set value (SV): 8 channels = 16]

Output: Assembly Instance: 101


Size: 9 [Setting state change (1 word) * + Set value (SV): 8 channels = 9] * Always assigned to setting data item (OUT).



4. Click the [Next] button to display the next page.

Set the "Requested Packet Interval (RPI)," which is the interval between message responses in I/O communication.

In this example, "Requested Packet Interval (RPI)" is set to 100.0 ms.




5. Click the [Finish] button to store the COM-ML settings.

This completes the configuration of the initial settings using the tool.


10.6 I/O Communication

This section explains how to execute I/O communication and check data.

1. Click "Off line" at the upper left of the test project screen and select "Go Online" in the sub-menu.



2. The "Connect To Go Online" window will open. Click the [Download] button. A confirmation window will appear. Click the [Download] button again.




3. "Off line" at the upper left of the test project screen will change to "Rem Run," and I/O communication will be executed. If communication is normal, the display to the right of "Rem Run" will change to Run Mode, Controller OK, Battery OK, and I/O OK.



4. Select "Controller Tags" under "Controller Test" in the tree at the left side of the test project screen. "COM_ML: I" in Monitor Tags at the right side of the screen shows the measured data items (IN) data.

Values of COM_ML: I. Data [0] to [7]: Data of measured value (PV) channels 1 to 8.

Values of COM ML: I. Data [8] to [15]: Data of set value (SV) channels 1 to 8.




Data of measured value (PV) channels 1 to 8

5. "COM_ML: O" in Monitor Tags at the right side of the screen shows the set value (OUT) data. The Value cell of any data can be clicked to change the set value.

Value of COM ML: O. Data [0]: Setting state change data

Values of COM ML: O. Data [1] to [8]: Data of set value (SV) channels 1 to 8



Data of set value (SV) channels 1 to 8

Setting state change data

0: Data setting enable


1: Data setting disable

10.7 Explicit Message Communication

An example of using explicit message communication to set the value of set value (SV) channel 2 to "200" is shown below.


■ Creating a ladder program

To send an explicit message, create a program similar to the program below.




1. Register the "Exp_enb" relay (contact a), which is the trigger for explicit message transmission, ahead of time in "Tasks" → "Main Task" → "Main Program" → "Program Tags" in the tree at the left side of the test project screen.

In this example, the Tag Name is "Exp enb" and the Type is "BOOL."




2. Store "Message" in Edit Tags of "Controller Test" → "Controller Tags" in the tree at the left side of the test project screen.

In this example, "Message" is entered for the Tag Name under "COM_ML: O" of I/O communication, and "MESSAGE" is selected for the Type.



3. Create the program in the screen that appears when "Tasks" → "Main Task" → "Main Program" → "Main Routine" is selected in the tree on the left side of the test project screen.



4. Edit the commands in the screen using the icons.

After assigning MSG, click ... in the MSG frame to set the "Message Configuration."

In this example, the "Message Configuration" is set as follows:


Message Type: CIP Generic

Service Type: Set Attribute Single

Class: 64 Hex Instance: 2 Attribute: 65 Hex


Source Element: Set Value

Source Length: 2




5. Click the [New Tag] button in the same screen to store the "Set_Value" of Source Element.


The "New Tag" window will open, specify "Set_Value" for the name and select "INT" for the Data Type.



6. Set the path in the Communication tag of the Message Confirmation window.
Click the [Browse] button and select "ETHERNET-MODULE COM_ML" in the Message Path Browser window.



7. After the "Exp_enb" relay, connect the Message output EN using contact b. This completes the program.




Running the program

In the program that was created for explicit message communication, set the value of channel 2 of the set value (SV) to "200."

- Follow steps 1 and 2 of 10.6 I/O Communication (P. 84) to download the ladder program that was created.
- 2. In Monitor Tags of "Controller Test" → "Controller Tags" in the tree at the left side of the test project screen, set the value of "Set Value" to "200."



3. Set the value of "Exp_enb [0]" to "1" in "Tasks" → "Main Task" → "Main Program" → "Program Tags" in the tree at the left side of the test project screen. Explicit message communication will be executed, and the value of set value (SV) channel 2 will be "200."



11. TROUBLESHOOTING

This section explains probable causes and treatment procedures if any abnormality occurs in the instrument. For any inquiries, please contact RKC sales office or the agent, to confirm the specifications of the product.

If it is necessary to replace a device, always strictly observe the warnings below.

⚠ WARNING

- To prevent electric shock or instrument failure, always turn off the system power before replacing the instrument.
- To prevent electric shock or instrument failure, always turn off the power before mounting or removing the instrument.
- To prevent electric shock or instrument failure, do not turn on the power until all the wiring is completed. Make sure that the wiring is correct before applying power to the instrument.
- To prevent electric shock or instrument failure, do not touch the inside of the instrument.
- All wiring must be performed by authorized personnel with electrical experience in this type of work.

♠ CAUTION

All wiring must be completed before power is turned on to prevent electric shock, instrument failure, or incorrect action.



When replacing the module with a new one, always use the module with the same model code. If the module is replaced, it is necessary to re-set each data item.

■ COM-ML

Problem	Probable cause	Solution	
FAIL/RUN lamp does not	Power not being supplied	Check external breaker etc.	
light up	Appropriate power supply voltage not being supplied	Check the power supply	
	Power supply terminal contact defect	Retighten the terminals	
	Power supply section defect	Replace COM-ML	
The FAIL/RUN lamp flashes (green)	Changing to the IP address default setting is in progress	When the power is turned on after the IP address default setting is enabled in the DIP switches, this lamp flashes for about 5 seconds. After flashing, the lamp automatically changes to solid green. At this point, the IP address becomes the factory set value.	
The FAIL/RUN lamp flashes (green): Recoverable fault occur	Data backup error (Error code 2) EEPROM read/write error	Turn off the power to the instrument. If the same error occurs when the power is turned back on, please contact RKC sales office or the agent.	
	Stack overflow (Error code 64) Runaway of the program, etc.	sures office of the agent.	
	Network module error (Error code 512) Operational failure of the network module in the COM-ML	Confirm the wiring, remove the noise, and turn off the power to the instrument. If the same error occurs when the power is turned back on, please contact RKC sales office or the agent.	
The FAIL/RUN lamp flashes (red): Major fault occur	RAM value abnormal Power suooly voltage monitoring error Watchdog timer error	Turn off the power to the instrument. If the same error occurs when the power is turned back on, please contact RKC sales office or the agent.	

■ EtherNet/IP

Problem	Probable cause	Solution
An IP address cannot be	DHCP selection is invalid	Enable DHCP selection
acquired by DHCP	Problem on the network	Consult your network administrator.
No response	Wrong connection, no connection or disconnection of the communication cable	Confirm the connection method or condition and connect correctly
	Breakage, wrong wiring, or imperfect contact of the communication cable	Confirm the wiring or connector and repair or replace the wrong one
	IP address acquisition by DHCP is enabled and the IP address changes each time the device connects to the network	Set the fixed IP address
	Wrong IP address setting	Confirm the settings and set them correctly
NS lamp: OFF MS lamp: ON (green)	An invalid IP address is being used	Confirm the settings and set them correctly
NS lamp: Flashs (green) MS lamp: ON (green)	Online, no communication established	Confirm the I/O communication settings and set them correctly
NS lamp: Flashs (red) MS lamp: ON (green)	I/O connection is timeout	Confirm the wiring or condition of scanner side and connect correctly
NS lamp: ON (red) MS lamp: ON (green)	Duplicate IP address	Restart after the resetting is made so that IP address is not duplicated
MS lamp: Flashs (green)	Do not use connection type message in explicit message communication	Confirm the setting of scanner side and set them correctly
MS lamp: Flashs (red)	Duplication of the IP address	Restart after the resetting is made so that IP address is not duplicated
	IP address is changed during I/O communication	Turn off the power once and then turn it on again.
MS lamp: ON (red)	Network module (COM-ML) failure	Replace COM-ML
Data cannot be set	When a setting item (OUT) is set by I/O communication, setting state selection is not assigned to the first word.	Confirm the settings and set them correctly
Data content does not match	The data specified in the communication item settings is different from the data actually handled in I/O communication or explicit message communication	Confirm the settings and set them correctly
Data numbers do not match	In I/O communication, the number of measurement items (IN) used and the number of setting items (OUT) used do not match the set numbers	Confirm the settings and set them correctly

■ RKC communication

Problem	Probable cause	Solution	
No response	Wrong connection, no connection or disconnection of the communication cable	Confirm the connection method or condition and connect correctly	
	Breakage, wrong wiring, or imperfect contact of the communication cable	Confirm the wiring or connector and repair or replace the wrong one	
	Mismatch of the setting data of communication speed and data bit configuration with those of the host computer	Confirm the settings and set them correctly	
	Wrong address setting		
	Error in the data format	Reexamine the communication program	
	Transmission line is not set to the receive state after data send		
EOT return	The specified identifier is invalid	Confirm the identifier is correct or that with the correct function is specified. Otherwise correct it	
	Error in the data format	Reexamine the communication program	
NAK return	Error occurs on the line (parity bit error, framing error, etc.)	Confirm the cause of error, and solve the problem appropriately. (Confirm the transmitting data, and resend data)	
	BCC error		
	The data exceeds the setting range	Confirm the setting range and transmit correct data	
	The block data length of the transmission exceeds 128 bytes	Divide the block using ETB before sending it	
	The specified identifier is invalid	Confirm the identifier is correct or that with the correct function is specified. Otherwise correct it	

■ Modbus

Problem	Probable cause	Solution
No response	Wrong connection, no connection or disconnection of the communication cable	Confirm the connection method or condition and connect correctly
	Breakage, wrong wiring, or imperfect contact of the communication cable	Confirm the wiring or connector and repair or replace the wrong one
	Mismatch of the setting data of communication speed and data bit configuration with those of the host computer	Confirm the settings and set them correctly
	Wrong address setting	
	There is length of query message exceeds set range	
	A transmission error (overrun error, framing error, parity error or CRC-16 error) is found in the query message	
	The time interval between adjacent data in the query message is too long, exceeding 24 bit's time	
Error code 1	Function cod error (Specifying nonexistent function code)	Confirm the function code
Error code 2	When the mismatched address is specified	Confirm the address of holding register
Error code 3	 When the specified number of data items in the query message exceeds the maximum number of data items available When the data written exceeds the setting 	Confirm the setting data
	range	
Error code 4	Self-diagnostic error	Turn off the power to the instrument. If the same error occurs when the power is turned back on, please contact RKC sales office or the agent.

12. SPECIFICATIONS

■ Ethernet communication

Physical layer: Ethernet

10BASE-T/100BASE-TX automatic recognition

Application layer: EtherNet/IP

Corresponding message: I/O communication, Explicit massage communication

Connector type: RJ-45

■ Host communication

Interface: Based on EIA, RS-422A standard

Based on EIA, RS-485 standard

Protocol: • RKC communication

Based on ANSI X3.28-1976 subcategories 2.5 and B1

Polling/selecting type

Error control: Vertical parity (with parity bit selected)

Horizontal parity (BCC check)

Data types: ASCII 7-bit code

• Modbus

Signal transmission mode:

Remote Terminal Unit (RTU) mode

Function codes: 03H Read holding registers

06H Preset single register

08H Diagnostics (loopback test)

10H Preset multiple registers

Error check method:

CRC-16

Error codes: 1: Function code error

(An unsupported function code was specified)

2: When the mismatched address is specified.

3: • When the data written exceeds the setting range.

• When the specified number of data items in the query message exceeds the maximum number of data items

available

4: Self-diagnostic error response

Synchronous method: Start/stop synchronous type

Connection method: RS-422A: 4-wire system, half-duplex multi-drop connection

RS-485: 2-wire system, half-duplex multi-drop connection

Communication speed: 4800 bps, 9600 bps, 19200 bps, 38400 bps

Data bit configuration: Start bit: 1

Data bit: 7 or 8 (Modbus: 8 fixed) Parity bit: Without, Odd or Even

Stop bit: 1

Interval time: 0 to 250 ms

Maximum connections: 16 SRZ units per communication port of host computer

Connection method: Modular juck (6-pin)

Termination resistor: External connection is necessary (Example: 120Ω , 1/2 W)

■ Loader communication

Interface: Connection with a loader communication cable for our USB converter COM-K2

(sold separately).

Protocol: RKC communication (Based on ANSI X3.28-1976 subcategories 2.5 and B1)

Synchronous method: Start/stop synchronous type

Communication speed: 38400 bps **Data bit configuration:** Start bit: 1
Data bit: 8

Parity bit: Without

Stop bit: 1

Maximum connections: One SRZ unit

■ Self-diagnostic function

Major fault

Action stop: RAM value abnormal

Power supply voltage monitoring error

Watchdog timer error

Instrument status: Display: A red lamp (FAIL/RUN) is on

Host communication:

Receive mode

Network communication:

Receive mode

Error recovery: Recovery by device power restart after cause of error is removed

• Recoverable fault

Data backup error: Display: A green lamp (FAIL/RUN) frashes

Status: Error code 2

Stack overflow: Display: A green lamp (FAIL/RUN) frashes

Status: Error code 64

Network module error: Display: A green lamp (FAIL/RUN) frashes

Status: Error code 512

■ General specifications

Power supply voltage: 21.6 to 26.4 V DC [Including power supply voltage variation]

(Rating 24 V DC)

Power consumption (at maximum load):

120 mA max. (at 24 V DC)

Rush current: 12 A or less

Insulation resistance: Between power supply terminal and grounding:

 $20 \text{ M}\Omega$ or more at 500 V DC

Between host communication terminal and grounding:

 $20 \text{ M}\Omega$ or more at 500 V DC

Between power supply terminal and host communication terminal:

 $20 \text{ M}\Omega$ or more at 500 V DC

Between power supply terminal and network communication terminal:

 $20 \text{ M}\Omega$ or more at 250 V DC

Withstand voltage: See table shown below

Time: 1 min.	1	2	3
① Grounding terminal			
② Power supply terminal	750 V AC		
③ Host communication terminal	750 V AC	750 V AC	
4 Network communication terminal	750 V AC	250 V AC	750 V AC

Power failure: A power failure of 4 ms or less will not affect the control action.

Memory backup: Backed up by non-volatile memory

Number of writing: Approx. 1,000,000 times

Data storage period: Approx. 10 years

Vibration: Equivalent to JIS C1805-3 Clause 7 conformance test

Frequency range: 10 to 150 Hz Amplitude: < 0.075 mm Acceleration: < 9.8 m/s²

Each direction of XYZ axes

Shock: Free fall: Height 50 mm or less

Each direction of XYZ axes (de-energized state)

Allowable ambient temperature:

−10 to +50 °C

Allowable ambient humidity: 5 to 95 %RH

(Absolute humidity: MAX.W.C 29.3 g/m³ dry air at 101.3 kPa)

Installation environment conditions:

Indoor use

Altitude up to 2000 m

Operating environment: Avoid the following conditions when selecting the mounting location.

• Rapid changes in ambient temperature which may cause condensation.

• Corrosive or inflammable gases.

• Water, oil, chemicals, vapor or steam splashes.

• Direct air flow from an air conditioner.

• Exposure to direct sunlight.

• Excessive heat accumulation.

Weight: Approx. 130 g

Dimensions: $30.0 \times 100.0 \times 81.6 \text{ mm (W} \times H \times D) \text{ (Not including protruding parts)}$

■ Standard

Safety standards: UL: UL 61010-1

cUL: CAN/CSA-C22.2 No.61010-1

CE marking: LVD: EN61010-1

POLLUTION DEGREE 2, Class II (Reinforced insulation)

EMC: EN61326-1

RCM: EN55011

13. OBJECT MODEL

EtherNet/IP is an implementation of CIP (Common Industrial Protocol) on Ethernet and TCP/IP. CIP is defined by means of an object model.

13.1 CIP Common Object

■ Identity Object (0x01: 01Hex)

Object class

	ID Description	Get Set Type Value	
Attributes	1 Revision	Yes No UINT 1	
	EtherNet/IP service	Parameter option	
Services	0x0E Get_Attribute_Single	None	
	0x01 Get_Attribute_All	None	

• Object instance 1

	ID	Description	Get	Set	Туре	Value
Attributes	1	Vendor ID	Yes	No	UINT	394
	2	Device type	Yes	No	UINT	0
	3	Product code	Yes	No	UINT	8
	4	Revision	Yes	No	Struct	_
		Major revision			USINT	1
		Minor revision			USINT	1
	5	Status	Yes	No	WORD	Note
	6	Serial number	Yes	No	UDINT	(Unique serial number)
	7	Product name	Yes	No	Struct	
		Length			SHORT	8
		Name			SHORT	"COM-ML-2"
					STRING	
	11	Active Language	Yes	Yes	Struct	
					USINT	"e"
					USINT	"n"
					USINT	"g"
	12	Supported Language List	Yes	No	Any of Struc	t
					USINT	"e"
					USINT	"n"
					USINT	"g"

	EtherNet/IP service	Parameter option
Services	0x0E Get_Attribute_Single	None
	0x10 Set_Attribute_Single	None
	0x05 Reset	0
	0x01 Get_Attribute_All	None

Note: A bit layout of "Status"

bit 0: Owned bit 9: Minor Unrecoverable Fault bit 2: Configured bit 10: Major Recoverable Fault bit 4 to 7: Extended Device Status bit 11: Major Unrecoverable Fault bit 8: Minor Recover Fault (Bit 1, bit 3 and bit 12 to 15 is always 0.)

■ Message Router Object (0x02: 02Hex)

Object class

Attributes	Not supported
Services	Not supported

Object instance

Attributes	Not supported	
Services	Not supported	

■ Assembly Object (0x04: 04Hex)

Object class

	ID Description	Get Set Type Value	
Attributes	1 Revision	Yes No UINT 2	
	2 Max Instance	Yes No UINT (Highest Instar	ice number)
	EtherNet/IP service	Parameter option	

	EtherNet/IP service	Parameter option
Services	0x0E Get_Attribute_Single	None

• Object instance 100

	ID Description	Get Set Type Value
Attributes	3 Produced Data	Yes No Array of BYTE
	EtherNet/IP service	Parameter option
Services	0x0E Get_Attribute_Single	None

• Object instance 101

	ID Description	Get Set Type Value
Attributes	3 Consumed Data	Yes Yes Array of BYTE
	EtherNet/IP service	Parameter option
Services	0x0E Get_Attribute_Single 0x10 Set_Attribute_Single	None None

■ Connection Manager Object (0x06: 06Hex)

Object class

Attributes	Not supported
Services	Not supported

Object instance

Attributes Not supported

	EtherNet/IP service	Parameter option	
Services	0x4E Forward_Close	None	
	0x54 Forward_Open	None	

■ TCP/IP Interface Object (0xF5: F5Hex)

• Object class

	ID Description	Get Set Type Value
Attributes	1 Revision	Yes No UINT 1
	EtherNet/IP service	Parameter option
Services	0x0E Get_Attribute_Single	None
	0x01 Get_Attribute_All	None

Object instance 1

	ID	Description	Get	Set	Туре	Value
Attributes	1	Status	Yes	No	DWORD	1
	2	Configuration Capability	Yes	No	DWORD	0000 0014h or 0000 0004h
						bit 0 to 1: 0 (fixed)
						bit 2: DHCP Client
						bit 3: 0 (fixed)
						bit 4: Configuration Settable
						bit 5 to 31: 0 (fixed)
	3	Configuration Control	Yes	Yes	DWORD	0: non-volatile memory
						2: DHCP
	4	Physical Link Object	Yes	No	Struct	
		Path Size			USINT	2
		Path			Padded	20 F6 24 01h
					EPATH	
	5	Interface Configuration	Yes	Yes	Struct	
		IP Address			UDINT	
		Network Mask			UDINT	
		Gateway Address Name Server 1			UDINT UDINT	
		Name Server 2			UDINT	
		Domain Name			STRIN	
		Bollium Pume			G	
	6	Host Name	Yes	Yes	STRING	
			_			
	Eth	erNet/IP service	Paran	neter	option	
Services	0x0	E Get_Attribute_Single	None			
	0x0	1 Get_Attribute_All	None			
	0x1	0 Set_Attribute_Single	None			

■ Ethernet Link Object (0xF6: F6Hex)

• Object class

	ID Description	Get Set Type Value
Attributes	1 Revision	Yes No UINT 2
	EtherNet/IP service	Parameter option
Services	0x0E Get_Attribute_Single	None
	0x01 Get Attribute All	None

Object instance 1

	ID	Description	Get	Set	Type	Value
Attributes	1	Interface Speed	Yes	No	UDINT	10 or 100
	2	Interface Flags	Yes	No	DWORD	
	3	Physical address	Yes	No	6 USINT	(MAC ID)
	4	Interface Counters	Yes	No	Struct	
		In Octets			UDINT	
		In Ucast Packets			UDINT	
		In NUcast Packets			UDINT	
		In Discards			UDINT	
		In Errors			UDINT	
		In Unknown Protos			UDINT	
		Out Octets			UDINT	
		Out Ucast Packets			UDINT	
		Out NUcast Packets			UDINT	
		Out Discards			UDINT	
		Out Errors			UDINT	
	5	Media Counters	Yes	No	Struct	
		Alignment Errors			UDINT	
		FCS Errors			UDINT	
		Single Collisions			UDINT	
		Multiple Collisions			UDINT	
		SQE Test Errors			UDINT	0
		Deferred Transmissions			UDINT	
		Late Collisions			UDINT	
		Excessive Collisions			UDINT	
		MAC Transmit Errors			UDINT	
		Carrier Sense Errors			UDINT	
		Frame Too Long			UDINT	
		MAC Receive Errors			UDINT	
	6	Interface Control	Yes	Yes	Struct	
		Control Bits			WORD	
		Forced Interface Speed			UINT	
	Eth	erNet/IP service	Parar	neter	option	
Services	0x0	E Get Attribute Single	None			
			N T			
	0x0	l Get Attribute All	None			
	0x0 0x1		None			

13.2 Application Object

■ Controller Object (0x64: 64Hex)

Object class

Attributes	Not supported
Services	Not supported

● Object instance □ (□: 1 to 255)

	ID Description	Get Set Type Value
Attributes	100 Data 0	Yes Yes UINT Note
	101 Data 1	Yes Yes UINT Note
	• •	
	148 Data 48	Yes Yes UINT Note
	149 Data 49	Yes Yes UINT Note

	EtherNet/IP service	Parameter option
Services	0x0E Get_Attribute_Single	None
	0x10 Set_Attribute_Single	None

Note: Modbus address data specified in the Controller Communication Item Setting Object (0xC5).

The instance number indicates how many data items the data is from the Modbus address data specified in the attribute ID of 0xC5.

When an RO item is written to, the value reverts to the original value several seconds later. Items that are not used are RO, and the data is 0.

Example: Data of instance 2, attribute 100 is the data of "first Modbus address + 1" specified in attribute 100 of 0xC5.

■ Controller Communication Item Setting Object (0xC5: C5Hex)

Object class

Attributes	Not supported	
Services	Not supported	

Object instance 1

	ID Description	Get Set Type	Value
Attributes	100 Item setting of Data 0	Yes Yes UINT	Note
	101 Item setting of Data 1	Yes Yes UINT	Note
	• •	• • •	•
	• •		•
	148 Item setting of Data 48	Yes Yes UINT	Note
	149 Item setting of Data 49	Yes Yes UINT	Note

	EtherNet/IP service	Parameter option
Services	0x0E Get_Attribute_Single	None
	0x10 Set_Attribute_Single	None

Note: Set the first Modbus address of the data used in the Controller Object (0x64). If not used, set 0xFFFF.

■ Controller Communication Measured Data Item (IN) Setting Object (0xC6: C6Hex)

Object class

Attributes	Not supported
Services	Not supported

Object instance 1

	ID	Description		Set	Type	Value
Attributes	100	The number of Measured Data Item (IN) of Data 0		Yes	USINT	0 to 128 (0: Unused)
	101	The number of Measured Data Item (IN) of Data 1		Yes	USINT	0 to 128 (0: Unused) *
	:	•	:	:	:	•
	•	•	•	•	•	•
	148	The number of Measured Data Item (IN) of Data 48		Yes	USINT	0 to 128 (0: Unused) *
	149	The number of Measured Data Item (IN) of Data 49	Yes	Yes	USINT	0 to 128 (0: Unused) *

	EtherNet/IP service	Parameter option
Services	0x0E Get_Attribute_Single	None
	0x10 Set_Attribute_Single	None

^{*} A cumulative number of data items of up to 128 from attribute 100 is valid. A setting above this will be disregarded.

■ Controller Communication Set Data Item (OUT) Setting Object (0xC7: C7Hex)

Object class

Attributes	Not supported	
Services	Not supported	

Object instance 1

	ID	Description		Set	Type	Value
Attributes	100	The number of Set Data Item (OUT) of Data 0	Yes	Yes	USINT	0 to 127 (0: Unused)
	101	The number of Set Data Item (OUT) of Data 1	Yes	Yes	USINT	0 to 127 (0: Unused) *
	•	:	:	•	:	:
	<u>:</u>	•	<u>:</u>	<u>:</u>	<u>:</u>	•
	148	The number of Set Data Item (OUT) of Data 48		Yes	USINT	0 to 127 (0: Unused) *
	149	The number of Set Data Item (OUT) of Data 49	Yes	Yes	USINT	0 to 127 (0: Unused) *

	EtherNet/IP service	Parameter option
Services	0x0E Get_Attribute_Single	None
	0x10 Set_Attribute_Single	None

^{*} A cumulative number of data items of up to 127 from attribute 100 is valid. A setting above this will be disregarded.

Regardless of the setting of this object, "setting state selection" is assigned to the first-word of the set data item (OUT).

	Description	Get Set Type	Value
First-word of the set data item (OUT)	Setting state selection	Yes Yes UINT	Bit data bit 0: Data setting disabled/enabled 0: Setting disable 1: Setting enable bit 1 to 15: Unused

APPENDIX. HOST COMMUNICATION PROTOCOL

A.1 Communication Requirements

■ Processing times during data send/receive

When the host computer is using either the polling or selecting procedure for communication, the following processing times are required for SRZ unit to send data:

- Response wait time after SRZ unit sends BCC in polling procedure
- Response wait time after SRZ unit sends ACK or NAK in selecting procedure

RKC communication (Polling procedure)

Procedure details	Time	
Response send time after controller receives ENQ 60 ms		
Response send time after controller receives ACK	60 ms max.	
Response send time after controller receives NAK	60 ms max.	
Response send time after controller sends BCC	2 ms max.	

RKC communication (Selecting procedure)

Procedure details	Time
Response send time after controller receives BCC	60 ms max. *
Response wait time after controller sends ACK	2 ms max.
Response wait time after controller sends NAK	2 ms max.

Modbus

Procedure details	Time
Read holding registers [03H] Response send time after the slave receives the query message	60 ms max.
Preset single register [06H] Response send time after the slave receives the query message	100 ms max.
Diagnostics (loopback test) [08H] Response send time after the slave receives the query message	30 ms max.
Preset multiple registers [10H] Response send time after the slave receives the query message	100 ms max. *

- * In the case of RKC communication (selecting procedure), the time will be "the time after BCC reception until an acknowledgement [ACK] is sent."
 - When successive changes are made to the setting of the same item [Example] Successive changes to a set value (SV), control by manual manipulated output value, etc.
 - When successive changes are made to multiple items [Example] Configuring initial settings

Processing times (Varies with the function module types.)

Function module (When connected maximum connection number)	Time
Setting items of the Z-TIO module	750 ms max.
Setting items of the Z-DIO module	2000 ms max.

Caution for selecting

When selecting of the following communication data of a Z-TIO module is performed, the next selecting procedure for the changed Z-TIO module will not be possible for 4 to 6 seconds.

For this reason, when there are many channels to be changed, do not perform selecting for each channel individually; perform selecting for all channels at once. Note that if the communication data exceeds 128 bytes, the data will be separated into blocks by ETB.

- Input type
- Decimal point position
- Integral/derivative time decimal point position

■ RS-485 (2-wire system) send/receive timing

RS-485 communication is conducted through two wires, therefore the transmission and reception of data requires precise timing.

Polling procedure

Host computer	Send data (Possible/Impossible)	Possible Impossible
	Sending status	E N A K
SRZ unit	Send data (Possible/Impossible)	Possible a b C C C C C C C C C
OI (Z dillit	Sending status	ST BCC

- a: Response send time after the controller receives [ENQ] + Interval time
- b: Response send time after the controller sends BCC
- c: Response send time after the controller receives [ACK] + Interval time or Response send time after the controller receives [NAK] + Interval time

Selecting procedure

Host computer	Send data	Possible		
	(Possible/Impossible)	Impossible		
	Sending status	S B C C		
	Send data	Possible a b		
SRZ unit	(Possible/Impossible)	Impossible		
S. V.Z. UTIII	Sending status	or NAK		

- a: Response send time after the controller receives BCC + Interval time
- b: Response wait time after the controller sends ACK or Response wait time after the controller sends NAK
- To switch the host computer from transmission to reception, send data must be on line.
- The following processing times are requires for the SRZ unit to process data.
 - In Polling procedure, Response wait time after the SRZ unit sends BCC
 - In Selecting procedure, Response wait time after the SRZ unit sends ACK or NAK

■ Fail-safe

A transmission error may occur with the transmission line disconnected, shorted or set to the high-impedance state. In order to prevent the above error, it is recommended that the fail-safe function be provided on the receiver side of the host computer. The fail-safe function can prevent a framing error from its occurrence by making the receiver output stable to the MARK (1) when the transmission line is in the high-impedance state.


A.2 RKC Communication Protocol

RKC communication uses the polling/selecting method to establish a data link. The basic procedure is followed ANSI X3.28-1976 subcategories 2.5 and B1 basic mode data transmission control procedure (Fast selecting is the selecting method used in SRZ unit).

- The polling/selecting procedures are a centralized control method where the host computer controls the entire process. The host computer initiates all communication so the SRZ unit responds according to queries and commands from the host.
- The code use in communication is 7-bit ASCII code including transmission control characters.
 Transmission control characters used in SRZ unit:
 EOT (04H), ENQ (05H), ACK (06H), NAK (15H), STX (02H), ETB (17H), ETX (03H)
 (): Hexadecimal

A.2.1 Polling procedures

Polling is the action where the host computer requests one of the connected SRZ units to transmit data. An example of the polling procedure is shown below:



(1) Data link initialization


Host computer sends EOT to the controllers to initiate data link before polling sequence.

(2) Data sent from host computer - Polling sequence

The host computer sends the polling sequence in the following two types of formats:

- Format in which no memory area number is specified, and
- Format in which the memory area number is specified.
- When no memory area number is specified


To be sent in this format for any identifier not corresponding to the memory area.





• When the memory area number is specified

To be sent in this format for any identifier corresponding to the memory area.





1. Address (2 digits)

This data is a unit address of the SRZ for polled and must be the same as the unit address set value in item 5.1 Address Setting (P. 21).

The polling address which transmitted a message once becomes effective so long as data link is not initialized by transmit and receive of EOT.

2. Memory area number (2 digits)

This is the identifier to specify the memory area number. It is expressed by "K1" to "K8" to each memory area number (from 1 to 8). If the memory area number is assigned with "K0," this represents that control area is specified.

	The memory area now	used for control:	is called "Control area."
--	---------------------	-------------------	---------------------------

If the memory area number is not specified when polling the identifier corresponding to the memory area, this represents that the control area is specified.

If any identifier not corresponding to the memory area is assigned with a memory area number, this memory area number is ignored.

3. Identifier (2 digits)

The identifier specifies the type of data that is requested from the SRZ unit. Always attach the ENQ code to the end of the identifier.


See 9. COMMUNICATION DATA LIST (P. 38).

4. ENQ

The ENQ is the transmission control character that indicates the end of the polling sequence. The host computer then must wait for a response from the SRZ unit.

(3) Data sent from the SRZ unit

If the polling sequence is received correctly, the SRZ unit sends data in the following format:



If the length of send data (from STX to BCC) exceeds 128 bytes, it is divided into blocks by ETB. In this case, the succeeding divided data is sent after STX.

1. STX

STX is the transmission control character which indicates the start of the text transmission (identifier and data).

2. Identifier (2 digits)

The identifier indicates the type of data (measured value, status and set value) sent to the host computer.

For the communication data, see 9. COMMUNICATION DATA LIST (P. 38).

3. Data

Data which is indicated by an identifier of SRZ unit, consisting of channel numbers, data, etc. Each channel number and data are delimited by a space (20H). The data and the next channel number are delimited by a comma (2CH).

- Channel number: 3-digit ASCII code, not zero-suppressed. Channels without channel numbers may exist depending on the type of identifier.
- Data: ASCII code, zero-suppressed with spaces (20H). The number of digits varies depending on the type of identifier.
- Memory area soak time monitor and area soak time become the following data:
 - When data range is 0 hour 00 minute to 99 hours 59 minutes: Data range is 0:00 to 99:59, punctuation of time unit is expressed in colon ": (3AH)."
 - When data range is 0 minute 00 second to 199 minutes 59 seconds: Data range is 0:00 to 199:59, punctuation of time unit is expressed in colon ": (3AH)."
- "0" (without a decimal point) is sent for unused channels and for data that is invalid due to the function selection.

4. ETB

Transmission control character indicating the end of the block.

5. ETX


Transmission control character indicating the end of the text.

6. BCC

BCC (Block Check Character) detects error by using horizontal parity (even number).

Calculation method of BCC: *Exclusive OR* all data and characters from STX through ETB or ETX, not including STX.

Example:



Hexadecimal numbers

BCC = 4DH \oplus 31H \oplus 30H \oplus 31H \oplus 20H \oplus 20H \oplus 31H \oplus 35H \oplus 30H \oplus 2EH \oplus 30H \oplus 03H = 54H (\oplus : Exclusive OR)

Value of BCC becomes 54H

(4) EOT send (Ending data transmission from the SRZ unit)

In the following cases, the SRZ unit sends EOT to terminate the data link:

- When the specified identifier is invalid
- When there is an error in the data format
- When all the data has been sent
- When the module that relates to the identifier is not connected

(5) No response from the SRZ unit

The SRZ unit will not respond if the polling address is not received correctly. It may be necessary for the host computer to take corrective action such as a time-out.

(6) ACK (Acknowledgment)

An acknowledgment ACK is sent by the host computer when data received is correct. When the SRZ unit receives ACK from the host computer, the SRZ unit will send any remaining data of the next identifier without additional action from the host computer. When host computer determines to terminate the data link, EOT is sent from the host computer.

- When ACK is received after ETX and BCC are sent, the next identifier data is sent according to the order of the communication data list.
- When ACK is received after ETB and BCC are sent, the data after ETB is sent.

(7) NAK (Negative acknowledge)

If the host computer does not receive correct data from the SRZ unit, it sends a negative acknowledgment NAK to the SRZ unit. The SRZ unit will re-send the same data when NAK is received. This cycle will go on continuously until either recovery is achieved or the data link is corrected at the host computer. The format of the data that an SRZ unit re-sends is as follows.

STX	Identifier	Data	ETB or FTX	всс
-----	------------	------	------------------	-----

(8) No response from host computer

When the host computer does not respond within approximately three seconds after the SRZ unit sends data, the SRZ unit sends EOT to terminate the data link (time-out time: about 3 seconds).

(9) Indefinite response from host computer


The SRZ unit sends EOT to terminate the data link when the host computer response is indefinite.


(10) EOT (Data link termination)


The host computer sends EOT message when it is necessary to suspend communication with the SRZ unit or to terminate the data link due lack of response from the SRZ unit.

■ Polling procedure example (When the host computer requests data)


Normal transmission









• Error transmission





A.2.2 Selecting procedures

Selecting is the action where the host computer requests one of the connected SRZ units to receive data. An example of the selecting procedure is shown below:



(1) Data link initialization

Host computer sends EOT to the SRZ unit to initiate data link before selecting sequence.

(2) Sending selecting address from the host computer

Host computer sends selecting address for the selecting sequence.

Address (2 digits):


This data is a unit address of the SRZ to be selected and must be the same as the unit address set value in item 5.1 Address setting (P. 21).

As long as the data link is not initialized by sending or receiving EOT, the selecting address once sent becomes valid.


(3) Data sent from the host computer

The host computer sends data for the selecting sequence with the following format:

• When no memory area number is specified



• When the memory area number is specified



- For the STX, Memory area number Identifier, Data, ETB, ETX and BCC, see A.2.1 Polling procedures (P. 110).
- If the length of send data (from STX to BCC) exceeds 128 bytes, it is divided into blocks by ETB. In this case, the succeeding divided data is sent after STX.
- Area soak time set data as the following:
 - When data range is 0 hour 00 minute to 99 hours 59 minutes: Data range is 0:00 to 99:59, punctuation of time unit is expressed in colon ": (3AH)."
 - When data range is 0 minute 00 second to 199 minutes 59 seconds:

 Data range is 0:00 to 199.59, punctuation of time unit is expressed in colon ": (3AH)."

 In addition to above, when minute and second data are set in more than 60, become as the following:

Example: 1:65 (1 hour 65 minutes) \rightarrow 2:05 (2 hours 05 minutes) 0:65 (0 minute 65 seconds) \rightarrow 1:05 (1 minute 05 seconds)

About numerical data

[The data that receipt of letter is possible]

• Data with numbers below the decimal point omitted or zero-suppressed data can be received.

(Number of digits: Within 7 digits)

<Example>

When data send with -001.5, -01.5, -1.5, -1.50, -1.500 at the time of -1.5, SRZ unit can receive a data.

• When the host computer sends data with decimal point to item of without decimal point, the SRZ unit receives a message with the value that cut off below the decimal point.

<Example>

When setting range is 0 to 200, the SRZ unit receives as a following.

Send data	0.5	100.5	
Receive data	0	100	

• The SRZ unit receives value in accordance with decided place after the decimal point. The value below the decided place after the decimal point is cut off.

<Example>

When setting range is -10.00 to +10.00, the controller receives as a following.

Send data	5	058	.05	-0
Receive data	-0.50	-0.05	0.05	0.00



If the host computer sends "decimal point only (.)" or "minus sign and decimal point only (-.)," the SRZ unit receives this as "0." However, the decimal point position will be the same as the decimal point position of the transmitted data item.

[The data that receipt of letter is impossible]

The SRZ unit sends NAK when received a following data.

+	Plus sign and the data that gained plus sing
_	Only minus sign (there is no figure)

(4) ACK (Acknowledgment)

An acknowledgment ACK is sent by the SRZ unit when data received is correct. When the host computer receives ACK from the SRZ unit, the host computer will send any remaining data. If there is no more data to be sent to the SRZ unit, the host computer sends EOT to terminate the data link.

(5) NAK (Negative acknowledge)

If the SRZ unit does not receive correct data from the host computer, it sends a negative acknowledgment NAK to the host computer. Corrections, such as re-send, must be made at the host computer.

The send conditions of NAK (after reception of ETX or BCC)

- When an error occurs on communication the line (parity, framing error, etc.)
- When a BCC check error occurs
- When the specified identifier is invalid
- When receive data exceeds the setting range
- When receive data is the identifier of RO (read only)
- When the module related to the identifier received by the SRZ is not connected

The send conditions of NAK (after reception of ETB or BCC)

• When a BCC check error occurs

(6) No response from SRZ unit


The SRZ unit does not respond when it can not receive the selecting address, STX, ETB, ETX or BCC.

(7) EOT (Data link termination)


The host computer sends EOT when there is no more data to be sent from the host computer or there is no response from the SRZ unit.


■ Selecting procedure example (when the host computer sends data)

Normal transmission



• Error transmission





A.2.3 Communication data structure

■ Data description



Part of the data above is shown below.

• Data for each unit (Without channel)


Data length 7 digits



Data length 1 digit



Data length 32 digits (Model code)



Data length 8 digits (ROM version)





Example) Data structure for control RUN/STOP switching in each SRZ unit




• Data for each module











Data length 32 digits (Model code)



Data length 8 digits (ROM version)



Continued on the next page.

Space

Example) Data structure of error codes of Z-TIO, Z-DIO and Z-CT modules Ε Ζ 0 0 0 0 0 0 0 0 2 0 0 0 0 0 0 0 0 1 0 Identifier Channel No. Data Channel No. Data

For the calculation method of the channel number, see 6.2 Temperature Control Channel of the SRZ (P. 24) and 6.3 Digital Input/Output Channel of Z-DIO Module (P. 25).

Comma


Space

Data for each channel

Data length 7 digits




Data length 1 digit



* To select data corresponding to a memory area, specify the number of the appropriate memory area.

If a memory area number is specified for data that does not correspond to a memory area, the specification will be invalid.

Example) Data configuration of measured value (PV) of Z-TIO module




For the calculation method of the channel number, see 6.2 Temperature Control Channel of the SRZ (P. 24) and 6.3 Digital Input/Output Channel of Z-DIO Module (P. 25).

A.3 Modbus Protocol

The master controls communication between master and slave. A typical message consists of a request (query message) sent from the master followed by an answer (response message) from the slave (SRZ unit). When master begins data transmission, a set of data is sent to the slave in a fixed sequence. When it is received, the slave decodes it, takes the necessary action, and returns data to the master.

A.3.1 Message format

The message consists of four parts: slave address, function code, data, and error check code which are always transmitted in the same sequence.



Message format

■ Slave address

The slave address is a number from 0 to F manually set at the address setting switch located at the front of Z-COM module.

For details, see 5.1 Address Setting (P. 21).

Although all connected slave units receive the query message sent from the master, only the slave with the slave address coinciding with the query message will accept the message.

■ Function code

The function codes are the instructions set at the master and sent to the slave describing the action to be executed. The function codes are included when the slave responds to the master.

For details, see A.3.2 Function code (P. 124).

■ Data

The data to execute the function specified by the function code is sent to the slave and corresponding data returned to the master from the slave.

For details, see A.3.6 Register read and write (P. 129), A.3.7 Data processing precautions (P. 133) and 9. COMMUNICATION DATA LIST (P. 38).

■ Error check

An error checking code (CRC-16: Cyclic Redundancy Check) is used to detect an error in the signal transmission.

For details, see A.3.5 Calculating CRC-16 (P. 126).

A.3.2 Function code

• Function code contents

Function code (Hexadecimal)	Function	Contents
03H	Read holding registers	Measured value, control output value, current transformer input measured value, Event status, etc.
06H	Preset single register	Set value, PID constants, event set value, etc.
08H	Diagnostics (loopback test)	Loopback test
10H	Preset multiple registers	Set value, PID constants, event set value, etc.

Message length of each function (Unit: byte)

Function code	Function	Query message		Response message	
(Hexadecimal)	Tunction	Min	Max	Min	Max
03H	Read holding registers	8	8	7	255
06H	Preset single register	8	8	8	8
08H	Diagnostics (loopback test)	8	8	8	8
10H	Preset multiple registers	11	255	8	8

A.3.3 Communication mode

Signal transmission between the master and slaves is conducted in Remote Terminal Unit (RTU) mode.

Items	Contents
Data bit length	8-bit (Binary)
Start mark of message	Unused
End mark of message	Unused
Message length	See A.3.2 Function code
Data time interval	Less than 24 bits' time *
Error check	CRC-16 (Cyclic Redundancy Check)

^{*} When sending a command message from the master, set intervals of data configuring one message to time shorter than the 24 bits' time. If time intervals become time longer than the 24 bits' time the relevant slave assumes that message sending from the master is terminated to deform the message format. As a result, the slave does not make a response.

A.3.4 Slave responses

(1) Normal response

- In the response message of the Read Holding Registers, the slave returns the read out data and the number of data items with the same slave address and function code as the query message.
- In the response message of the Preset Single Register, the slave returns the same message as the query message.
- In the response message of the Diagnostics (Loopback test), the slave returns the same message as the query message.
- In the response message of the Preset Multiple Registers, the slave returns the slave address, the function code, starting number, and number of holding registers in the multi-query message.

(2) Defective message response

• If the query message from the master is defective, except for transmission error, the slave (SRZ unit) returns the error response message without any action.

Example: If there is a problem in the data range of CH3 when writing data of four channels, the data of CH1 and CH2 will be written. The data of CH3 and CH4 will be disregarded and an error response message will be returned.

- If the self-diagnostic function of the slave (SRZ unit) detects an error, the slave (SRZ unit) will return an error response message to all query messages.
- The function code of each error response message is obtained by adding 80H to the function code of the query message.

Slave address
Function code
Error code
Error check CRC-16

Error response message

Error code	Contents	
1	Function code error (An unsupported function code was specified)	
2	When the mismatched address is specified.	
3	When the specified number of data items in the query message exceeds the maximum number of data items available When the data written exceeds the setting range	
4	Self-diagnostic error response	

(3) No response

The slave (SRZ unit) ignores the query message and does not respond when:

- The slave address in the query message does not coincide with any slave address settings.
- The CRC code of the master does not coincide with that of the slave.
- Transmission error such as overrun, framing, parity and etc., is found in the query message.
- Data time interval in the query message from the master exceeds 24 bit's time.


A.3.5 Calculating CRC-16

The Cyclic Redundancy Check (CRC) is a 2 byte (16-bit) error check code. After constructing the data message, not including start, stop, or parity bit, the master calculates a CRC code and appends this to the end of the message. The slave will calculate a CRC code from the received message, and compare it with the CRC code from the master. If they do not match, a communication error has occurred and the slave does not respond.

The CRC code is formed in the following sequence:

- 1. Load FFFFH to a 16-bit CRC register.
- 2. Exclusive OR (⊕) the first byte (8 bits) of the message with the CRC register. Return the result to the CRC register.
- 3. Shift the CRC register 1 bit to the right.
- 4. If the carry flag is 1, exclusive OR the CRC register with A001 hex and return the result to the CRC register. If the carry flag is 0, repeat step 3.
- 5. Repeat step 3 and 4 until there have been 8 shifts.
- 6. Exclusive OR the next byte (8 bits) of the message with the CRC register.
- 7. Repeat step 3 through 6 for all bytes of the message (except the CRC).
- 8. The CRC register contains the 2 byte CRC error code. When they are appended to the message, the low-order byte is appended first, followed by the high-order byte.

■ The flow chart of CRC-16



The \oplus symbol indicates an *exclusive OR* operation. The symbol for the number of data bits is n.

■ Example of a CRC calculation in the 'C' language

This routine assumes that the data types 'uint16' and 'uint8' exists. Theses are unsigned 16-bit integer (usually an 'unsigned short int' for most compiler types) and unsigned 8-bit integer (unsigned char). 'z_p' is a pointer to a Modbus message, and 'z_messaage_length' is its length, excluding the CRC. Note that the Modbus message will probably contain NULL characters and so normal C string handling techniques will not work.

```
uint16 calculate crc (byte *z p, unit16 z message length)
/* CRC runs cyclic Redundancy Check Algorithm on input z p
/* Returns value of 16 bit CRC after completion and
/* always adds 2 crc bytes to message
                                                                   */
                                                                   */
/* returns 0 if incoming message has correct CRC
   uint16 CRC= 0xffff;
   uint16 next;
   uint16 carry;
   uint16 n;
   uint8 crch, crcl;
   while (z messaage length--) {
       next = (uint16) *z p;
       CRC ^= next;
       for (n = 0; n < 8; n++) {
           carry = CRC \& 1;
           CRC >>= 1;
           if (carry) {
             CRC ^= 0xA001;
           }
       z p++;
   \operatorname{crch} = \operatorname{CRC} / 256;
   crcl = CRC \% 256
   z_p [z_messaage_length++] = crcl;
   z p [z messaage length] = crch;
   return CRC;
}
```

A.3.6 Register read and write

■ Read holding registers [03H]

The query message specifies the starting register address and quantity of registers to be read.

The contents of the holding registers are entered in the response message as data, divided into two parts: the high-order 8-bit and the low-order 8-bit, arranged in the order of the register numbers.

Example: The contents of the four holding registers from 01FCH to 01FFH are the read out from slave address 2.

Query message

			_
Slave address		02H	
Function code		03H	
Starting number	High	01H	J
	Low	FCH	Ì
Quantity	High	00H	اً
	Low	04H	
CRC-16	High	85H	
	Low	F6H	

First holding register address

The setting must be between 1 (0001H) and 125 (007DH).

Normal response message

Mornial response incosage		
Slave address	02H	
Function code		03H
Number of data		08H
First holding register contents	High	01H
	Low	24H
Next holding register contents	High	01H
	Low	1BH
Next holding register contents	High	01H
	Low	2BH
Next holding register contents	High	01H
	Low	22H
CRC-16	High	AAH
	Low	F3H

 \rightarrow Number of holding registers $\times 2$

Error response message

<u> </u>		
Slave address	·	02H
80H + Function code		83H
Error code		03H
CRC-16	High	F1H
	Low	31H

■ Preset single register [06H]

The query message specifies data to be written into the designated holding register. The write data is arranged in the query message with high-order 8-bit first and low-order 8-bit next. Only R/W holding registers can be specified.

Example: Data is written into the holding register 0ADCH of slave address 1.

Query message

Slave address		01H
Function code		06H
Holding register number	High	0AH
	Low	DCH
Write data	High	00H
	Low	64H
CRC-16	High	4AH
	Low	03H

Any data within the range

Normal response message

Slave address		01H
Function code		06H
Holding register number	High	0AH
	Low	DCH
Write data	High	00H
	Low	64H
CRC-16	High	4AH
	Low	03H

Contents will be the same as query message data.

Error response message

Slave address		01H
80H + Function code		86H
Error code		02H
CRC-16	High	СЗН
	Low	A1H

■ Diagnostics (Loopback test) [08H]

The master's query message will be returned as the response message from the slave (SRZ unit). This function checks the communication system between the master and slave (SRZ unit).

Example: Loopback test for slave address 1

Query message

Slave address		01H	
Function code		08H	
Test code	High	00H	\ \
	Low	00H	T
Data	High	1FH]
	Low	34H	}
CRC-16	High	E9H	
	Low	ECH	

Test code must be set to 00.

Any pertinent data

Normal response message

Slave address		01H
Function code		H80
Test code	High	00H
	Low	00H
Data	High	1FH
	Low	34H
CRC-16	High	E9H
	Low	ECH

Contents will be the same as query message data.

Error response message

1 0		
Slave address		01H
80H + Function code		88H
Error code		03H
CRC-16	High	06H
	Low	01H

■ Preset multiple registers [10H]

The query message specifies the starting register address and quantity of registers to be written. The write data is arranged in the query message with high-order 8-bit first and low-order 8-bit next. Only R/W holding registers can be specified.

Example: Data is written into the two holding registers from 0ADCH to 0ADDH of slave address 1.

Query message

Slave address		01H	
Function code		10H	
Starting number	High	0AH	First holding register address
	Low	DCH	First holding register address
Quantity	High	00H	The setting must be between 1 (0001H) and
	Low	02H	∫ 123 (007BH).
Number of data		04H	→ Number of holding registers × 2
Data to first register	High	00H)
	Low	64H	
Data to next register	High	00H	Any pertinent data
	Low	64H	J
CRC-16	High	C0H	
	Low	32H	

Normal response message

Slave address		01H
Function code		10H
Starting number Hig		0AH
	Low	DCH
Quantity	High	00H
	Low	02H
CRC-16	High	83H
	Low	EAH

Error response message

Slave address		01H
80H + Function code		90H
Error code		02H
CRC-16	High	CDH
	Low	C1H

A.3.7 Data processing precautions

• The numeric range of data used in Modbus protocol is 0000H to FFFFH. Only the set value within the setting range is effective.

FFFFH represents –1.

• The Modbus protocol does not recognize data with decimal points during communication.

Example1: When "Heater break alarm (HBA) set value" is 20.0 A, 20.0 is processed as 200, 200 = 00C8H

Heater break alarm (HBA)	High	00H
set value	Low	C8H

Example2: When "Set value (SV)" is -20.0 °C, -20.0 is processed as -200, -200 = 0000H - 00C8H = FF38H

Set value (SV)	High	FFH
	Low	38H

- In this communication, the data that memory area includes handles different address with for control area and for setting area.
- If data (holding register) exceeding the accessible address range is accessed, an error response message is returned.
- Read data of unused item is a default value.
- Any attempt to write to an unused item is not processed as an error. Data cannot be written into an unused item.
- If data range or address error occurs during data writing, it is not processed as an error. Except the data that error occurred, normal data is written in data register. Therefore, it is necessary to confirm data after the end of setting data.
- Communication data includes data that becomes RO (read only) depending on the specification. No error occurs even if data is written when set to RO. However in this case, no data is written.

For details, see 9. COMMUNICATION DATA LIST (P. 38).

• Send the next command message at time intervals of 24 bits after the master receives the response message.

A.3.8 How to use memory area data

Memory area function can store up to 8 individual sets of SVs and parameters. One of the areas is used for control, and the currently selected area is "Control area."


Memory area data can be used to check and change settings that belong to memory areas other than the control area. Reading and writing of memory area data is performed by channel.

■ Read and write of memory area data

If any memory area number to perform data read and write is specified by the setting memory area number (386CH to 38ABH), data corresponding to the specified memory area number is called up to the register addresses from 38ACH to 3DABH. By using these register addresses from 38ACH to 3DABH, it becomes possible to read and write data in any memory area.

		Register address			1	
	CH1	CH2	••••	CH64		
Setting memory area number	386CH	386DH		38ABH	\leftarrow	Register address to specify memory area
Event 1 set value (EV1)	38ACH	38ADH		38EBH	h	
Event 2 set value (EV2)	38ECH	38EDH		392BH	۱۱	
Event 3 set value (EV3)	392CH	392DH		396BH	1	
Event 4 set value (EV4)	396CH	396DH		39ABH	11	
Control loop break alarm (LBA) time	39ACH	39ADH		39EBH	11	
LBA deadband	39ECH	39EDH		3A2BH	11	
Set value (SV)	3A2CH	3A2DH		3A6BH	11	
Proportional band [heat-side]	3A6CH	3A6DH		3AABH	11	
Integral time [heat-side]	3AACH	3AADH		3AEBH	1 (
Derivative time [heat-side]	3AECH	3AEDH		3B2BH	1 >	Register address of memory area data
Control response parameter	3B2CH	3B2DH		3B6BH	1 /	
Proportional band [cool-side]	3B6CH	3B6DH		3BABH	11	
Integral time [cool-side]	3BACH	3BADH		3BEBH	11	
Derivative time [cool-side]	3BECH	3BEDH		3C2BH	1	
Overlap/Deadband	3C2CH	3C2DH		3C6BH	11	
Manual reset	3C6CH	3C6DH		3CABH	11	
Setting change rate limiter (up)	3CACH	3CADH		3CEBH	11	
Setting change rate limiter (down)	3CECH	3CEDH		3D2BH	11	
Area soak time	3D2CH	3D2DH	••••	3D6BH		
Link area number	3D6CH	3D6DH		3DABH	IJ	

For the Memory area data list, see 9.4 Memory Area Data Address of Z-TIO Module (P. 66).



Event 1 set value (EV1) (38ACH)
Event 2 set value (EV2) (38ECH)
Event 3 set value (EV3) (392CH)
Event 4 set value (EV4) (396CH)
Control loop break alarm (LBA) time (39ACH)
LBA deadband (39ECH)
Set value (SV) (3A2CH)
Proportional band [heat-side] (3A6CH)

Data corresponding to a specified memory area number is called up to the CH1 register


Integral time [heat-side] (3AACH)
Derivative time [heat-side] (3AECH)
Control response parameter (3B2CH)
Proportional band [cool-side] (3B6CH)
Integral time [cool-side] (3BACH)
Derivative time [cool-side] (3BECH)
Overlap/Deadband (3C2CH)
Manual reset (3C6CH)

Setting change rate limiter (up) (3CACH) Setting change rate limiter (down) (3CECH) Area soak time (3D2CH)

Link area number (3D6CH)

[Example 1] When data on the Event 1 set value in Memory area 2 of CH1 is read


1. The memory area number, "2" is written to the CH1 setting memory area number (386CH). Data in Memory area 2 is called up to the CH1 register addresses.



2. Data "50" on Event 1 set value (38ACH) is read.

[Example 2] When the set value (SV) in Memory area 3 of CH1 is changed to 200

1. The memory area number, "3" is written to the CH1 setting memory area number (386CH). Data in Memory area 3 is called up to the CH1 register addresses.




2. "200" is written to the set value (SV) (3A2CH).

■ Control area transfer

Any memory area used for control is specified by the memory area transfer (08DCH to 091BH). The area (095CH to 0E5BH) now used for control is called "Control area."

The memory area number (control area) can be changed at either RUN or STOP.


		Register	address		
	CH1	CH2	••••	CH64	
Memory area transfer	08DCH	08DDH	<u>_</u>	091BH	Register address to specify control area
Event 1 set value (EV1)	095CH	095DH		099BH	\
Event 2 set value (EV2)	099CH	099DH		09DBH	1)
Event 3 set value (EV3)	09DCH	09DDH		0A1BH	1
Event 4 set value (EV4)	0A1CH	0A1DH		0A5BH	1
Control loop break alarm (LBA) time	0A5CH	0A5DH		049BH	
LBA deadband	0A9CH	0A9DH		0ADBH	
Set value (SV)	0ADCH	0ADDH		0B1BH	1
Proportional band [heat-side]	0B1CH	0B1DH		0B5BH	
Integral time [heat-side]	0B5CH	0B5DH		0B9BH] \
Derivative time [heat-side]	0B9CH	0B9DH		0BDBH	Register address of memory area data
Control response parameter	0BDCH	0BDDH		0C1BH	1 /
Proportional band [cool-side]	0C1CH	0C1DH		0C5BH	
Integral time [cool-side]	0C5CH	0C5DH		0C9BH	1
Derivative time [cool-side]	0C9CH	0C9DH		0CDBH	
Overlap/Deadband	0CDCH	0CDDH		0CDCH	
Manual reset	0D1CH	0D1DH		0D5BH	1
Setting change rate limiter (up)	0D5CH	0D5DH		0D9BH	
Setting change rate limiter (down)	0D9CH	0D9DH		0DDBH]
Area soak time	0DDCH	0DDDH		0E1BH	1 /
Link area number	0E1CH	0E1CH		0E5BH	$\mathcal V$



Data corresponding to a specified memory

[Example] When performing control by calling up data in Memory area 3 of CH1

1. The memory area number, "3" is written to the memory area transfer (08DCH). Data in Memory area 3 is called up to the CH1 register addresses.



2. Control of CH1 is performed by using data in the register addresses.



If the memory area transfer (08DCH to 091BH) and the setting memory area number (386CH to 38ABH) are set to the same memory area number, the respective data can be synchronized.

- Values in the control areas (095CH to 0E5BH) and the setting memory area number (38ACH to 3DABH) are set to the same memory area number, the respective data can be synchronized.
- If data in the control area is changed, data in the memory area is also changed.
- If data in the memory area is changed, data in the control area is also changed.

■ Data mapping function

When using a COM-ML joined to function modules, the data mapping function cannot be used.

MEMO

The first edition: MAR. 2008 [IMQ01] The third edition: JUL. 2019 [IMQ00]



HEADQUARTERS: 16-6, KUGAHARA 5-CHOME, OHTA-KU TOKYO 146-8515 JAPAN

PHONE: 03-3751-9799 (+81 3 3751 9799)

E-mail: info@rkcinst.co.jp

Website: https://www.rkcinst.com/



IMR02E08-E3 JUL. 2019