

FB100 Parameter List

All Rights Reserved, Copyright © 2008, RKC INSTRUMENT INC.

IMR01W14-E3

SV setting & Monitor mode

Symbol	Name	The display or data ranges	Factory set value
—	Measured value (PV)/Set value (SV) monitor	PV display: PV is displayed. ² Input scale low to Input scale high SV display: The target value for control is displayed. • Set Value (SV) ² • Remote setting (RS) input value ² • Manual manipulated output value	—
SH	Set value (SV) ^{1,2}	Setting limiter low to Setting limiter high The target value for control can be set.	0
CF1	Current transformer 1 (CT1) input value monitor	0.0 to 30.0 A or 0.0 to 100.0 A Displayed only when the CT1 input is provided.	—
CF2	Current transformer 2 (CT2) input value monitor	0.0 to 30.0 A or 0.0 to 100.0 A Displayed only when the CT2 input is provided.	—
SHr	Remote setting (RS) input value monitor ³	Setting limiter low to Setting limiter high Displayed only when the Remote setting (RS) input is provided.	—
EHn1	Event monitor 1	SV display Event 1 (EV1) Event 2 (EV2) Event 3 (EV3) Event 4 (EV4) It is possible to check the type of created event depending on which digit was lit. Displayed when the event action is selected for any one of the Event types from 1 to 4.	—
EHn2	Event monitor 2	SV display Heater break alarm 1 (HBA1) Heater break alarm 2 (HBA2) It is possible to check the type of HBA which occurred depending on which digit was lit. Display when the CT1 or CT2 input is provided. This screen is not displayed when set the CT assignment to "0: None."	—
nH	Manipulated output value (MV1) monitor [heat-side] ³	PID control or Heat/Cool PID control: MV1 is displayed. (-5.0 to +105.0%) Position proportioning PID control: When the control motor with Feedback resistance (FBR) is used: FBR input value is displayed. (0.0 to 100.0%)	—
nH2	Manipulated output value (MV2) monitor [cool-side]	-5.0 to +105.0% MV2 of cool-side is displayed when the control action is Heat/Cool PID control.	—
RPf	Memory area soak time monitor ⁴	0 minutes 00 seconds to 199 minutes 59 seconds or 0 hours 00 minutes to 99 hours 59 minutes Memory area soak time is displayed when the Ramp/Soak control is being executed.	—
RE	Memory area transfer	1 to 8 When "EXT: External mode" is selected at Control area Local/External transfer, "d1" is shown on the SV display and memory area is not changeable from the front panel in the meantime.	1
PSn1	Manipulated output value at MV transfer	PID control: Output limiter low (MV1) to Output limiter high (MV1) Heat/Cool PID control: -Output limiter high (MV2) to +Output limiter high (MV1) For overlap: -105.0 to +105.0% * Actual output value is limited by the output limiter function. When in Auto mode, Manipulated output values (MV1 and MV2) can be manually changed. This screen is not displayed when the MV transfer function is set to "0."	0.0
ILr	Interlock release	on: Interlock oFF: Interlock release Not displayed when Event 1, 2, 3 or 4 interlock function is not used.	oFF

¹ Parameters related to Multi-memory area function

² Varies with the setting of the Decimal point position

³ MV1 of heat-side is not displayed when the control action is Position proportioning control and the input of feedback resistance (FBR) is not used.

⁴ Not displayed when "Digital input (DI) assignment" (Engineering mode) is somewhere between 6 and 12.

Operation mode

Symbol	Name	Data range	Factory set value
RFU	PID/AT transfer	on: Autotuning (AT) oFF: PID control	oFF
SFU	Startup tuning (ST)	on1: Execute one * on2: Execute always oFF: ST unused * When the Startup tuning is finished, the setting will automatically returns to "oFF: ST unused." The Startup tuning function (ST) is executed when the power is turned on; when transferred from STOP to RUN; or when the Set value (SV) is changed. This screen is not displayed when the control action is Position proportioning PID control.	oFF
CHR	Automatic temperature rise learning	on: Learning * oFF: Unused * When the Automatic temperature rise learning is finished, the setting will automatically returns to "oFF: Unused." This screen is not displayed when the Automatic temperature rise group is set to "0."	on
A-n	Auto/Manual transfer	AUTo: Auto mode MAN: Manual mode	AUTo
r-L	Remote/Local transfer	LoC: Local mode rEM: Remote mode Displayed only when the Remote setting (RS) input or Communication is provided.	LoC

Symbol	Name	Data range	Factory set value
L-E	Control area Local/External transfer ¹	LoC: Local mode EXT: External mode	LoC
r-S	RUN/STOP transfer	rUn: RUN mode (Control start) SToP: STOP mode (Control stop)	rUn

¹ Displayed only when "Digital input (DI) assignment" (Engineering mode) is somewhere between 6 and 12.

Parameter setting mode

Symbol	Name	Data range	Factory set value
EH1	Event 1 set value (EV1) ¹	Deviation: -Input span to +Input span ² Process and set value: Input scale low to Input scale high ² Manipulated output value (MV1 or MV2): -5.0 to +105.0% Not displayed when Event function is not used. EV4 is not displayed when the Event 4 is used as an LBA.	50
EH2	Event 2 set value (EV2) ¹	Same as EH1	50
EH3	Event 3 set value (EV3) ¹	Same as EH1	50
EH4	Event 4 set value (EV4) ¹	Same as EH1	50
LbA	Control loop break alarm (LBA) time	1 to 7200 seconds, oFF: Unused This screen is displayed when the Event 4 is used as an LBA.	480
Lbd	LBA deadband ^{1,2}	0 to Input span This screen is displayed when the Event 4 is used as an LBA.	0
P	Proportional band ¹ [heat-side]	TC/RTD inputs: 0 (0.0, 0.0) to Input span ² (Unit: °C [°F]) Voltage (V)/Current (I) inputs: 0.0 to 1000.0 % of Input span 0 (0.0, 0.0): ON/OFF action	30 ^a
I	Integral time ^{1,3} [heat-side]	PID control or Heat/Cool PID control: 1 to 3600 seconds or 0.1 to 1999.9 seconds oFF: PD action (both heat-side and cool-side) Position proportioning PID control: 1 to 3600 seconds or 0.1 to 1999.9 seconds	240
d	Derivative time ^{1,3} [heat-side]	1 to 3600 seconds or 0.1 to 1999.9 seconds oFF: PI action	60
r-Pf	Control response parameter ¹	0: Slow 1: Medium 2: Fast [When the P or PD action is selected, this setting becomes invalid.]	Note 1
Pc	Proportional band ^{1,4} [cool-side]	TC/RTD inputs: 1 (0.1, 0.01) to Input span ² (Unit: °C [°F]) Voltage (V)/Current (I) inputs: 0.1 to 1000.0 % of Input span	30 ^a
Ic	Integral time ^{1,3,4} [cool-side]	1 to 3600 seconds or 0.1 to 1999.9 seconds oFF: PD action (both heat-side and cool-side)	240
dc	Derivative time ^{1,3,4} [cool-side]	1 to 3600 seconds or 0.1 to 1999.9 seconds oFF: PI action	60
db	Overlap/Deadband ^{1,4}	TC/RTD inputs: -Input span to +Input span ² (Unit: °C [°F]) Voltage (V)/Current (I) inputs: -100.0 to +100.0 % of Input span Minus (-) setting results in Overlap. However, the overlapping range is within the proportional range.	0 ^a
n-r	Manual reset ¹	-100.0 to +100.0% The offset can be manually eliminated. The screen is displayed when the Integral time [heat-side] or Integral time [cool-side] is set to "oFF."	0.0
SHrU	Setting change rate limiter (up) ^{1,2}	1 to Input span/unit time * oFF: Unused	oFF
SHrd	Setting change rate limiter (down) ^{1,2}	* Unit time (factory set value): 60 seconds	oFF
ASf	Area soak time ^{1,5}	0 minutes 00 seconds to 199 minutes 59 seconds or 0 hours 00 minutes to 99 hours 59 minutes Any Area soak time is set when Ramp/Soak control is performed. Data range of Area soak time can be selected on the Soak time unit.	0:00
LnEA	Link area number ^{1,5}	1 to 8 oFF: No link It is possible to perform Ramp/Soak control by linking each memory area. The memory area at the linked destination at that time is set.	oFF

¹ Parameters related to Multi-memory area function

² Data range varies depending on the Decimal point position

³ Data range varies depending on the Integral/ Derivative decimal point position

⁴ This screen is displayed when the control action is Heat/Cool PID control.

⁵ Not displayed when "Digital input (DI) assignment" (Engineering mode) is somewhere between 6 and 12.

^a Factory set value varies depending on the instrument specification.

Note 1: PID control, Position proportioning PID control (0) Heat/Cool PID control (2)

Setup setting mode

Symbol	Name	Data range	Factory set value
HbA1	Heater break alarm 1 (HBA1) set value ^{a,b}	When CT is CTL-6-P-N: 0.1 to 30.0 A oFF: Not used When CT is CTL-12-S56-10L-N: 0.1 to 100.0 A oFF: Not used	oFF
HbL1	Heater break determination point 1 ^{a,b,c}	0.1 to 100.0 % of HBA1 set value oFF: Heater break determination is invalid	30.0
HbH1	Heater melting determination point 1 ^{a,b,c}	0.1 to 100.0 % of HBA1 set value oFF: Heater melting determination is invalid	30.0
HbA2	Heater break alarm 2 (HBA2) set value ^{d,e}	When CT is CTL-6-P-N: 0.1 to 30.0 A oFF: Not used When CT is CTL-12-S56-10L-N: 0.1 to 100.0 A oFF: Not used	oFF
HbL2	Heater break determination point 2 ^{d,e,f}	0.1 to 100.0 % of HBA2 set value oFF: Heater break determination is invalid	30.0
HbH2	Heater melting determination point 2 ^{d,e,f}	0.1 to 100.0 % of HBA2 set value oFF: Heater melting determination is invalid	30.0

^a Displayed when the CT1 is provided.

^b This screen is not displayed when set the CT1 assignment to "0: None."

^c Displayed when the HBA1 type is type B.

^d Displayed when the CT2 is provided.

^e This screen is not displayed when set the CT2 assignment to "0: None."

^f Displayed when the HBA2 type is type B.

Symbol	Name	Data range	Factory set value																																																							
Pb	PV bias ¹	-Input span to +Input span	0																																																							
dF	PV digital filter	0.1 to 100.0 seconds oFF: Unused	oFF																																																							
Pc	PV ratio	0.500 to 1.500	1.000																																																							
PLC	PV low input cut-off	0.00 to 25.00 % of input span This screen is displayed when the Square root extraction is set to "1: Used."	0.00																																																							
rb	RS bias ^{1,a}	-Input span to +Input span	0																																																							
dF2	RS digital filter ^a	0.1 to 100.0 seconds oFF: Unused	oFF																																																							
rr	RS ratio ^a	0.001 to 9.999	1.000																																																							
f	Proportional cycle time [heat-side]	0.1 to 100.0 seconds This screen is not displayed when the output type is Voltage/Current output.	20.0 ^b																																																							
t	Proportional cycle time [cool-side]	0.1 to 100.0 seconds Displayed only when the control action is Heat/Cool PID control. This screen is not displayed when the output type is Voltage/Current output.	20.0 ^b																																																							
Add1	Device address 1 ^c	0 to 99 Do not use the same device address for more than one controller in multi-drop connection. In Modbus communication, two-way communication is not possible when the address is 0.	0																																																							
bPS1	Communication speed 1 ^{c,d}	2.4: 2400 bps 4.8: 4800 bps 9.6: 9600 bps 19.2: 19200 bps 38.4: 38400 bps	19.2																																																							
bit1	Data bit configuration 1 ^{c,d}	<table border="1"> <thead> <tr> <th rowspan="2"></th> <th colspan="3">Bit configuration</th> </tr> <tr> <th>Data</th> <th>Stop</th> <th>Parity</th> </tr> </thead> <tbody> <tr> <td>8n1</td> <td>8</td> <td>1</td> <td>Without</td> </tr> <tr> <td>8n2</td> <td>8</td> <td>2</td> <td>Without</td> </tr> <tr> <td>8E1</td> <td>8</td> <td>1</td> <td>Even</td> </tr> <tr> <td>8E2</td> <td>8</td> <td>2</td> <td>Even</td> </tr> <tr> <td>8o1</td> <td>8</td> <td>1</td> <td>Odd</td> </tr> <tr> <td>8o2</td> <td>8</td> <td>2</td> <td>Odd</td> </tr> <tr> <td>7n1*</td> <td>7</td> <td>1</td> <td>Without</td> </tr> <tr> <td>7n2*</td> <td>7</td> <td>2</td> <td>Without</td> </tr> <tr> <td>7E1*</td> <td>7</td> <td>1</td> <td>Even</td> </tr> <tr> <td>7E2*</td> <td>7</td> <td>2</td> <td>Even</td> </tr> <tr> <td>7o1*</td> <td>7</td> <td>1</td> <td>Odd</td> </tr> <tr> <td>7o2*</td> <td>7</td> <td>2</td> <td>Odd</td> </tr> </tbody> </table> * When the Modbus communication protocol selected, this setting becomes invalid.		Bit configuration			Data	Stop	Parity	8n1	8	1	Without	8n2	8	2	Without	8E1	8	1	Even	8E2	8	2	Even	8o1	8	1	Odd	8o2	8	2	Odd	7n1*	7	1	Without	7n2*	7	2	Without	7E1*	7	1	Even	7E2*	7	2	Even	7o1*	7	1	Odd	7o2*	7	2	Odd	8n1
	Bit configuration																																																									
	Data	Stop	Parity																																																							
8n1	8	1	Without																																																							
8n2	8	2	Without																																																							
8E1	8	1	Even																																																							
8E2	8	2	Even																																																							
8o1	8	1	Odd																																																							
8o2	8	2	Odd																																																							
7n1*	7	1	Without																																																							
7n2*	7	2	Without																																																							
7E1*	7	1	Even																																																							
7E2*	7	2	Even																																																							
7o1*	7	1	Odd																																																							
7o2*	7	2	Odd																																																							
Inf1	Interval time 1 ^{c,d}	0 to 250 ms	10																																																							
Add2	Device address 2 ^e	Same as the Device address 1																																																								
bPS2	Communication speed 2 ^{a,e}	Same as the Communication speed 1																																																								
bit2	Data bit configuration 2 ^{a,e}	Same as the Data bit configuration 1																																																								
Inf2	Interval time 2 ^{a,e}	Same as the Interval time 1																																																								
LLP	Set lock level	0: Unlock 1: Lock Set to "0" or "1" for each digit. SV display Parameters other than Set value (SV) and Event set value (EV1 to EV4) Event set value (EV1 to EV4) Set value (SV) "0" fixed (Cannot be changed)	0000																																																							

¹ Varies with the setting of the Decimal point position

² Displayed only when the Remote setting (RS) input or Communication is provided.

³ Factory set value varies depending on the instrument specification.

⁴ Displayed only when the Communication 1 is provided.

⁵ This screen is not displayed when the Intercontroller communication function is selected.

^e Displayed only when the Communication 2 is provided.

Engineering mode

Parameters in Engineering mode are settable only when the controller is in STOP mode. However, it is possible to check only the data even in RUN mode. In addition, there are invalid parameters when no optional function is specified.

Symbol	Name	Data range	Factory set value
F10.	Function block 10	This is first parameter symbol of Function block 10.	
SPCH	STOP display	0: "STOP" is displayed on the PV display. 1: "SToP" is displayed on the SV display.	1
dE	Bar graph display	0: No display 4: Deviation value 1: MV 5: CT1 input value 2: PV 6: CT2 input value 3: SV monitor	1
dEUR	Bar graph display resolution	1 to 100 digit/dot The resolution can be changed when the Bar graph display (dE) was set to deviation value or CT input value.	100
dSoP	PV flashing display at input error	0: Flashing display 1: Non-flashing display	0
F11.	Function block 11	This is first parameter symbol of Function block 11.	
Fn1	Direct key selection	0: Unused 1: Used	1
Fn	Direct key type	1: Auto/Manual transfer 2: Monitor 3: Memory area transfer 4: Remote/Local transfer 5: RUN/STOP transfer	1

Symbol	Name	Data range	Factory set value
F21.	Function block 21	This is first parameter symbol of Function block 21.	
InP	Input type	0: TC input K 1: TC input J 2: TC input R 3: TC input S 4: TC input B 5: TC input E 6: TC input N 7: TC input T 8: TC input W5Re/W26Re 9: TC input PLII 10: TC input U 11: TC input L 12: RTD input Pt100 13: RTD input JPt100 14: Current input 0 to 200 mA DC 15: Current input 4 to 20 mA DC 16: Voltage (high) input 0 to 10 V DC 17: Voltage (high) input 0 to 5 V DC 18: Voltage (high) input 1 to 5 V DC 19: Voltage (low) input 0 to 1 V DC 20: Voltage (low) input 0 to 100 mV DC 21: Voltage (low) input ±1 V DC 24: Voltage (high) input ±1 V DC 25: Voltage (low) input ±100 mV DC 26: Voltage (low) input ±10 mV DC	0 ^a
Unif	Display unit	0: °C 1: °F Use to select the temperature unit for Thermocouple (TC) and RTD inputs.	0
PCDP	Decimal point position	0: No decimal place 1: One decimal place 2: Two decimal places 3: Three decimal places 4: Four decimal places TC input: K, J, E: Only 0 or 1 can be set. T, U, L: Only 1 can be set. Other than the above: Only 0 can be set. RTD input: From 0 to 2 can be set. V/I inputs: From 0 to 4 can be set.	0 ^a
PGSH	Input scale high	TC/RTD inputs: Input scale low to Maximum value of the selected input range Voltage (V)/Current (I) inputs: -19999 to +19999 (Varies with the setting of the Decimal point position)	Maximum value of the selected input range ^a
PGSL	Input scale low	TC/RTD inputs: Minimum value of the selected input range to Input scale high Voltage (V)/Current (I) inputs: -19999 to +19999 (Varies with the setting of the Decimal point position)	Minimum value of the selected input range ^a
POB	Input error determination point (high)	Input scale low - (5 % of input span) to Input scale high + (5 % of input span) (Varies with the setting of the Decimal point position)	Input scale high + (5 % of input span) ^a
PUb	Input error determination point (low)	Input scale low - (5 % of input span) (Varies with the setting of the Decimal point position)	Input scale low - (5 % of input span) ^a
boS	Burnout direction	0: Upscale 1: Downscale Valid only when the TC input and Voltage (low) input are selected.	0
Sqr	Square root extraction	0: Unused 1: Used	0
PFrq	Power supply frequency	0: 50 Hz 1: 60 Hz If the display on the screen flickers, set the value to the same value as the power frequency used. No power frequency can be changed while it can be normally measured with the CT input provided.	0
Snp	Sampling cycle	0: 50 ms 1: 100 ms 2: 250 ms	1
F22.	Function block 22	This is first parameter symbol of Function block 22.	
rInP	Remote setting input type	Refer to the input type (InP) for the transfer method of the voltage (low) or voltage (high) input.	15 ^a
F23.	Function block 23	This is first parameter symbol of Function block 23.	
d1SL	Digital input (DI) assignment	1 to 26 (Refer to next page table 1.)	1
F30.	Function block 30	This is first parameter symbol of Function block 30.	
LoGC	Output assignment	1 to 15 (Refer to next page table 2.)	1
off1	Timer 1	0.0 to 600.0 seconds Customization tool is necessary when the timer function is available.	0.0
off2	Timer 2		0.0
off3	Timer 3		0.0
off4	Timer 4		0.0
EuC	Energized/De-energized	0: Energized 1: De-energized SV display DO1 DO2 "0" fixed (Cannot be changed) "1" fixed (Cannot be changed)	0000

^a Factory set value varies depending on the instrument specification.

Symbol	Name	Data range	Factory set value
RLL1	Alarm (ALM) lamp lighting condition 1 ^a	0: ALM lamp is not lit 1: ALM lamp is lit 	1111
RLL2	Alarm (ALM) lamp lighting condition 2 ^a	0: ALM lamp is not lit 1: ALM lamp is lit 	0011
SS	Output status at STOP mode	0: OFF 1: Action continued 	0000
F33	Function block 33	This is first parameter symbol of Function block 33.	
Ro	Transmission output type	0: None 1: PV 2: SV monitor 3: Deviation value 4: MV1 [heat-side] 5: MV2 [cool-side] 6: SV 7: Remote setting (RS) input value	1
RHS	Transmission output scale high	When the PV, SV, SV monitor and RS: Input scale low to Input scale high (Varies with the setting of the Decimal point position)	Input scale high
RLS	Transmission output scale low	When the MV1 and MV2: -5.0 to +105.0 % When the deviation value: -Input span to +Input span	Input scale low
F41	Function block 41	This is first parameter symbol of Function block 41.	
ES1	Event 1 type	0: None 1: Deviation high ¹ 2: Deviation low ¹ 3: Deviation high/low ¹ 4: Band 5: Process high ¹ 6: Process low ¹ 7: SV high 8: SV low 9: Unused 10: MV1 high [heat-side] ^{1,2} 11: MV1 low [heat-side] ^{1,2} 12: MV2 high [cool-side] ¹ 13: MV2 low [cool-side] ¹ ¹ Event hold action is available. ² Feedback resistance (FBR) input value is displayed when the control motor with Feedback resistance (FBR) is used.	0 ^b
EHo1	Event 1 hold action	0: OFF 1: Hold action ON 2: Re-hold action ON	0 ^b
EIL1	Event 1 interlock	0: Unused 1: Used	0
EH1	Event 1 differential gap	Deviation, process or set value: 0 to Input span (Varies with the setting of the Decimal point position) MV: 0.0 to 110.0 %	2 ^b
EHF1	Event 1 delay timer	0.0 to 600.0 seconds	0.0
EEo1	Force ON of Event 1 action	0: Invalid 1: Valid 	0000
F42	Function block 42	This is first parameter symbol of Function block 42.	
ES2	Event 2 type	Same as Event 1 type	
EHo2	Event 2 hold action	Same as Event 1 hold action	
EIL2	Event 2 interlock	Same as Event 1 interlock	
EH2	Event 2 differential gap	Same as Event 1 differential gap	
EHF2	Event 2 delay timer	Same as Event 1 delay timer	
EEo2	Force ON of Event 2 action	Same as Force ON of Event 1 action	
F43	Function block 43	This is first parameter symbol of Function block 43.	
ES3	Event 3 type	Same as Event 1 type	
EHo3	Event 3 hold action	Same as Event 1 hold action	
EIL3	Event 3 interlock	Same as Event 1 interlock	
EH3	Event 3 differential gap	Same as Event 1 differential gap	
EHF3	Event 3 delay timer	Same as Event 1 delay timer	
EEo3	Force ON of Event 3 action	Same as Force ON of Event 1 action	
F44	Function block 44	This is first parameter symbol of Function block 44.	
ES4	Event 4 type	9: Control loop break alarm (LBA) The other data is the same as an Event 1 type.	
EHo4	Event 4 hold action	Same as Event 1 hold action The invalidity in case of the LBA.	
EIL4	Event 4 interlock	Same as Event 1 interlock	
EH4	Event 4 differential gap	Same as Event 1 differential gap The invalidity in case of the LBA.	
EHF4	Event 4 delay timer	Same as Event 1 delay timer	
EEo4	Force ON of Event 4 action	Same as Force ON of Event 1 action The invalidity in case of the LBA.	

^a The ALM lamp is lit through the OR operation of EV1, EV2, EV3, EV4, HBA1 and HBA2 each of which is set to "1": ALM lamp is lit.
^b Factory set value varies depending on the instrument specification.

Symbol	Name	Data range	Factory set value
F45	Function block 45	This is first parameter symbol of Function block 45.	
CFr1	CT1 ratio	0 to 9999 CT type: CTL-6-P-N CTL-12-S56-10L-N	800 ^a
CFr1	CT1 assignment	0: None 1: OUT1 2: OUT2 3: DO1 4: DO2	1
HbS1	Heater break alarm 1 (HBA1) type	0: Heater break alarm 1 (HBA1) type A 1: Heater break alarm 1 (HBA1) type B	0 ^a
HbC1	Number of heater break alarm 1 (HBA1) delay times	0 to 255	5
F46	Function block 46	This is first parameter symbol of Function block 46.	
CFr2	CT2 ratio	Same as CT1 ratio	
CFr2	CT2 assignment	0: None 1: OUT1 2: OUT2 3: DO1 4: DO2	0
HbS2	Heater break alarm 2 (HBA2) type	0: Heater break alarm 2 (HBA2) type A 1: Heater break alarm 2 (HBA2) type B	0
HbC2	Number of heater break alarm 2 (HBA2) delay times	Same as Number of heater break alarm 1 (HBA1) delay times	5
F50	Function block 50	This is first parameter symbol of Function block 50.	
Pd	Hot/Cold start	0: Hot start 1 1: Hot start 2 2: Cold start 3: Stop start	0
PdR	Start determination point	0 to Input span (The unit is the same as input value.) (0: Action depending on the Hot/Cold start selection) (Varies with the setting of the Decimal point position)	3 % of input span
CRn	External input type	0: Remote setting input 1: Intercontroller communication cascade control 2: Intercontroller communication ratio setting	0
nCH	Master channel selection	0 to 31 This value is valid when Intercontroller communication cascade control or ratio setting is selected.	0
FrE	SV tracking	0: Unused 1: Used	1
nHFS	MV transfer function	0: MV1 or MV2 in Auto mode is used. 1: When selected by Digital input (DI): MV1 or MV2 in previous Manual mode is used. When selected by front key: MV1 or MV2 in Auto mode is used. 2: MV1 or MV2 in previous Manual mode is used.	0
PHFS	PV transfer function	0: Unused 1: Used	0
F51	Function block 51	This is first parameter symbol of Function block 51.	
oS	Control action	0: Brilliant II PID control (direct action) 1: Brilliant II PID control (reverse action) 2: Brilliant II Heat/Cool PID control [water cooling] 3: Brilliant II Heat/Cool PID control [air cooling] 4: Brilliant II Heat/Cool PID control [Cooling gain linear type] 5: Brilliant II Position proportioning PID control (reverse action) 6: Brilliant II Position proportioning PID control (direct action)	1 ^a
IdDP	Integral/Derivative time decimal point position	0: 1 second setting (No decimal place) 1: 0.1 seconds setting (One decimal place)	0
dGR	Derivative gain	0.1 to 10.0	6.0
oHH	ON/OFF action differential gap (upper)	TC/RTD inputs: 0.0 to Input span (Unit: °C [°F]) (Varies with the setting of the Decimal point position) Voltage (V)/Current (I) inputs: 0.0 to 100.0 % of input span	1 ^a
oHL	ON/OFF action differential gap (lower)	Same as oHH	
RoBE	Action (high) at input error	0: Normal control 1: Manipulated output value at input error	0
RUrE	Action (low) at input error	Same as RoBE	
P5n	Manipulated output value at input error	-105.0 to +105.0 %	0.0
rHb1	Manipulated output value (MV1) at STOP mode	-5.0 to +105.0 %	-5.0
rHb2	Manipulated output value (MV2) at STOP mode	Same as rHb1	
oRU	Output change rate limiter (up) [MV1]	0.0 to 100.0 %/seconds (0.0: OFF)	0.0
oRD	Output change rate limiter (down) [MV1]	Same as oRU	
oLH	Output limiter high (MV1)	Output limiter low (MV1) to 105.0 %	105.0
oLL	Output limiter low (MV1)	-5.0 % to Output limiter high (MV1)	-5.0
oRU2	Output change rate limiter (up) [MV2]	Same as Output change rate limiter (up) [MV1]	
oRD2	Output change rate limiter (down) [MV2]	Same as Output change rate limiter (down) [MV1]	
oLH2	Output limiter high (MV2)	Output limiter low (MV2) to 105.0 %	105.0
oLL2	Output limiter low (MV2)	-5.0 % to Output limiter high (MV2)	-5.0
dFP	Derivative action	0: Measured value derivative 1: Deviation derivative	0
US	Undershoot suppression factor	0.000 to 1.000	1.000 ^a
dbPR	Deadband position adjust	0.0 to 1.0	0.0

^a Factory set value varies depending on the instrument specification.

Symbol	Name	Data range	Factory set value
F52	Function block 52	This is first parameter symbol of Function block 52.	
ATb	AT bias ^b	-Input span to +Input span	0
ATC	AT cycles	0: 1.5 cycles 1: 2.0 cycles 2: 2.5 cycles 3: 3.0 cycles	1
ATH	AT differential gap time	0.0 to 50.0 seconds	10.0
ATOn	Output value with AT turned on	Output value with AT turned off to 105.0 %	105.0
ATOff	Output value with AT turned off	-105.0 % to Output value with AT turned on	-105.0
PLH	Proportional band limiter (high) [heat-side]	TC/RTD inputs: 0 (0.0, 0.00) to Input span ^b (Unit: °C [°F]) Voltage (V)/Current (I) inputs: 0.0 to 1000.0 % of input span	Input span ^a
PLL	Proportional band limiter (low) [heat-side]	Same as PLH	
ILH	Integral time limiter (high) [heat-side]	0 to 3600 seconds or 0.0 to 1999.9 seconds	3600
ILL	Integral time limiter (low) [heat-side]	(Varies with the setting of the Integral/Derivative time decimal point position)	0
dLH	Derivative time limiter (high) [heat-side]	Same as ILH	
dLL	Derivative time limiter (low) [heat-side]	Same as ILL	
PcLH	Proportional band limiter (high) [cool-side]	TC/RTD inputs: 1 (0.1, 0.01) to input span ^b (Unit: °C [°F]) Voltage (V)/Current (I) inputs: 0.1 to 1000.0 % of input span	Input span ^a
PcLL	Proportional band limiter (low) [cool-side]	Same as PcLH	
ICLH	Integral time limiter (high) [cool-side]	Same as Integral time limiter (high) [heat-side]	
ICLL	Integral time limiter (low) [cool-side]	Same as Integral time limiter (low) [heat-side]	
dCLH	Derivative time limiter (high) [cool-side]	Same as Derivative time limiter (high) [heat-side]	
dCLL	Derivative time limiter (low) [cool-side]	Same as Derivative time limiter (low) [heat-side]	
PRJ	Proportional band adjusting factor [heat-side]	0.01 to 10.00 times	1.00
IRJ	Integral time adjusting factor [heat-side]	Same as PRJ	
DRJ	Derivative time adjusting factor [heat-side]	Same as IRJ	
PcRJ	Proportional band adjusting factor [cool-side]	Same as PRJ	
ICRJ	Integral time adjusting factor [cool-side]	Same as IRJ	
dCRJ	Derivative time adjusting factor [cool-side]	Same as DRJ	
F53	Function block 53	This is first parameter symbol of Function block 53.	
Ydb	Open/Close output neutral zone	0.1 to 10.0 % of output	2.0
YHS	Open/Close output differential gap	0.1 to 5.0 % of output	1.0
Ybr	Action at feedback resistance (FBR) input error	0: Action depending on the valve action at STOP 1: Control action continued	0
PaS	Feedback adjustment	At the Feedback adjustment screen, press the shift key for 5 seconds to start the adjustment.	—
nOT	Control motor time	5 to 1000 seconds	10
oLR	Integrated output limiter	0.0 to 200.0 % of control motor time 0.0: Integrated output limiter function OFF This value becomes invalid when Feedback resistance (FBR) input is used.	150.0
HAL	Valve action at STOP	0: Close-side output OFF, Open-side output OFF 1: Close-side output ON, Open-side output OFF 2: Close-side output OFF, Open-side output ON	0
YASo	Action at saturated output	0: Invalid 1: Valid	0
F54	Function block 54	This is first parameter symbol of Function block 54.	
STS	ST start condition	0: Activate the Startup tuning (ST) function when the power is turned on; when transferred from STOP to RUN; or when the Set value (SV) is changed. 1: Activate the Startup tuning (ST) function when the power is turned on; or when transferred from STOP to RUN. 2: Activate the Startup tuning (ST) function when the Set value (SV) is changed.	0
STPE	ST proportional band adjusting factor	0.01 to 10.00 times	1.00
STIE	ST integral time adjusting factor	Same as STPE	
STDE	ST derivative time adjusting factor	Same as STPE	
F55	Function block 55	This is first parameter symbol of Function block 55.	
CHRg	Automatic temperature rise group	0 to 16 (0: Automatic temperature rise function OFF)	0
rSG	RUN/STOP group	0 to 16 (0: RUN/STOP group function OFF)	0
CHRd	Automatic temperature rise dead time	0.1 to 1999.9 seconds	10.0
CHRf	Automatic temperature rise gradient data	0.1 to Input span/minutes	1.0

^a Factory set value varies depending on the instrument specification.
^b Data range varies depending on the Decimal point position

Symbol	Name	Data range	Factory set value
F60	Function block 60	This is first parameter symbol of Function block 60.	
CnP1	Communication 1 protocol	0: RKC communication 1: Modbus 2: Intercontroller communication ^b	0 ^a
CnP2	Communication 2 protocol	0: RKC communication 1: Modbus 2: Intercontroller communication	2
F70	Function block 70	This is first parameter symbol of Function block 70.	
SHrT	Setting change rate limiter unit time	1 to 3600 seconds	60
STdP	Soak time unit	0: 0 hours 00 minutes to 99 hours 59 minutes 1: 0 minutes 00 seconds to 199 minutes 59 seconds	1
F71	Function block 71	This is first parameter symbol of Function block 71.	
SLH	Setting limiter high	Setting limiter low to Input scale high (Varies with the setting of the Decimal point position)	Input scale high
SLL	Setting limiter low	Input scale low to Setting limiter high (Varies with the setting of the Decimal point position)	Input scale low
F91	Function block 91	This is first parameter symbol of Function block 91.	
C492	ROM version monitor	Display the version of loaded software.	
OT	Integrated operating time monitor	0 to 19999 hours	
TCJ	Heating peak value ambient temperature monitor	-10.0 to +100.0 °C	

^a Factory set value varies depending on the instrument specification.
^b Intercontroller communication is available only when one communication function is selected.

Table 1: Digital input (DI) assignment

Set value	DI 1	DI 2	DI 3	DI 4	DI 5
1	Unused	Unused	Unused	Unused	Unused
2	Memory area number transfer (1 to 8)			Memory area set	RUN/STOP
3	Memory area number transfer (1 to 8)			Memory area set	Unused
4	Memory area number transfer (1 to 8)			Memory area set	AUTOMAN
5	Memory area number transfer (1 to 8)			Memory area set	Interlock release
6	Memory area number transfer (1 to 8)			RUN/STOP	Unused
7	Memory area number transfer (1 to 8)			RUN/STOP	AUTOMAN
8	Memory area number transfer (1 to 8)			RUN/STOP	Interlock release
9	Memory area number transfer (1 to 8)			Unused	AUTOMAN
10	Memory area number transfer (1 to 8)			Unused	Interlock release
11	Memory area number transfer (1 to 8)			AUTOMAN	Interlock release
12	Memory area number transfer (1 to 8)				
13	RUN/STOP	REMLoc*		AUTOMAN	
14	RUN/STOP	REMLoc*		Interlock release	
15	RUN/STOP	AUTOMAN		Interlock release	
16	REMLoc*	AUTOMAN		Interlock release	
17	RUN/STOP	REMLoc*			
18	RUN/STOP	AUTOMAN			
19	RUN/STOP	Interlock release			
20	REMLoc*	AUTOMAN			
21	REMLoc*	Interlock release			
22	AUTOMAN	Interlock release			
23	RUN/STOP				
24	REMLoc*				
25	AUTOMAN				
26	Interlock release				

RUN/STOP: RUN/STOP transfer AUTOMAN: Auto/Manual transfer REMLoc: Remote/Local transfer
* In the case of the optional function A, C and D without Remote setting input and Communication, the Remote/Local transfer becomes invalid.

Table 2: Output assignment

"Energized" or "De-energized" can be selected for the Digital outputs (DO1 and DO2).
[However, with the exception of FAIL ("De-energized" fixed)]

Set value	OUT1	OUT2	DO1	DO2	Set value	OUT1	OUT2	DO1	DO2
1	MV1	MV2	EV1	EV2	9	MV1	HBA	EV1	EV4
2	MV1	MV2	EV1	EV4	10	MV1	HBA	EV1	FAIL
3	MV1	MV2	EV1	HBA	11	MV1	HBA	EV4	FAIL
4	MV1	MV2	EV1	FAIL	12	MV1	FAIL	EV1	EV2
5	MV1	MV2	EV4	HBA	13	MV1	FAIL	EV1	EV4
6	MV1	MV2	EV4	FAIL	14	MV1	EV1	EV2	EV3
7	MV1	MV2	HBA	FAIL	15	MV1	EV4	EV1	EV2
8	MV1	HBA	EV1	EV2					

MV1: Control output 1, MV2: Control output 2, HBA: Heater break alarm, FAIL: Fail output (De-energized only), EV1 to EV4: Event output 1 to Event output 4

- For Position proportioning PID control, regardless of the above selection, OUT1 becomes the open-side output, and OUT2 becomes the close-side output.
- HBA output becomes OR when two CT inputs are available.